

KETRON X SERIES



o w n e r ' s m a n u a l

INDEX

SWITCH ON THE INSTRUMENT	pag. 1
SAFETY INSTRUCTIONS	1
CONNECTIONS / OUTPUTS	4
VOICES	6
USER VOICES	8
DRAWBARS	10
PROGRAM	11
SOUND BANK / RAM CARD	14
KEYBOARD CONTROLS	16
EFFECTS	19
UTILITY	23
STYLES	29
ARRANGER	33
CUSTOM STYLE / ARRANGE VIEW	35
DRUM MIXER	36
PATTERN	38
SONG PLAY	45
FOOTSWITCH	50
SONG RECORD	51
ACCORDION	51
OUT ASSIGN	53
ARABIC	54
REGISTRATION	55
MIDI	56
DISK	60
SAMPLER	66
SEQUENCER	71
VOICE BANKS	91
STYLES	93
GROOVES	95
DRUM SETS	96
ACCESSORIES	105
MIDI IMPLEMENTATION	107
EXCLUSIVE MESSAGES	109
TECHNICAL SPECIFICATIONS	114
ABNORMAL RUNNING CONDITIONS	115
ERROR MESSAGES	115

KETRON X SERIES

KETRONX1



KETRONX4



KETRONX8



This Instructions manual is valid for instruments X1 (keyboard), X4 (expander module) and X 8 (keyboard with buttons) .

In fact, these instruments have the same technical-musical characteristics and only differentiate themselves from one another in the type of keyboard used (this is the case for X 1 and X 8) or for the fact that they do not have internal amplification (this is the case for X4).

SWITCH ON THE INSTRUMENT

When the instrument is switched on, the display panel indicates the name of the instrument and, straight after this, (only when the HARD DISK has been installed inside it) the inscription “SOUND BANK AUTOLOADING...” appears for a few seconds. This function automatically activates the loading of the Sound Bank Folk contained in folder 1 of the HD.

The folder from which to draw the Sound Bank can however be selected by the user by means of a special procedure that will be described further on in the POWER ON SETUP paragraph.

The user can import new Sound Banks from floppy disk, save them onto a specific folder of the Hard disk and then set it up so that a specific Sound Bank will be loaded automatically when the instrument is switched on.


This useful function also allows the user to select and load new sounds while playing or even before playing, depending on the type of repertoire required.

WARNING

In the Pattern section, a few “bonus” PATTERNS have been saved, which partly use sounds contained in the Sound Bank Folk loaded when the instrument was switched on.

Should the instrument not be equipped with a Hard disk and consequently be unable to load these sounds, these Patterns could be played incorrectly.

SAFETY INSTRUCTIONS



MEANING OF GRAPHIC SYMBOLS:

The lightning arrow inside an equilateral triangle warns you about the presence of dangerous, not insulated voltage that may constitute a risk of electric shock.

The exclamation mark in an equilateral triangle informs you about important instructions in the User's Manual.

INSTRUCTIONS ABOUT RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERONS.

Warning: to reduce the risk of fire or electric shock, do not expose this instrument to rain or moisture.

- Earthing instructions -

This product must be connected to an earthed outlet. In case of malfunctioning, the earthing will reduce the risk of electric shock. The instrument comes with an earthed power cable and plug to be used with an earthed outlet.

DANGER - Improper earthing connections may cause electric shocks. In case of doubts, have your electric installation checked by a qualified electrician. Do not modify the power cable coming with the instrument.

IMPORTANT SAFETY AND INSTALLATION INSTRUCTIONS



WARNING - When using electrical products, some basic precautions must be followed, including the following:

- 1** Before using this instrument, carefully read the User's Manual.
- 2** When the instrument is used by children, the presence of an adult is required.
- 3** Do not use the instrument near water, for example near a wash-basin, a swimming-pool, a wet surface, etc.
- 4** The instrument must be used only on supports recommended by the manufacturer.
- 5** Do not play the instrument at a high volume for a long period of time: exceedingly loud music can cause damage to your health.
- 6** The instrument is to be used in a position where adequate ventilation is provided.
- 7** Use the instrument far away from heat sources such as radiators, heaters, etc.
- 8** Use only the supplied power cable for connecting the instrument to the mains.
The identification and power supply data are reported on the bottom of the instrument.
- 9** Disconnect the power cable if the instrument is not used for longer periods of time.
- 10** Be careful to avoid any objects or liquids from falling into the inside of the enclosure.
- 11** Bring the instrument to an service centre in the following cases:
 - a. Damages on the power cable or plug.
 - b. Objects or liquids fallen into its inside.
 - c. The instrument has been exposed to rain.
 - d. Abnormal running or an evident decrease of the instrument's performance.
 - e. The instrument has fallen down or the enclosure has been damaged.
- 12** Never try to repair the instrument yourself. All operations must be performed by specialised engineers.

KEEP THESE INSTRUMENTS IN A SAFE PLACE

HOW TO AVOID RADIO/TV INTERFERENCE

This instrument operates at radio frequencies, and if not correctly installed according to the instructions supplied, it may cause interference with radio and television reception.

Though this instrument has been designed according to the applicable standards and notwithstanding the reasonable protections against interference it has been equipped with, there is no guarantee that such events will not occur. In order to check if the interference is actually caused by this instrument, switch it off and see if the interference disappears. Then switch it on again and check if the interference appears again.

Once you have made sure that the interference is originated by this instrument, take one of the fol-

lowing measures:

- 1** Turn the radio or TV antenna in a different direction.
- 2** Modify the instrument's position with respect to the receiver.
- 3** Increase the distance between the instrument and the receiver.
- 4** Connect the instrument's plug to a different outlet to make sure that the instrument and the receiver are connected to two different circuits.
- 5** If necessary, contact a specialised technician.

WARNINGS

After having read the safety precautions and instructions on the previous pages, carefully read and conform to the following recommendations:

POWER SUPPLY

- Before connecting this instrument to any other equipment (amplifier, mixer, other MIDI instruments, etc.) make sure that all units are switched off.
- Read the instructions about Radio and TV interference.

HOW TO CLEAN THIS INSTRUMENT

- Use only a soft and dry cloth to clean the external surface of your instrument.
Never use petrol, thinners or solvents generally speaking.

OTHER PRECAUTIONS

- If you wish to use your instrument abroad and if you have any doubts about the power supply, contact a qualified engineer previously.
- The instrument should never be subject to strong vibrations.
- Never exert excessive pressure on the keys and knobs.
- Do not place any objects on the central display. The transparent panel could brake or be damaged and the reading of data could become more difficult.
- The instrument's cover could be slightly heated during playing. This is caused by heat dissipation of its internal components and is considered to be a normal effect.
Nonetheless the instrument should be placed in a ventilated area, if possible.

IN ORDER NOT TO LOOSE DATA

Please remember that the data stored in the instrument can be deleted at any time in case of abnormal running conditions. We therefore advise to carry out back-up copies of your data during the various programming phases.

CONNECTIONS / OUTPUTS

REAR PANEL

The rear panel is provided with the following connection points: (from the left)

Speaker off / on: Internal loud speaker cut out switch.

Inputs: These are two stereo audio inputs (Right and Left/Mono) that may be used to connect external devices such as MIDI Expanders, CD player, MiniDisc , DAT etc.. The signal of these devices will be amplified by means of the same stereo output of the instrument (Left / Right Output) but at a constant level, or independently from the Volume controls of the instrument.

Outputs: The instrument is provided with 4 audio outputs. The Left/Mono 1 and Right 2 outputs are the two main stereo outputs and are used to connect the system to the external amplification system (Stereo Mixer or Stereo amplifier).

It is important to make sure that the Bass, Middle and Treble tones of the Mixer or amplifier are set at a linear position (central) so that the natural balance of the keyboard sounds are not altered. Furthermore the quality of the instrument speakers or monitors is fundamental in order to guarantee a correct audio response throughout the entire frequency range without any excessive privilege to the Bass or Treble bands.

The instrument may also be connected to a normal domestic Hi-Fi system making sure that the amplification is not excessively high or distorted.

It may occur that the level of the output signal from the instrument is too high for the input sensitivity of the AUX IN of the stereo. In this case the sound would be quite distorted. If this should occur, merely reduce the general instrument volume by means of the Master potentiometer to restore normal sound levels.

Outputs 3 and 4 are 2 Mono outputs which may be used (in addition to the 2 main stereo ones) for the separate external amplification of some specific instrument sections. For further details concerning the possibility of the assignment of the 3 and 4 Outputs refer to the OUT ASSIGN. chapter (Page 49).

Footswitch: This is a multi-pin socket for the connection of the two FS 6 or FS 13 pedals (optional). These pedals allow the easy control of many instrument functions (i.e. Fill In, Ending etc) without taking the hands off the keyboard. The list of programmable functions on the 2 pedal controls is found in the FOOT SWITCH chapter (Page 46).

Sustain pedal: A socket for the Sustain pedal control (optional). The Sustain Pedal is an accessory required for the ideal response of the keyboard over all the percussion instruments such as the Piano, E-piano, Harpsichord etc.

Volume pedal: A socket for the stereo Volume Control pedal (optional).

Warning : by connecting Volume pedals to the instrument different to those recommended for the instrument may cause keyboard anomalies, for example, incorrect adjustment of the Volume or worse still hazardous short-circuits.

Midi: The instrument is provided with 4 Midi sockets:

Midi in 1 (GM): This input is to be used to connect a Computer or other instruments transmitting in General Midi Standard (Sequencers, Keyboards etc.), if only the Midi In input is used and not the keyboard and panel controls.

Midi in 2 (Keyboard): The Midi In 2 input must be used when the instrument is to be connected to Master keyboards, Keyboards, Midi Accordions, Digital Pianos etc.. In this case the instrument is controlled by an external keyboard and performs exactly like a Midi module.

Midi Out: Main Midi Output of the keyboard. To be used when transferring data to an external

Midi unit.

Midi Thru: The Midi Thru is a copy of the Midi In 1 (GM) and may be used to connect one or more expander modules in series with the instrument.

The THRU socket functions exclusively in conjunction with the Midi in 1 (GM) socket and therefore is inefficient when used in conjunction with the Midi In 2 socket (Keyboard).

Computer Interface: By means of the Computer Interface socket the instrument is able to communicate with computers without MIDI interface (PC or Macintosh). This may be useful, for example, for receiving / transmitting information about Songs or about music sequences of various kinds. A special cable is required for the connection (optional – available on request) that differs according to whether a PC or McIntosh is to be connected.

FRONT PANEL

The front panel of the instrument is provided with the following connection points:

Headphone: A socket for the Stereo headphones. We advise the use of a high quality pair of Hi-Fi headphones in order to avoid losing the quality sound of the instrument especially of the extreme high and low frequencies.

The sound volume in the headphones may be adjusted directly using the Master potentiometer. When the headphones are connected the internal amplification is shut off.

Micro Input: A stereo Input for a Microphone with sensitivity control.

2 Microphones may be connected to the Micro socket by means of an appropriate adapter (which will function in Mono mode). If the keyboard is also equipped with the Vocalist kit (optional), one of the 2 Microphones may control the Harmonizer effect whereas the other may function normally without interfering with the Vocalist functions.

The MICRO input may also be used to connect other instruments such as the Electric Guitar, Keyboard etc.. Make sure to adjust the Gain accordingly.

For all the Microphone control functions, refer to the MICRO section within the EFFECTS chapter (Page 22).

Note

The Microphone level may vary considerably depending on the type of Microphone used.

Reset the Gain control to zero each time the Microphone is connected or disconnected in order to avoid undesired noises. If the microphone is placed too near the internal speakers (or external in the case of external amplification) some feedback may be encountered. Adjust the position of the microphone and reduce if necessary the amplification level or the Microphone Gain.

Amplification: The keyboard is provided with internal amplification with a 2 x 25 WRMS stereo amplifier, two 8" Loudspeakers and two tweeters.



VOICES

The complex system of the basic sounds of the X series is sub-divided into various Banks according to the scheme below:

VOICES BANK 1 / 2	256 Sounds (128 on 2 Banks)
RAM BANK	112 Sounds + 8 Drum Sets + Grooves
CARD BANK	112 Sounds + 8 Drum Sets + Grooves
USER VOICES BANK 2	16 Digital Drawbars + Samples + .Wave files

Furthermore there are other Voice Banks available with the possibility of controlling, combining and modifying the standard Sounds listed above:

2nd VOICE	combined with Voices Bank 1 and 2, Users and Drawbars
1 TOUCH	48 distributed on Bank 1 and 2
PROGRAMS	128
USER VOICES	128


VOICE BANKS

The Bank is selected using the Bank 1/2* key. Bank 2 is in use when the LED is lit, whereas when the LED is off Bank 1 is in use.

The Voices of Bank 1 are grouped into 16 families exactly according to the General Midi standards. The Voices of Bank 2, in order to utilise the instrument Timbre possibilities in the best possible manner, are sub-divided into groups of 8 with free sounds assignment.

To select a Voice, select the family key and then using the 8 keys from A – H select the Voice desired. The selected Voice appears at the top right-hand corner of the Display.

The number at the side (55 in the illustration) corresponds to the Volume of the right Hand, whereas the smaller writing below the Voice (Violas in the illustration) corresponds to the second Voice assigned. (See 2nd Voice below). The complete list of Voices of Banks 1 and 2 are provided at the end of the handbook.



SECOND VOICE

To each of the 256 standard sounds of the instrument (also to the User Voices and to the Drawbars) a second Voice has been matched, which is required to immediately confer additional emphasis to the melody line without necessarily having to program a similar combination within the Program.

Merely press the 2nd Voice key to enter the 2nd Voice.

With the Program enabled the 2nd Voice is disabled.

The second Voices pre-selected by the manufacturer may be modified by changing the Voice, Volume and the Transposer as indicated below.

2nd Voice Edit

Per modificare la 2nd Voice:

- 1 press the Edit key at the side of 2nd Voice. A black arrow appears on the display next to 2nd Voice together with the initials T: --- 45 , where T refers to the Transposer and 45 to the Volume of the 2nd Voice.
- 2 select the new voice from the 2 Voice Banks available.
- 3 to set the Transposer use the 2 Cursor / Transposer < > keys. A transposition of +/- 12

semitones is possible. The position --- corresponds to the normal tuning.

4 use the 2 Value keys to modify the volume.

To save the 2nd Voices modified in the internal flash memory:

5 press SAVE/ENTER and select 2nd Voices. Then press the Save key (F10) to confirm.

Pressing both keys 2nd Voice and Edit at the same time, the 2nd Voice active at the time being is confirmed (function shown by an asterisk) and will not change any more, even if the various instruments' voices are modified.

This procedure completely saves all the 2nd Voices stored on the keyboard, namely those relating to both Bank 1 and 2 and those relating to the User Voices.

The DEFAULT function is used to restore the original 2nd Voices of the manufacturer.

To reload the latter, simply press SAVE / ENTER , select 2nd Voices and press DEFAULT to confirm.

Warning: If the aforesaid Save procedure is not performed, the new 2nd Voices saved will be lost when the instrument is switched off.

It is therefore advisable to frequently save the data during a long editing phase.

1 TOUCH VOICE

The 1 Touch section includes 48 Voices (24 on Bank 1 and 24 on Bank 2) selected from the 256 standard Voices, from the Users Voices and from the Programs.

This function allows the user to select the Voice desired by pressing one key only rather than the 2 or 3 keys usually required to change the sound within the GM standard.

Furthermore it allows the user to group 48 preferred

Voices, 24 for each of the 2 Banks in two individual lists that are clearly shown on the display:

(The 1 Touch list in the illustration below is purely indicative)

53A FUNKY_1	GRAND PIANO 39	
Factory	Violas	
Split : C_3 ♩ = 119 Left Level: 50		
01 GRAND PIANO	09 TROMBONE	17 LESLIE
02 PHILARMONIC	10 CIRCUS SAX	18 ROCK ORGAN
03 BRASS1	11 ROCK SAX	19 MARIABA
04 JAZZ ORGAN	12 FLUTE	20 HAWAIIAN
05 FLAMENCO	13 MANDOLIN	21 BANJO
06 CHOIR 1	14 MUSETTE 1	22 ANDES PIPE
07 VIOLIN	15 MILES MUTED	23 TRUMPET
08 SLOW STRING	16 FM PIANO2	24 CLARINET

To select the 1 Touch voices:

1 press the 1 Touch key. The 1 Touch sound list appears on the display. (Press Exit to return to the main display).

2 press the Bank 1 / 2 key to select the Bank.

3 Select the 1 Touch item in the Voice Bank section by directly pressing the key having the same number from 1 to 24 (the number is clearly seen above the first 24 keys).

The selection of the 1 Touch Bank is achieved using the Bank Ω key or the Page < > key.

The list of the 48 1 Touch Voices stored on the keyboard is purely indicative; the user may easily modify it according to the specific requirements.

To modify the 1 Touch list:

1 Press the Save/Enter key and select 1 Touch List.

2 Enable the Edit function.

3 Using the Cursor < > keys, select the number of the item and then select the voice, be it a Voice from Banks 1/ 2, a User voice or Program.

4 Once the list has been completed, press the Save/Enter key once again to save it and confirm by pressing the Save key (F10).

USER VOICES

The User Voice section enables the user to modify and customise the sounds of the X series thanks to a sophisticated editing program.


The 128 User Voices are divided into families, just like the standard Voices and located in Bank 1 (Bank 2 as we will see is assigned to the Drawbars, the Samples and the Wave files).

To program a User Voice:

- 1** Select the Voice to be modified. The Voice may be a pre-existing Voice of the manufacturer or even a standard Voice selected from the 256 voices of the 2 Banks (in the second hypothesis the User key must remain off).
- 2** Press the Edit Voice key (F 7). The following will appear on the display:

The sound Edit function includes the controls of the ADSR (Attack, Decay, Sustain, Release, Level, Resonance, Cut Off), the Effects, the controls with Aftertouch and Wheel, LFO and dynamics control.

Access is gained to the 4 Edit Voice pages using the Page < > keys.




ADSR / FILTER - the controls of the ADSR are selected using the F1 – F5 keys. The curve of the ADSR is displayed at the centre of the Display. Use the F 6 and F 7 keys to select the 2 Filter controls, Resonance and Cut Off.

Using the Value < > keys the value of each part is modified.

EDIT VOICE EFFECTS - As for the Effects, using the Value < > keys the various pre-set Effects combinations may be selected and using the Cursor < > keys the contents of the Effects or the Effects combination to be edited are viewed.

For a better understanding of the possibilities of the Effects section of the instrument and for the list of all the kinds of Effects available we advise you to refer to the EFFECTS chapter (Page. 22). Once the individual Effect to be edited has been selected using the Cursor, the Value keys are used to scroll all the versions of the Effects, User inclusive.

Then again with the Cursor < > keys access may be gained to the boxes below in which the Volumes of the various Effects selected are located: the value of the Volume may be modified using the Value < > keys.




EDIT VOICE AFTERTOUCH - WHEEL

This part of the Edit section enables the user to assign some functions to the User Voice that may be controlled by means of the Aftertouch of the keyboard or by means of the Wheel Modulation or both.

Use the Cursor < > keys to scroll all the options foreseen for Aftertouch and Wheel. Using the Value < > keys, On / Off is selected.

Cut Off: controls the opening and closing of the filter.



LFO Pitch, Amplitude and Filter: these activate the modulation on the Oscillator (Vibrato), on the Amplitude (Tremolo) or on the Filter.

Volume: Volume control by means of the Aftertouch.

Wha Wha: Wha Wha effect assigned to the wheel Modulation.

Slide: this special effect affects the sound tuning, creating a sort of Pitch envelope each time a key is pressed hard. This proves extremely useful while playing to simulate the attack of the typical sound of the wind instruments.

Attack: this parameter causes all the effects controlled with the After Touch to start with a slight and gradual delay. Used appropriately this function confers impressive expressiveness to the melody lines.

EDIT VOICE LFO - VELOCITY

This section controls the parameters regarding the LFO's and the Dynamics of the User Voice.

Use the Cursor < > keys to select the box and the Value < > keys to modify the value.

LFO 1 (Dco) Rate, Depth, Delay : Vibrato velocity, intensity and delay control.

LFO 2 (Dcf, Dca) Rate, Depth, Delay : velocity, intensity, delay control applied to the modulation on the filter and on the Amplitude.

VELOCITY OFFSET: this parameter controls the slope of the dynamic curve controlled in Amplitude. 64 is the value corresponding to the standard setting of the internal sound.

VELOCITY FILTER: controls the opening of the Filter according to the key dynamics. With value 64 the standard condition is achieved, with lower values a less brilliant sound is achieved even when playing with high dynamics.

ATTACK		Edit Voice		RESONANCE	
0		[GRAND PIANO]		0	
DECAY		LFO 1 Rate 64		CUT OFF	
64		(Dco) Depth 64		64	
SUSTAIN		Delay 0		EFFECTS	
64		LFO 2 Rate 48		AFTERTOU	
RELEASE		(Dcf) Depth 0		WHEEL	
64		(Dca) Depth 0		LFO	
LEVEL		VELOC. SLOPE 64		VELOCITY	
64		VELOC. FILTER 64			

To save the User Voice once modified:

- 1 Press Save / Enter.
- 2 At the top right-hand side of "Save Voice" the original name of the User Voice is indicated. The current number and name of the location are indicated below.
To change the location number of the new User Voice simply set a new number by selecting it by means of the Voice bank keys (1 –128).
- 3 It is also possible to write a new name for the User Voice. To do this, simply write the letters by pressing the keys between C2 and F 5 (or using the Value < > keys) and moving the sector by means of the Cursor < > keys.
A maximum of 12 letters are permissible.
The last symbol (F 5) cancels the string of letters from the point in which the cursor is positioned onwards.
- 4 If the name has been written correctly press Save to confirm the entry. The User Voice saved is stored in the memory even after the instrument has been switched off. To save the 128 User Voices on Disk see the DISK Chapter.

Save User Voice [GRAND PIANO]	
001 USERS	
NEW NAME	
GRAND PIANO	
Undo	
Escape	<Letters with C2/F5 keys sector with CURSOR<>>
	Save

DRAWBARS


The digital Drawbars section is positioned in the first 16 User Voice locations of Bank 2.

To gain access to the section:

- 1 press the User Voice key.
- 2 select Bank 2 (Bank 1/2 key lit)
- 3 press the EDIT VOICE function key (F7).

The Drawbars are not selected per family as for the GM standard sounds, but by simply following the progressive number indicated above the keys from 1 to 16.

In addition to the numerous organ Voices stored on the keyboard, the Drawbars section allows the user to program many other organ sound combinations following the typical system of the electro-magnetic organs, or rather by means of the harmonic drawbars or Drawbars.



Click: typical noise in the sound attack of the electro-magnetic organ. The value is modified using the Value < > keys.

(Note: the Click included in the Drawbar effect is not saved in the Program, but may be added as an individual item at a later date: Prg. Change 91 Bank 2)

Sustain: Sustain effect, typical of the electronic Organs of the Sixties/Seventies. The value may be changed using the Value < > keys.

Percussion: the percussion is a fundamental feature in the sound of the Jazz and Rock Organ. The 2 percussions 4' and 2 2/3' are alternated by pressing the function key (F6) successively. The volume is modified using the Value < > keys.

Effects: by pressing the F 7 key access is gained to the Effects of the Drawbars, consisting of Chorus and Vibrato. Vibrato may be applied to the Oscillator (Dco), to the Amplitude (Dca) or to the Filter (Dcf) with an overall velocity control (Rate).

Use the Cursor < > keys to select the effect desired and use the Value + / - keys to modify the amount. Press the F7 key once again to return to the Drawbars display.

Drawbars: 8 Drawbars are available: 16', 5 1/3', 8', 4', 2 2/3', 2', 1 3/5', 1'. The first 6 Drawbars may be controlled by means of the first six pairs of Volume keys situated at the left-hand side of the panel (16' - 2'); the remaining 2 Drawbars (1 3/5' - 1') are controlled by means of the 2 Page < > and Cursor < > keys .

The volume range of each Drawbar is pointed out with a numeric grading from 0 to 8 (the actual control steps are 32).


The Drawbar level is reset to zero by pressing the two keys at the same time.

To save a Drawbar combination:

- 1 Press Save / Enter.
- 2 If the name is not to be modified simply press Save to confirm.

To modify the name write the letters using the C2 to F5 keys and move the sector using the Cursor < > key. Then press Save to confirm the entry.

- 3 The Default key restores the original combinations of the manufacturer. The Undo function on the other hand saves only the last combination saved in that location.



PROGRAM

The Program section is a powerful Editing area for the X series sounds. It enables the combination of up to 4 Voices simultaneously, with the possibility of modifying the Voice, Volume, Octave, Tuning, Pan/Pot, Effects, Keyboard split, Sustain functions, Portamento and Velocity switch for each one of them.

Furthermore it also enables the user to create special effects such as Duet and Trio. By using the Programs appropriately the user may expand and customise the sounds system of the instrument as desired.

To save a Program:

- 1** Press the Program key.
- 2** Press the Edit Program function key (F8). Access is gained to page no. 1:

The display shows the first page of the Edit Program with these functions:

Voices: By repeatedly pressing the function key F 1 or F 6 the Voice is selected. To modify the voice simply select it normally using the Voice Bank keys.

Volume: to gain access to the 4 Volumes, repeatedly press the function key F2 or key F 7. The Volume value is modified using the Value < > keys. If the two Value keys are pressed simultaneously the volume is reset to zero.

Shift: the Shift control shifts the tuning of the Voice by Semitone in semitone, with a total range of + / - 63 semitones. By pressing repeatedly the function key F 3 or F 8 the Voice is sought; with the Value < > keys the value is set.

Tune: fine tuning control with a max. range of +/- 63 steps corresponding to + / - one semitone. The Voice is selected using the function key F 4 or F 9 and the value is modified using the Value < > keys.

Pan: the Pan / Pot controls the location of the Voice in the stereo panorama with an amplitude of 64 steps Left and 64 steps Right. The 0 value corresponds to the middle position. The Voice is selected using the F 5 or F 10 keys. The value is controlled using the Value < > keys. Use the Page > key to proceed to the 2nd page of the Program concerning the Effects.

Effect: The group of Effects is indicated on the top line.

The groups are combinations of pre-set Effects that allow the simultaneous functioning of a number of Effects. Each program may run with one group of Effects alone.

Use the Cursor < > keys to scroll the 5 available groups:

- Chorus / Distorsor / Delay
- Distorsor > Chorus / Chorus
- Delay > Chorus / Chorus
- Distorsor > Delay / Chorus / Delay
- Distorsor > Delay > Chorus / Delay > Chorus / Chorus

For each Voice one of the Effects may be enabled or one of the combinations of Effects between the diagonal strokes.

Voices: the voices of the 4 Program Voices may also be selected from this display.

Reverb.: Controls the amount of Reverberation for each Voice. Use the F2 or F 7 key to select the Voice and the Value + / - keys to set the value.

Effect: this parameter enables the selection of the Effect or the combination of Effects for the Voice.

001 GRAND_PIANO				Page 1/3
VOICES ▶	Grand	Rock	Off	Off
VOLUME ▶	55	55	31	31
SHIFT ▶	---	-12	---	---
TUNE ▶	---	+2	---	---
PAN ▶	32L	32R	--	--

DIST+DEL CHORUS DELAY				Page 2/3
VOICES ▶	Grand	Rock	Off	Off
REVERB ▶	44	32	0	0
EFFECT ▶	CHORUS	OFF	OFF	OFF
AMOUNT ▶	63			
DELAY ▶				
CHORUS ▶				

Use key F3 or F8 to select the Voice and the Value keys to set the type of Effect.

Amount: Effect amount control. Use the F4 or F9 key to select the Voice and the Value keys to modify the value. Press the 2 Value keys simultaneously to reset the value to zero.

Delay - Chorus: these parameters enable the individual control of the Chorus and Delay level if 2 or 3 Effects are overlapped. Use the F5 or F10 key to select the 4 Voices for both Chorus and for Delay. Use the Value < > keys to control the amount.

Use the **Page >** key to proceed to **Page no.3** Edit Program concerning the Range, Velocity, Sustain, Portamento, Duet and Trio functions.

Voices: Use the F1 or F6 key to select the Voice for which the Voice is to be changed.

Range: this parameter restricts the keyboard section within which the Voice may function.

2 Sections are foreseen for each Voice which establish the lowest note and the highest note.

Use function keys F2 or F7 to select the sector.

The value of the lowest and highest note for the Voice is set by directly playing these notes on the keyboard from C1 to C6 (or using the Value < > keys). By pressing the 2 Value < > keys simultaneously OFF appears in both sectors. When the Voice is in the Off mode, this means that it plays over the entire

keyboard but once the keyboard split is enabled with the Arranger to the left, it will play only in the melody part. This is the most frequently used mode, but there is also the possibility of assigning a part of the program to the left and the other to the Song part. To achieve this second possibility, merely set a Range with a value of i.e. C1-C3 on the Voices to be assigned to the left. In this case, even if the keyboard split is enabled on C3, these Voices will remain active on the left-hand side or Arranger. This function proves particularly useful to enhance the background sounds of the Arranger in addition to the 2 Lower, or to transform the left-hand side of the Program in a true lower Manual Organ, if the instrument is to be configured as an Organ by connecting the MIDI pedal.

Velocity Switch: this parameter enables the control of the Program Voices functioning, according to the keyboard dynamics. Use keys F3 or F8 to select the Voice. Use the Value < > keys to select the Velocity operational Mode:

Normal: normal sound dynamics.

Low: in the low position the Voice plays with a dynamic amplitude that ranges from the minimum to the Threshold value.

Threshold consists of a Dynamic threshold above or below which the Voice will no longer play. I.e. in the Low position and with a Threshold value of 64, the Voice will play from the minimum to the Dynamic value of 64.

Use key F10 to select the function and the Value < > keys to search for the Threshold value.

High: in the High position the Voice will play only when the Threshold value is exceeded up to the maximum dynamic value. (127). The Velocity Switch function may be used to create Programs in which there is a strong voice differentiation between soft dynamics and maximum dynamics.

Cross: in the Cross position and only for the first two voices, you can obtain the gradual crossing from the first voice over to the second one depending on the dynamics applied to the keyboard. The Dynamics threshold where one sound crosses over to the next can be selected by means of the Threshold value.

Sustain - Portamento: this parameter enables the Sustain pedal effects function (optional) and Portamento on the individual Voices (if the Portamento key is pressed).

Use key F4 or F9 to select the Voice and the Value < > keys to confirm the Effect selected.


001 GRAND				Page 3/3			
VOICES ▶	Grand	Rock	Philarmo	Off			
RANGE ▶	Off	Off	Off	Off	Off	Off	Off
VELOC. SWITCH ▶	Cross	Cross	Vel.Low	Vel.Low			
SUST. ▶	Sustain	Sustain	Off	Off			
PORT. ▶	Portam.	Portam.	Off	Off			
EXPR. ▶	Expr.	Expr.	Expr.	Expr.			
DUET/TRIO ▶	Steel			THRESHOLD ▶	127		

Duet - Trio: access is gained to the 2 functions by pressing F5 a number of times. The effect is cut-out in the OFF position. In the Duet status, the Voice no. 1 of the Program will play exclusively only the highest note, Voice no. 2 the lowest note. **EXAMPLE :** in a Duet with a Clarinet at Voice 1 and Trumpet at Voice 2, when the two notes are played, the Clarinet will always play the highest note and the Trumpet the lowest note. The Trio works in the same way as the Duet, with the exception that the 3rd Voice added (Voice no. 3) plays the highest note of the three notes played. With a bit of practice and a correct musical phrasing the Duet and Trio effects enable the user to achieve extremely interesting results for all typical Folklore, March and Band music.

Steel: press F5 repeatedly to have access to it. The Steel function allows you to assign the pitch bend only to the lowest-pitch note of two notes played at the same time in the singing part, imitating in a very realistic way the typical effect of Hawaiian Guitar or Pedal Steel Guitar.

To save the program once the Editing phase is complete:

- 1** Press Save / Enter.
- 2** It is possible to assign a new location to the Program by selecting it directly from the 128 available.
- 3** A new name may also be given to the Program: the letters are entered using the keyboard from C2 to F5 and the syllable is split using the Cursor < > key.
- 4** If the previous name is left, simply save by pressing function key F10 (Save).
- 5** If a mistake is made, the program conditions previous to the last modifications made may be restored before saving by means of the Undo (F4) key.




To save a single Program in a folder of the Hard Disk or onto a Floppy Disk once the Edit phase has been completed:

- 1** Press Save/Enter
- 2** Press Save to Disk (F9) You can also give the Program a new name: you can write the letters using the keyboard from C2 to F5 and you can move syllables using the Cursor < >.
- 3** Press F10 to save

To load the Single Program from disk:

- 1** Press Disk
- 2** Select Hard or Floppy according to the location (if on Hard Disk or on floppy disk).
- 3** Press Exit
- 4** Press Edit Program
- 5** Select the number of the Single Program using the numeric keypad (Select)
- 6** To load the subsequent ones, resume the procedure from point 4



Note: if the Edit Program menu is exited without saving the new program beforehand, the new setting will be lost. For the Saving on Disk functions refer to the DISK chapter.

SOUND BANK / RAM CARD

The Sound system of the X series may be expanded and continuously updated by means of new SOUND BANKS that may be loaded on **RAM** or **Card**. The **RAM** consists of a standard **16 Mbyte** Simm inside the instrument whereas the **CARD** is an external **8 Mbyte** Flash Card which may be directly connected to the instrument by means of the appropriate slot situated at the front part of the keyboard.

SOUND BANK

The SOUND BANK is a block of sounds made up of 8 floppy disks, in the case of 8 Mbytes, or 16 floppy disks in the case of 16 Mbytes. Each floppy disk contains a single Sound file with a progressive number; i.e. the file stored in Disk no. 1 will be called Sound_1.Snd. The Sound Banks may be loaded in the internal SIMM or in the optional FLASH CARD; they may be loaded directly from Floppy Disk or from Hard Disk. **It is advisable to copy the files onto Hard Disk first then from there to load them individually in the Simm or Flash card.**

How to copy a Sound Bank onto Hard Disk

- 1 – Insert the Floppy containing the first file of the Sound Bank (the progressive numbers of the Floppy disks are printed on the outer label).
- 2 – Press the Disk key.
- 3 – Select the Folder in which the files are to be copied using the keyboard from 0 to 9.
- 4 – Read the Floppy Disk contents by pressing Page < >.
- 5 – Press key F4 (Copy).
- 6 – Press key F10 (Execute) to confirm the operation.

Follow this procedure for all the Floppy Disks that make up the Sound Bank. All the Sound Bank files are to be copied in the same Folder. The initial transfer of the Sound Bank files from Floppy to Hard Disk requires a certain amount of time. The following loading from Hard Disk to Simm will be much quicker (approximately 1 minute and 20 seconds for a 8-Mbytes Sound Bank).

How to load the Simm or the Flash card from Hard Disk

Loading from HARD DISK

- 1 – Press the Disk button.
- 2 – Set the Hard Disk using Page < >.
- 3 – Using the keyboard 0-9, select the Folder containing the Sound Bank files
- 4 – Select a file from the Sound Bank using Value +/-
- 5 – Unlock the Card Lock function (see Utility chapter)

If you now wish to load the SIMM:

- 6 – Extract the Flash Card if it has been inserted into the special Slot .
- 7 – Press F2 Load.
- 8 – Press F10 Execute to set the operation going.

All files concerning the selected Sound Bank will automatically be loaded onto the Simm. If you have forgotten to remove the Flash Card from the special Slot, the display will warn you as follows when you press F2 Load: "Warning! Loading will erase card data? F5: Exit F10: Execute." If you still intend to write the Simm, extract the Flash Card, then press F10. Press F5 to abandon the operation.

If on the other hand you wish to load the FLASH CARD:

- 9 – Insert the Flash Card into the special Slot.
- 10 – Press F2 Load.

The display will warn you as follows: "Warning! Loading will erase card data? F5: Exit F10: Execute." If you still intend to write the Flash Card, press F10. Press F5 to abandon the operation.

Loading from FLOPPY DISK

1 – Insert the first floppy disk of the Sound Bank and press the Disk button.

2 – Set the Floppy using Page < >. (if you are already in floppy, press F1 Dir)

To continue, resume the procedure from point 6 of this paragraph. The procedure to follow will require a little more time, seeing as the Sound Bank diskettes must be loaded one by one.



NOTES concerning the SIMM and the CARD

- The data loaded in the Simm are erased when the keyboard is turned off. Therefore each time the keyboard is turned on, the Sound Bank desired must be reloaded.
- The contents of the Simm (or of the Flash Card if inserted) are erased as soon as a new Sound Bank is loaded.
- The 16-Mbytes Sound Bank (16 floppy disks) may be loaded in the Simm alone.
- It is possible to save a countless number of Sound Banks on Hard Disk and to create an impressive Sounds and Grooves Library that may be used according to the specific requirements.
- It is possible to simultaneously run a Sound Bank loaded on Ram and a different Sound Bank stored on Card directly.
- The sounds stored in the Sound Bank Ram or Card may be entered within the Programs and stored in Registration.
- For Sound Banks containing the Grooves, a Floppy disk containing the Styles especially programmed for those Grooves will be supplied together with the 8 floppy disks. These Styles are then loaded individually in the internal memory as Patterns (See DISK: Load Pattern).
- The Flash Card takes longer to load than the Simm, but its advantage lies in the fact that it remains permanently stored and accessible without Loading operations even after the keyboard has been turned off.
- Merely completely and accurately insert the Card into its slot to connect it to the instrument. (The Card will not run if it is not inserted correctly).
- Disable the RAM key before removing the Card.
- The Card must not be removed while the Grooves and Sounds contained within are running.

Once the Sound Bank has been loaded from the Disk:

1) – **Press the RAM key to activate the Sound Bank of the RAM (Simm).**

2) – **Press both the RAM and BANK 2 keys to activate the Sound Bank of the CARD.**

HARD DISK Data (for X1 HD only)

The Hard Disk of model instrument HD comes with the following outfit of Sounds and Styles:

FOLDER 1:SOUND BANK 1 = Piano 1, Ensemble, Power Organ 1, Power Organ 2, Full Organ, 60Choir, Effects 1 (Car Start, Jet, Racing , Airport), Effects 2 (Roaster, Splash, River, Rain), Applause, Piano 2.

SOUND BANK 2 : Techno 1, Techno 2, Dream, Magic, Sweep Pad, Rotary Organ, B3 Organ, Pipe Organ, Tango Accordion, X1 Pad, Grooves 1 – 6 (18 Grooves).

SOUND BANK 3 : Default Autoloading Folk Sound Bank

SONG STYLES from MS 50 / MS 60 (56 Patterns)

FACTORY SET-UP (Programs, Registrations, Custom Styles Standard, Custom Styles Remix, User Drum Sets, User Voices).

FOLDER 2:INTERNAL STYLES from MS 100 (99 Patterns)

FOLDER 3: INTERNAL STYLES from MS 50 / MS 60 (99 Patterns)

FOLDER 4: STYLE MIX from MS LIBRARY (151 Patterns)

KEYBOARD CONTROLS

The X series has been designed to meet the most demanding requirements of a live performance and therefore has been implemented with a large number of keyboard controls that may be easily activated by the user while playing in order to better control the expressiveness of the music.

Key Velocity

The instrument is equipped with a keyboard of 61 semi-weighted keys with Dynamics and After Touch control. 6 Dynamic Curves are available: Soft 1, Soft 2, Normal, Hard 1, Hard 2, Fixed.

To change the dynamic response of the keyboard:

1 – Press key F 3 to gain access to the UTILITY Menu.

2 – The F10 key is pressed repeatedly to scroll the various types of dynamic Curves available.

The SOFT 2 curve is that set as the default parameter and the FIXED 127 curve corresponds to dynamic cut-out. If the dynamic curve is to be changed permanently, this may be done using the Power On Set Up function (see below). If on the other hand the activation of a different dynamic curve is required only temporary, the Registration function may be used.

Power On Set Up

The function is used to change some original keyboard settings so that when the instrument is switched on the new values set by the user are always available.

The parameters that may be saved in the Power On Set Up mode are:

Style Custom/Factory (led)	Portamento time	Chord Mode	
Style Bank A/B (led)	Equalizer	Dynamic Arranger	
Pattern (led)	Separate Out Assignment	Autocrash	
1 Touch (led)	Accordion Mode	Pedalboard	Font 1-2 text lyric
Global transposer	Lower 1 Hold	Bass to Lower	4 switch mode
Split point	Lower 2 Hold	Reverb Lock	
Reverb Level	Lower Lock	Sync time	
Harmony type	Bass Lock	Canali Gm Tx-Rx	
Dynamic Curve	Pianist Sustain	Sustain 2nd voice	
Global Tune	Swell to right	Arabic mode	

To save the new Set Up:

- 1** Press the Save / Enter key.
- 2** Press the F3 key - Power On set Up.
- 3** Press key F10 - Save to confirm the entry.
- 4** The Default function - F9 is used to restore the original Power On conditions set by the manufacturer.

SOUNDBANK AUTOLOADING

This function allows you to load a Sound Bank when the instrument is switched on.

- 1** Press Disk
- 2** Select the folder containing the SoundBank you wish to load
- 3** Select the first file of the Soundbank
- 4** Press the Save/Enter button. A new configuration file called INITXX.PWR will be saved onto disk, which contains all the information on the Sound bank.
- 5** Go back to the main display screen and Press the Save/Enter button
- 6** Press F3 Power On Setup

When the instrument is switched on, the file InitXX.Pwr will be opened and the selected Soundbank will automatically be loaded.

Press on the Exit button during the AutoLoading operation to cancel the latter and go back to the main display screen.

HARMONY

This function adds grace or complementary notes to the melody based on the chords achieved on the Arranger part.

To gain access to the Harmony functions:

- 1** Press the Harmony key.
- 2** Use the F 1 – F 9 keys to select the available effects.

The instrument is provided with the following types of harmonies:

CLOSE 1: the notes of the chord played on the left hand section are repeated on the right hand section and summed to song line.

CLOSE 2: like Close 2, but with a more complex and differentiated harmonization, depending on the key played.

DOUBLE UP: adds the higher octave to the song.

DOUBLE DOWN: adds the lower octave to the song.

5TH: adds the higher fifth octave to the song.

8 + 5th: adds the lower octave and fifth to the song.

TRILL: to achieve this effect at least 2 notes must be played on the Song part.

The 2 notes are automatically repeated one after the other.

The repeating velocity is controlled with the Speed function - F9.

REPEAT: repeating effect on the individual note played.

The Repeat Time is synchronized with the standard Time of the Styles and quantified according to the various types of Speed available.

SPEED: velocity control for the Trill and Repeat effects.

The Velocity values are: 4, 6, 8, 12, 16, 24, 32.

TRANSPOSER

The Transposer function enables the global transposing of the general tuning of the instrument.

To gain access to the transposer function simply press one of the 2 Cursor / Transposer < > keys.

" GLOBAL TRANSPOSER " will appear on the display

for approximately 2 seconds during which time the transposition of the instrument may be modified using the 2 Cursor / Transposer < > keys.

The max. transposition permissible is + / - 24 semitones.

The new transposition value remains on the main display next to "Transp".

To restore normal Tuning conditions (or rather

transposition 0) simply press the 2 Cursor / Transposer < > keys at the same time.

SPLIT

The Split function is used to establish which part of the keyboard is assigned to the Arranger and which to the melody part. The normal condition is C3.

To modify the Split:

- 1** Press and hold down the Split key.

- 2** Simultaneously play the key related to the Split point desired on the keyboard.
- 3** Release the Split key. The new value will remain effective until the keyboard is switched off.


ON LINE EFFECTS

This section of the instrument controls the immediate enabling on the Song part (Right) of the most important Effects available.

This an important prerogative when playing live music as it allows the player to immediately change the type of Effect while playing without entering into the main Effects menu.

To gain access to the On- Line Effects:

1 – Press the On- line Effects key.



F 1: Chorus: F 1 activates this effect.

F 2: Wha Wha: F 2 activates this effect.

To obtain the Wha Wha effect, the instrument must be connected to the Volume Pedal (optional). As long as the Wha Wha function is active, the volume Pedal no longer controls the general volume of the instrument but rather only that of the Wha Wha effect. You can obtain remarkable Effects with Wha Wha on all electric guitar Voices.

F 3: Delay: F 3 activates this effect.

F 4: Overdrive: the Overdrive effect consists of a gradual saturation of the sound associated with the Volume Pedal control.

It is the typical effect of old electromagnetic organs which made a characteristic distorted sound when the pedal was pushed all the way down.

Just like the Wha Wha effect, the Volume Pedal (optional) must be connected to the instrument for the Overdrive to work.

This effect is particularly suitable for all those Organ, Jazz and Rock Voices.

F 5: Distorsor: typical Distortion effect of the electric Guitar. It can also be applied to other sounds to obtain particular effects.

F 6: Exclusion / insertion of the Effect on the Microphone. (Effect / Dry)

F 7: Level of the Microphone's direct signal. Use the Value + / - buttons to modify the value.

F 8: Level of Reverberation on the Microphone. Use the Value + / -buttons to modify the value.

F 9: Vocal Set. Selection of the type of Vocalizer using Value .(See the KIT VOCALIZER Manual)

F 10 : Exclusion / insertion of Vocalizer . On / Off .

EFFECTS

The Effects Menu controls all the effects of the 2 DSP supplied with the X series.
To gain access to this menu press the function key F 2 - EFFECTS from the main display.

REVERBERATION

Reverb Level: this parameter controls the general Reverberation level of the instrument. Key F1 is used to select the parameter and the Value + / - keys are used to modify the value (from 1 to 16).

Reverb Type: choice of the type of Reverberation. Use key F 2 to select the function and the Value keys to search for the type of Reverberation amongst the 16 preset and the 4 User Reverb. available:

BOX 1, BOX 2, ROOM 1, ROOM 2, STUDIO 1, STUDIO 2, HALL 1, HALL 2, STAGE 1, STAGE 2, THEATRE, CATHEDRAL, ARENA, VALLEY, PLANET, GALAXY, USER REVERB 1 - 4.

Reverb Edit: this section allows the user to modify the Reverberation effects.

- 1 Press Edit to gain access to the function.
- 2 the Source parameter - F8 defines the type of effect to be modified. By repeatedly pressing key F 8 the various types available are scrolled.
- 3 the Destination parameter – F 9 establishes in which of the 4 User Reverb. locations available the new Reverberation will be saved after it has been edited. Press key F9 repeatedly to set the location.
- 4 Using the Cursor < > keys the various control parameters are selected and the Value + / - keys modify the value.

Effects		EQUALIZE
REV. LEVEL	Global 10	CHORUS1
REV. TYPE	3_A HOUSE_1	DELAY1
HALL_2	Factory	DISTORSOR1
SAMPLER	↓ = 126	Edit
MICRO	Tran.: --- Left: 48	
VOCALIZE	GRAND PIANO 63	
	Violas	

Reverb Edit		SOURCE
Level	32	HALL_1
Filter	32	DESTINAT.
Pre Del.	32	USER_REV1
Decay	32	SAVE
Delay	32	
Default		
Escape		

Level: amount of the effect.

Filter: softening of the high frequencies on the Reverberation.

Predelay: predelay timing, or rather the delay from the start of the sound to the first sound repeat or reflection.

Decay: decay length of the reverberation.

Delay: thinning out of the repeats between the various delays that make up the reverb.

- 5 simply press F 10 – SAVE to save the new Reverberation. The Reverberation thus edited will take the name of the corresponding User Reverberation.
- 6 Use the DEFAULT function (F 4) to restore the original Reverberation effects.

SAMPLER: section devoted to Sampling. (See Sampler paragraph)

MICROPHONE: Microphone control menu. To gain access to the functions concerning the Microphone:

- Enter into the EFFECT menu using key F 2.
- Press key F 4 – Micro.



Level 1 / Level 2: these 2 parameters (F1 and F 2) control the input level of the stereo Microphone separately for part 1 and part 2. It is indeed possible to connect 2 Microphones to the instrument by means of a special adaptor indicated in the illustration. The Input Micro Overload LED situated at the right-hand side of the panel next to Registration, points out that the Micro Input is saturated. In this case it may be useful to reduce the Microphone Gain using the potentiometer situated on the front panel. The volume of part 1 and part 2 is modified using the Value + / - keys.

Pan 1 / Pan 2: (F 3 - F 4) pan Pot control on the part 1 and 2 of the Microphone. The value is modified using the Value + / - keys.

Music Vol (F5): this function allows you to adjust the global volume of the keyboard without altering the volume of the microphone. The range is from 32 to 63.

Echo/Reverb 1 / 2: (F 6 - F 7) these 2 parameters separately control the amount of the Echo or Reverberation Effect on the 2 Micro Inputs.

By repeatedly pressing key F 6 or F 7 part 1 or part 2 is selected and the value of the effect is modified using the Value + / - keys.

Pitch Shift: Vocal shift effect by 1 octave on the Voice tuning (+ / - 12). The Pitch Shift functions exclusively on part 1 of the Microphone.

Dry: (F 9) this parameter cuts out the Echo or Reverberation Effects on the Microphone.

Quite useful for changing over from “singing” to “speaking” during the live performance.

Active / Inactive: (F 10). Microphone cut out function, particularly useful if the microphone is not provided with the On/Off switch.


VOCALIZER

You can access it from the Effects menu by pressing F5. The Vocalizer is a professional Harmonizer effect (optional) that can be applied to the instrument. It is capable of synthesizing 3 harmonising Voices on the basis of the note sung at the microphone input and it provides for many control functions such as Harmony type, Effects, Filter, Octave etc. The Vocalizer kit is supplied upon request and it should be installed inside the keyboard by specially qualified personnel in accordance with the instructions attached. All information regarding the operation of the VOCALIZER section is contained in a special Instructions Manual that is provided together with the Vocalizer Kit (optional).

EQUALIZER:

3-band Equalizer: Low, Mid, Hi . To gain access to the function:

- 1** Enter into the Effects menu using key F 2.
- 2** Press key F 6.
- 3** Use keys F1, F2, and F 3 to choose the band; use the Value + / - keys to select the values from 2 to 12 dB + / -.



The Equalizer globally affects the instrument and therefore affects both the external and internal amplification. The set Equalizer combination is stored until the instrument is switched off but may be saved in Registration and in the Power On Set Up function.

CHORUS: To gain access to the Chorus effects:

- 1** Enter into the Effects menu using the F2 key from the main display.
- 2** Press key F 7 . Use the Value + / - keys to select the 12 types of Chorus available:

CHORUS 1 - 5, FLANGER, SHORT DELAY, FEEDBACK, USER CHORUS 1 - 4.

The User Chorus are 4 locations in which up to 4 Chorus effects modified by the user may be saved.

To gain access to the Chorus Edit function press key F 10 – Edit.

- 3** The F 8 and F 9 parameters are used to select the Chorus to be modified (Source) and the User Chorus where the new effect is to be located (Destination) respectively.

Chorus Edit	
Level	120
Delay	64
Feedback	0
Rate	3
Depth	64
<div>Default</div> <div>Escape</div>	
<div>SOURCE</div> <div>CHORUS1</div> <div>DESTINAT.</div> <div>USER_CHOR1</div> <div>SAVE</div>	

- 4** Using Cursor < > the parameters are selected and using Value + / - the value is modified:

Level: global amount of the effect.

Delay: length of the delay.

Feedback: : feedback level on the delay.

Rate: Modulation Velocity.

Depth: modulation Intensity.

- 5** Simply press F10 - SAVE to save the new Chorus in the pre-selected User Chorus.

- 6** To exit from Edit press Escape – F 5.

The Default function – F 4 is used to restore the original Chorus effects.

DELAY: to gain access to the Delay effects:

- 1** Enter into the Effects menu using key F2 from the main display.

- 2** press key F 8 . Use the Value + / - keys to select the 12 types of Delay available:

DELAY 1 – 8 , USER DELAY 1 – 4 .

The Delay effects modified by the user may be saved in the 4 User locations.

To gain access to the Edit function of Delay press key F10:

- 3** Use keys F 8 and F 9 to set the Delay to be modified (Source) and the destination User location (Destination).

- 4** Using Cursor < > the various parameters are selected and using Value + / - the value is modified.

Delay Edit	
Vol. Center	0
Vol. Left	100
Vol. Right	100
Delay Center	23
Delay Left	0
Delay Right	23
Feedback	35
Filter	64
<div>Default</div> <div>Escape</div>	
<div>SOURCE</div> <div>DELAY1</div> <div>DESTINAT.</div> <div>USER_DEL.1</div> <div>SAVE</div>	

Considering that the Delay functions in stereophony the following parameters on the Left and Right may be controlled:

Volume Center: central level

Volume Left: left part level

Volume Right: right part level

Delay Center: amount of delay on the center

Delay Left: amount of delay on the left part

Delay Right: amount of delay on the right part

Feedback: feedback level on the delays.

Filter . softening control of the filter on the repeats.

- 5** Press F10 - SAVE to save the new Delay.

Using the Default function (F 4) the original Delays may be restored.

Press F5 - Escape to exit from the function.

DISTORSOR: to gain access to the Distorsor effects:

- 1 Enter into the Effects menu using key F2 from the main display.
- 2 Press F 9 – Distorsor. Use the Value + / - keys to select the various types of Distorsor available : Distorsor 1 - 8, User Distorsor 1 – 4.

4 new programmable Distorsor effects may be saved in the 4 User Distorsor locations.

To gain access the Edit function of the effect press the Edit key – F 10 :

- 3 Use key F 8 – Source to select the Distorsor effect to be modified and key F 9 – Destination to select the User location in which it is to be saved.

- 4 Using Cursor < > the parameters may be selected and using Value + / - the new value may be set.

Volume: general level of the effect.

Tone: filter control (Range 16 / 102)

Resonance: resonance control (Range 24 / 127).

With value 127 the resonance is set at zero.

- 5 To save the new Distorsor effect press F 10 – SAVE.

Using the Default function – F 4 the original Distorsor effects are restored.

Distorsor Edit	
Volume	40
Tone	90
Resonance	127
SOURCE	
DISTORSOR1	
DESTINAT.	
USER_DIST1	
SAVE	
Default	
Escape	

ROTOR: the Rotor effect is maybe the most classic effect of the electronic Organ and is achieved by rotating the loudspeaker of the special Organ amplifier.

Using the ROTOR ON key the effect is enabled; using the SLOW / FAST key the velocity change is controlled.

The Rotor effect has no affect on the following Organ Voices of the instrument: Leslies, Rock Organ, Church Organ, Rotor B3, Positive, 2nd Perc., 3rd Perc., Click.

Introduction

In the main display screen, press the F3 function button to have access to the Utility section, which is made up of 3 pages, each one of which can be selected by means of the special page > < buttons on the top right-hand side of the front panel of the instrument.

The first page is as follows: in the middle of the display panel, the current style is indicated, along with the tempo value, the transposer, the level of the left split of the keyboard, the main sound and the secondary one. This display is constant throughout all 3 pages. On the right- and left-hand side of the display panel, the various functions relating to the respective buttons appear, and these vary from page to page.

PAGE 1 UTILITY


OCTAVE (F1)

The Octave function enables the immediate transposition by one octave down or up (+/- 12 semitones) over the entire keyboard. To enable this function simply press the Octave key.

The octave selection is achieved in the following manner:

- 1** Press the F3 key – Utility.
- 2** The Octave change is associated with function key F1. Down corresponds to the lower Octave; Up to the higher Octave.

Using the Power On Set Up function it is possible to establish which of the two options, Down and Up is always enabled when the instrument is switched on (See the Power On Set Up paragraph). The Down or Up function of the Octave may also be saved in Registration.



AFTER TOUCH (F2)

On the contrary to the Velocity Key that controls the velocity with which the key is pressed, the After Touch controls the pressure applied to the key after it has reached the end-of-stroke. In other words, the After Touch starts to work when a key is pressed harder than usually done so to play.


To gain access to the After Touch controls:

- 1** Press the After Touch key.
- 2** Press key F 3 – Utility .
- 3** Enable the After Touch function using key F2.

Cut Off: control of the Filter associated with the After Touch. The parameter is enabled using the F1 key.

Lfo Dco, Dcf, Dca: 3 modulation controls associated with the After Touch and relative to the Oscillator (Dco), Filter (Dcf) and amplitude (Dca) respectively. The 3 parameters are selected using keys F 2, F 6 and F 7.

Bend: when Bend is pressed, the After Touch function shifts the tuning upwards or downwards, depending on whether the Bend value is positive or negative. This movement is performed in semitones, with a range of + / - 24 semitones. Use key F 3 to select the Bend parameter and the Value + / - keys to modify the value.



Slide: the Slide effect function (F 4) is enabled with the After Touch key pressed but in actual fact is associated with the Velocity Key of the keyboard. Simply play with strong dynamics to immediately evaluate the effect, which consists of the rapid adjustment of the tuning in the sound attack, quite similar to that commonly encountered in the attack of almost all wind instruments.

The Slide function may be used successfully to enhance the reality and incisiveness of music phrases of the song line in particular with all the Voices of Saxophone, Trombone, Clarinet, Guitar.

Slide Threshold (THR): this parameter (F 9) controls the Key Velocity threshold exceeding which the Slide effect starts to function. The value is modified using the Value + / - keys and has a range of 0 to 64. Lower the value, less key dynamics is required to activate the Slide. The default value is set at 25.

Attack: the Attack parameter (F 5) causes all the effects connected to the After Touch to start to function with a sort of slight and gradual delay.

This function is useful for accurately controlling the expressiveness of the song Voices, especially those that are not provided with natural sampled modulation.

Volume: Volume control associated with the After Touch. The parameter is enabled using key F8.

Sensitivity: this parameter (F 10) controls the sensitivity of the After Touch. The sensitivity modifies the global amount of the various effects associated with the After Touch, with a range of from 0 to 127. The value is selected using the Value + / - keys. At 0 the After Touch is no longer effective.

MODULATION (F3)

The Modulation menu controls all the functions associated with the Modulation wheel: Lfo, Cut Off, Wha Wha, Expression.

To gain access to this menu:

- 1** Press key F3 – Utility.
- 2** Press key F3 – Modulation

Lfo Pitch, Dcf, Dca: the On / Off selection of these 3 functions is achieved using keys F1 – F2 – F3. It enables to control respectively, by means of the Wheel, the Modulation of the LFO over the Oscillator, Filter or Amplitude.


To cut-out the LFO Pitch parameter one of the other 2 LFO's must be pressed first, or Cut-Off or Wha Wha; with the purpose of leaving one function assigned to the Wheel at all times.

Cut Off: this parameter (F 4) associates the complete opening and closing control of the filter with the Wheel Modulation. The enabling of the parameter is controlled with the F4 key.

Wha Wha: Wha Wha effect control by means of the Modulation Wheel. The parameter is enabled using the F6 key. The two Cut Off and Wha Wha effects are self-disabling.

To Swell: this function transfers all the aforesaid effects for the Modulation Wheel to the Volume Pedal (optional). Modulation. It is enabled using key F 7. This function is obviously enabled only if the Volume Pedal is connected to the keyboard.

Modulation Rate: Velocity control of the Modulation for the three LFO effects associated with the Modulation Wheel. The parameter is enabled using the F8 key and the value is controlled by means of the Value + / - keys.




PITCH (F4)

the Pitch menu controls the effects assigned to the Pitch Wheel and other functions related to the tuning such as Tune, Vibrato, Portamento and Legato.

To gain access to the Pitch menu :

- 1** Press the F3 key – Utility.



 Press the F4 key – Pitch.

Tune: The Tune controls the general tuning of the instrument with an amplitude of + / - 100 cents, or rather +/- 1 semitone. To modify the tuning press key F1 and adjust using the Value + / - keys. By pressing the two Value keys simultaneously the standard 440Hz tuning is restored.

Vibrato: this parameter is used to disable the Vibrato from the Voices where this is provided for.

Note : Some Voices of the instrument have been sampled with the natural Vibrato of the instrument; these voices are obviously not affected by the aforesaid function.

To disable the Vibrato simply press key F2.

Portamento: this parameter controls the velocity of the Portamento effect. The value is changed using the Value + / - keys.

Legato: with the Legato function in the ON position (F4) the Portamento is transformed into the Mono mode and is operational on one Voice alone. To achieve the Legato effect between two notes, one of the two notes must be held down.

The Legato function may be extremely useful when simulating the phrasing of some traditional soloist instruments such as the Violin, Trumpet, Trombone etc.

Bend Value: this parameter (F 6) controls the amplitude of the Pitch Bend expressed in semitones.

If the Pitch Wheel is moved upwards (Up) the tones are sharpened, whereas moving it downwards (DOWN), the tones are flattened. The standard value is 2 semitones +/- and the max. permissible range is + / - 24 semitones.

To set a different value use the Value + / - keys.

The following functions enable the association of some interesting controls to the Pitch Wheel concerning the LFO, the Filter and the Amplitude.

Bend LFO: controls the amount of LFO assigned to the Pitch wheel. The value is modified using the Value + / - keys.

Bend DCF: controls the Filter associated with the Pitch Wheel. The value is modified using the Value + / - keys. Moving it upwards, the Voice filter opens; moving it downwards the Filter closes. With value 127 the maximum filter amplitude is achieved; value 64 corresponds to the standard value.

Bend VCA: controls the sound amplitude associated with the Pitch Wheel. The value is changed using the Value < > keys. With value 127 the maximum amplitude is achieved, value 64 corresponds to the standard value.

FOOTSWITCH (F5)

Access to the functions assigned to the Pedal control (See Footswitch chapter).

ACCORDION (F6)

Access to the menu of the Accordion section (See ACCORDION chapter).

TEXT (F7)

Press F7 repeatedly to select the size of the character used by the text (Font 1 / Font 2), or to exclude the display of the text whilst playing.

MSP EDIT, F9 MSP NEW (F8)

These two functions concern the Multisamples and are described in the Sampler section of this manual.

Vel. Curve (F9)

Press F10 repeatedly to select among the 6 dynamic answer curves available: Normal. Hard1.


Hard2. Fixed. Soft1. Soft2. With the Fixed curve, you can use the value +/- buttons to establish the fixed value of Key Velocity that the instrument sends via Midi .

PAGE 2 UTILITY

On Page 2, the functions are:

ARABIC (F1)

Press F1 to access the ARABIC menu, in which you can modify the instrument's standard tuning adapting it to the type of tuning used in Arab countries. (See ARABIC chapter)




VIDEO (F2)

The Video function (F2) allows you to use the value +/- buttons to determine the settings for the optional video card (Instructions provided together with the Video card).

REGISTRATION MODE (F3)

In Registration Mode, you can select all types of parameters that can be assigned to the Registrations (Block or Single).

The first display screen appears in the centre and consists of the Global list of functions. This is the main display screen, which you always go back to after having scrolled through all the pages of the submenus available.



In general:

- 1) – Select the various functions using the CURSOR buttons.
- 2) – Use F 10 – SELECT to select the On / Off condition.
- 3) – Use F7 – SAVE to confirm the configuration that can be stored in Registration.

Utility Page 2/2: Press F 3 repeatedly to scroll down 2 display screens that list many keyboard functions and various commands. In the ON position, their storing in Registration is activated. To exclude this, just select the function using the Cursor, set on Off using Select and then press Save to confirm.

By default, the Midi, Footswitch and Accordion functions are on the Off position, seeing as you may find it useful that such parameters always stay configured in the same way regardless of the Registration inserted.

Arrange Page 3/3: Press F 1 repeatedly to have access to three display screens that list which functions of the Arranger can be stored in Registration or not.

Drum Mixer: this function allows you to activate or not on registration the storing of all the parameters regarding the Drum Mixer, i.e. the On/Off exclusion, the volumes, the effects etc. of the percussion groups.

Effects: List of all the Effects that can be stored in Registration.

Tabs Page 2/2: List of the buttons whose on / off condition can be saved on Registration.

Default: the Default function (F 8) restores the original Registration Mode configuration of the manufacturer.

Switch off: this useful function (F 9) automatically switches off the luminous led of the small Registration button after a few moments.

This helps to prevent a new Registration from being unintentionally selected instead of a new Style while the rhythm is in operation.

In fact, the two Style and Registration sections use the same numeric keypad 0 – 9 for the selection.

DISP.TIME (F4)

mediante questa funzione è possibile impostare con i tasti value+- il tempo di permanenza delle schermate nel display.

PIANIST (F5)

Questo tasto, premuto ripetutamente consente di selezionare il modo Automatic o il modo Normal per la funzione Pianist. Per ulteriori dettagli sulla funzione Pianist rimandiamo alla sezione Pianist all'interno del capitolo riguardante gli Styles e l'Arranger.

KEYBOARD OUT ASS (F6)

Questo tasto premette l'accesso alla pagina che gestisce l'invio delle note suonate sulla tastiera alle 4 uscite audio dello strumento. Per i dettagli consultare il capitolo Out Assign.

GM OUT ASS. (F7)

Mediante questo tasto si accede alla pagina che assegna le uscite separate alle 16 parti GM. Per i dettagli consultare il capitolo Out Assign.

BLOCK REGISTRATION (F8)

Con questo tasto si seleziona il tipo di registration corrente (Block o Single).

4SW. MODE (F9)

this special function is to be used when the instrument is connected to Midi SOLTON Pedalboard and to the special pedal for guitarists with 4 switches to change key.

When the parameter is on the ON position, each new change in key remains stored in the memory even if you do not continue to press the corresponding switch.

On the other hand, on the OFF position, the variation in key only remains effective for as long as the switch is pressed, after which it goes back to the Major key.

SONG EXPRESSION (F10)

this function allows you to control the global level of the Song during playing with the use of the expression Pedal.

PAGE 3 UTILITY

In page 3, the functions are:

2ND VOICE SUSTAIN ON/OFF (F1)

Activates or deactivates the pedal-control of the Sustain on the 2nd Voice.


2ND VOICE SPLIT ON/OFF. (F2)

This function allows you to determine a point of split only for the 2nd Voice. The point of split is fixed by pressing F 2 and playing a key on the keyboard.

ARAB.MODE. (F3)

Makes it possible to select the Styles with the use of just one figure that indicates the units. To select the number of tens, press both the Count In button and the desired number at the same time.

When Arab. Mode is activated, the normal function of COUNT IN is deactivated.



MICRO DRY ON STOP/ NORMAL. (F4)

Select Dry On Stop to remove the effect on the microphone each time the arranger is stopped using the Stop button. Normal: this is the standard condition.

LOWER HOLD ON/OFF. (F5)

Activates or deactivates the operation of the storage on the 2 Lower on the Stop position.

F6: PASSWORD. (F6)

Allows you to assign a personal Password to all the Folders on the Hard Disk. This function is useful for those Folders which have previously been locked using the LOCK function. (See DISK functions). In fact, with the Password, these folders benefit from a further protection from erasure procedures, writing and copying on the part of third parties, seeing as you first need to enter your Password to be able to deactivate the Lock device.

The Password can be assigned to the Folder of the Hard Disk which is active upon operation in the following way:

- 1) – Press F 1- Modify. If a Password does not already exist in the Folder, just write the new name on the NEW line. The name must be composed of a maximum of 6 letters. To confirm, press F 10 – Confirm.
- 2) – If an old Password already exists and you intend to modify it, first write the old name on the HOLD line, then write the new one on the NEW line and confirm it.

CARD LOCK . (F7)

Function of protection from the accidental writing on the Flash Card.

VOCALIZER CHANNEL LOCKED / UNLOCKED. (F8)

You can lock the Vocalizer mode on a specific Midi Channel. This function can be extremely useful if you possess many Midifiles which have the Vocalizer track on a specific Midi Channel (e.g. 05). In this case, in fact, if this function did not exist, you would have to set the Vocalizer onto this Midi Channel for every new Song. You can select the Vocalizer mode within the General Midi (GM) using the PART MODE – F8 function (Voice, Drum Set, Groove, VOCALIZER).

To access the Lock – Unlock function for the Midi Channel of the Vocalizer, use the F8 button in the Utility – Pag 3 menu.

SONG PLAY NORMAL/FAST: (F9)

Selection of the access time to the Midifile on Hard Disk. On the NORMAL position, the access time is the instrument's normal access time; on the other hand, on the FAST position, the Midifile starts immediately from the first notes in the sequence, ignoring the first 1 or 2 initial beats and thus allowing you to go from one Song to the next much faster.

F10: DELAY LOCK: (F10)

Allows you to lock the type of Delay active at that moment.

STYLES

The Style section controls the whole Automatic Arrangement of the X series and consists of the following main sections:

FACTORY STYLES: 198 original Styles sub-divided into 2 banks (A / B).

CUSTOM STYLES: Exact copy of the Factory Styles, but with the possibility of Editing and saving on behalf of the user.

PATTERNS: Styles freely programmable.

The Factory Styles section includes 198 Styles split up into 2 banks of 99 Styles each (A and B).

The list of Styles may be seen at the top part of the keyboard. In Bank A, mainly modern Styles are grouped; in Bank B, mostly dancing, Latin, and Folklore type Styles are grouped. The complete list of Styles is provided at the end of the handbook.

To select a Style:

1 Select the Bank using the Bank A/B key. If the LED is lit, Bank B is in use.

2 Write the number of the Style using the numeric keyboard from 0 – 9.

The name of the Style selected appears at the top left hand corner of the Display.

Style Structure

Each Style is made up of 8 Automatic Instrument sections plus 2 manual sections (Lower).

Drums

Groove

Bass

Chord 1 (Chords)

Chord 2 “

Chord 3 “

Chord 4 (Orchestral)

Chord 5 “

Lower 1 (Manual Tuning)

Lower 2 “

The various parts that make up the Arrangement are:


4 Arranger : A, B, C and D

3 Fill Ins

1 Break

3 Intros

3 Endings



Volume controls

At the bottom part of the main display, the controls of the Arranger Volume are clearly seen together with the volume control of the Right part. The Volume on the individual parts is controlled by means of the pair of keys situated at the right hand side of the panel. The Chords section globally controls the first three chords (1, 2 and 3), whereas the Orchestral section controls the volume of Chords 4 and 5. (Individual controls are possible within the Arrange View menu). Press the two Volume keys at the same time to reset the Volume. The Master slider potentiometer adjusts the general volume over the entire instrument

Left Level: globally controls the Volume of the whole automatic section. The value is indicated on the Display next to “Left Level” and can be modified using the < > Value / Balance keys.

The Left Level value may be saved for each Style in the Custom Style section.

Tempo: The Tempo is controlled by means of the 2 Slow and Fast keys with a range that varies between 40 and 250 beats per minute. By pressing the two Slow / Fast keys the tempo is locked on the value in use at that instant: the condition is pointed out on the Display by an asterisk to the left of the Tempo value. To release the tempo press the 2 keys at the same time once again.

Start: Style start and stop command.

Hold: Memory function for the Arranger.

Count In / Restart / Pause: this key controls 3 different functions:

Count In: consists of an empty measure executed with the Stick before the Start begins. It is enabled by setting the key in the Stop position. If the Jump key is enabled, the Count In may be activated and immediately following press Intro so that Count In and Intro are achieved one after the other.

Restart: if the Restart key is pressed while the Style is in use, the Style will restart from the initial step despite the point in which it is currently situated.

Pause: Pause function when listening to the Song. It functions only when the Song Play key is pressed.

Key Start: With Style in the Stop position and with the Key Start on, the Arranger starts to play as soon as a chord is played on the keyboard. If the Hold key is pressed, the Arranger continues to play even after the keys are released.

Key Stop: with the Key Stop on, the Arranger starts to play as soon as a chord is set on the keyboard just like the Start Key; if however the chord is held down for at least half a second approximately, after this amount of time the keys may be released and the chord remains stored in the memory all the same (if the Hold key is pressed). It is possible to accurately control the stand-by time required for this synchronization function of the Stop Key by means of the Sync Time parameter, in the following manner:

1 Press the F 4 key – Arrange Mode from the main display

2 Press the Page > key.

3 The F3 parameter enables the Sync Time function. Use the Value + / - keys to modify the value expressed in thousands of a second. Higher the value, longer the chord must be held down before it may be released. In cases of music requiring rapid gaps (i.e. Tango) lower values may be recommended (i.e. 200 or 300 ms); for slow songs (i.e. 16 Beat) it is probably more advisable to select higher values such as 500 or 600 thousands of a second. By pressing the + / - keys at the same time the standard value of 400 ms is restored.

Key Start + Key Stop: : With both the Start Key and Stop Key on and the Style in the Stop position, the Arranger starts as soon as the keyboard is touched and stops as soon as the keys are released.

Fill Ins 1, 2, 3: are variations of the Style of a timing of 1 measure being brief harmony rhythm elements. When pressed in the Stop status the Fill Ins may be used as Intros.

Break: the Break is a musical partial or complete stop beat for the entire arrangement.

Jump: the Jump function is used to achieve some special effect combined with the Fill Ins and with the Intro / Ending:

Jump + Fill Ins: With Jump pressed and the Style in use, each time the Fill Ins 1 and 2 are pressed, the Arranger shifts cyclically from A towards D. If the Fill 3 is pressed the Arranger shifts in the opposite direction from D towards A. When the Break function is enabled, the Arranger is not affected.

Jump + Intro/Ending: with Jump enabled in the Stop position, if the Intro is started the corresponding Ending is performed.

With the Jump enabled in the Start position, if the Ending is started, the corresponding Intro is performed after which the Style continues.

Jump + Count In: with Jump enabled in the Stop position, if Count In is pressed first and then

Intro these will be performed one after the other.

Intro / Ending: the Arranger foresees 3 Intro's and 3 Ending's. The Intro 1 / Ending 1 are mostly programmed without changing the tuning therefore the user may resolve the harmony as desired. Intro / Ending 2 and 3 are on the other hand programmed with harmony variations within and therefore it is inadvisable to change the tuning while they are playing. After the Intro the Arranger is pre-arranged always on Arrange A, unless a different Arrange is selected during the Intro.

Fade Out: the Fade out enables the "fading out" effect, or rather the gradual decrease in the general instrument Volume down to zero.

Lock: The Lock function is used to block the arrangement of the Drum, Bass and Chords section in a differentiated manner so that when switching over to one Arrange to the other the pattern of that section remains unaltered. This function allows the user to arrange the Style as preferred creating original combinations amongst the various Arrangers. To activate the Lock function simply select Arranger first and then press the DRUM, BASS or CHORDS keys depending on the section to be locked.

When changing the various Arrange you will notice that the section with the Lock enabled will not be affected.


PIANIST: The Pianist function automatically modifies the keyboard split and transforms it into one single piano type keyboard. In this condition the Automatic Arrangement can be controlled playing the keyboard with two hands. There are **two Pianist operating modes** available: **Auto and Standard**. To select them, press F3 – Utility, Page > and then F5 Auto – Standard.


Auto: This mode is selected by default. In the Auto mode, it is sufficient to play a chord of at least 3 notes on any keyboard area. As soon as this chord has been recognised, it is possible to play the lead with one or two notes on the piano, whereas the automatic accompaniment continues playing the last chord pressed.

Standard: The Standard mode is selected by means of the Sustain Pedal. If the Sustain Pedal is pressed immediately after having played a chord on the keyboard, the Arrangement will remain stored with this specific chord as long as the Sustain pedal remains pressed.

Pianist Sustain: This function is used to activate or deactivate the Sustain effect on the pedal while the Pianist mode is inserted. To select this function, press F4-Arrange Mode, Page > and then F7.

Manual Bass: this function allows the user to play the Bass manually. Each time the manual Bass is enabled the 2 Lower Chords and the entire Arrangement are cut out.





To Lowest: this function causes the Automatic Bass to perform its harmony loop starting always from the lowest note between those that make up the chord and not from the fundamental note of the chord acknowledged.

To Root: the Bass to Root function returns all the automatic Bass notes to the fundamental note of the chord, despite notes or harmony loops programmed in the Arrange.

ARRANGE TO.

Differentiated activation of the Program Changes on the Arranger section when the keyboard is working with the Simm loaded and the Card inserted. To have access to this function, press F9 – Drum Set.


F8 corresponds with the ARRANGE TO option, which allows you to assign one of the following 3 Program Changes onto the Arranger:

INTERNAL (Internal Sounds)

RAM (Simm Sounds)

CARD (Card Sounds)

To select, press the F8 button repeatedly. In Simm position, the Arranger can accept the sounds contained within the Simm as Program Change, and in Card position, it can accept those contained within the Card.



ARRANGER

Each Style is made up of 4 Arrangements , A, B, C e D . A corresponds to the beginning of the song, B and C are the intermediary variations and D is the Style in its complete form.

ARRANGE MODE: the Arrange Mode menu controls many functions related to the functioning of the Arranger. It is laid out on two pages.

To gain access to page 1 from the main menu, simply press F4 – Arrange Mode.

Lower 1- 2 Hold: Use the F 1 and F 2 keys to enable or disable the Memory in the 2 manual Lower Chords.

The default memory setting is enabled on Lower 1.

Lower 1- 2 Octave: the F 3 and F 4 keys are used to select the function and the Value + / - are used to select the octave (from 1 to 3) for the 2 Lower Chords.

Bass+Lower: when the function is enabled (F 5), each time the Style is situated in the Stop status, the 2 Lower Chords play in the Arranger part together with the Manual Bass, allowing the harmony to be played manually.

Bass Sustain: Sustain control on the Manual Bass. Key F 6 is used to enable the parameter and the Value + / - keys are used to modify the value. When the Bass + Lower function is enabled the Sustain is automatically shifted to value 20.

Bass Octave: Octave control of the Manual Bass. Key F 7 is used to enable the function and the Value + / - keys are used to modify the octave (+/- 3).

Right Swell: this function (F 8) allows the control with the Volume Pedal of the volume part alone (Right). The Arranger section will play at a constant level, the same as that in use when the Right Swell function is enabled.

Pedalboard: if the Midi Pedal board Mod. SOLTON K 8 is connected this parameter allows the user to enable the functioning of the Arranger section on the Pedal board.

To enable the Pedalboard mode, press F4 - Arrange Mode and then the F9 key.

For a correct functioning, it is required to set the RX Midi Channel (reception) of the left section (globally controlling the automatic Chords) to the same transmission channel as the Midi pedal board (if a SOLTON pedal board is used, the default transmission channel is channel Midi 02).

Pressing the MANUAL key, the pedal board Bass will be set to the manual mode, like on an organ.



Obviously the pedal board usually plays only pre-arranged major chords.

The tonality can be modified according to two different methods: either with the pedal switches (see Footswitches FS 13 and FS 6) or with a special 4 switches pedal for guitar players (Mod. 9AC101).

A special function, the so-called 4-Switch-Mode, is foreseen for using the pedal Mod. 9AC101. This function makes sure that the chords will not remain stored after each change of tonality, but automatically return to major.

In order to gain access to the 4-Switch-Mode press F3- Utility, then press Page > to go to page 2 Utility and then press F9.

Bass to Pedal: this function exempts the Automatic Bass from the keyboard to assign it to the Pedal board alone. It is a useful function if (in the pedal board mode) the automatic chords are required from the keyboard and the automatic Bass from the Pedal board.



Press F4 – Arrange Mode and then F10 to select this function.

Press Page > to proceed to **Page 2** of the Arrange Mode menu:

Set Tempo: this function allows you to carry out a metronomic tempo advancing in pre-established steps. To have access to this function, press F 1 and to choose the furtherance value, use the Value buttons. Every time you press the Page <> buttons, you speed up or slow down the Tempo according to the pre-established furtherance value (by default: 5).

AutoCrash: this parameter (F 2) cuts out the automatic Crash Cymbal usually played at the end of the Fill Ins and Intros of the Styles.

Sync Time: stand-by time control in the Stop Key function before the keys may be released.

(See Start Key / Stop Key functions). The value is changed using the Value + / - keys.

Lower Lock / Bass Lock: these 2 functions (F 4 – F 5) are used to block the voice of the 2 Lower sections and Bass, so that these remain unaltered when switching over from one Style to another.

Chord Mode: with these functions (F 6) you can activate the selection of the 3 different modes of operation for the automatic chord recognition: Fingered, Easy 1, Easy 2.

When the Fingered mode is inserted (F 6), the chords will execute an accompaniment based on the notes that have effectively been played. Therefore, for example, if you press just two keys, instead of the complete chord you will obtain an accompaniment made up of just two notes. In Easy 1 mode, the chord recognition is instantly adapted based on the notes played or released on the keyboard. In Easy 2 mode, the chord recognition is based exclusively on the notes added. If you remove some notes from the chord previously set (without playing a new one), the Arranger does not undergo any variations.

Pianist Sustain: this parameter is used to enable or otherwise the Sustain control when the Pianist effect is enabled. (See Pianist function).

Retrigger & Mode: this menu contains the group of Retrigger functions and the selection of the Close/Parallel mode for the Bass and the Chords. Press key F8 to gain access to this menu.

Retrigger. The Retrigger on Bass and Chord is enabled using keys F 2, F3, F4, F6, F7, F8.

The Retrigger function consists of the fact that each time a chord is changed the Bass plays the fundamental note of the chord at all times.

Close/Parallel: this function is used to establish whether the Automatic Chord must play in Close or Parallel mode. Using Cursor < > the chord is selected and using SELECT the option may be selected. In Close mode the Chord adapts to the tone changes with close inversions according to the rules of the musical harmony. In Parallel mode the chord is simply transposed from C to B without altering the musical intervals of the notes of which it is made up. Press Escape to return to Page 2 of Arrange mode.

Dynamic Arranger: controls the dynamics assigned to the individual Arranger sections.

To gain access to the function press key F 9 – Dyn. Arr (on page 2 of the Arrange Mode menu).

Active - Inactive : F10 is pressed in order to activate or deactivate the Dynamic Arranger. This function is on when Active is selected. The Dynamic Arranger value is usually set to 32 for each section, corresponding to 50% of the maximum value available (63). Lower values will produce a feeble variation of the Arranger parts between low and high dynamics, whereas higher values will produce a much more evident variation. The value is modified pressing the Value +/- keys.

Reverb Lock: : this function (F 10) is used to lock the type of Reverberation relating to the Style currently selected, so that it remains active even if new Styles are selected. In this way, the reverberation remains locked, even upon the execution of a Midifile containing a different reverberation.

Retrigger & Mode	
Chord1	Parallel
Chord2	Parallel
Chord3	Parallel
Chord4	Parallel
Chord5	Parallel

CUSTOM STYLE / ARRANGE VIEW

The Arrange View menu of the X series is sub-divided into 4 pages (Volume, Reverb, Effects, Pan). It allows an accurate control of all the instrumental parts of the Arranger, allowing the modification of the Sounds, Volumes and the Effects of each Style before it is saved in the **Custom Style** section. To gain access to the menu from the main display simply press F 5 – Arrange View. Use the Page < > keys to select the 4 pages. **SOUND MODIFICATION:** the change of the voices that characterise the Style may be carried out from any one of the 4 View pages. The sounds may be modified on each of the 4 Arrange's A, B, C, D and on each of the 3 Intros and Endings available.

To modify the sound, simply select the part using the relative function key. The part becomes black for 2 seconds

approximately, during which time the new voice may be searched for in the Voice Bank section. The modification of the sounds on the Arrangers may be carried out also in the Stop position whereas for Intro and Ending the Style must be in use to do so. The new voices selected remain saved in the memory only until a new Style is selected. To permanently save them the Style must be saved as a Customer Style. (see below).

Volume (Page1): controls the Volume of the Arranger parts. Use the F 1 – F 10 function keys to select the parts and the Value + / - keys to modify the value.

Reverb: (Page 2) controls the amount of Reverberation for the various parts.

Effects: (Page 3) controls the type and amount of the effect on the Style parts. To enable the effect, select the part first (which will become black) and then repeatedly press the same function key to select Chorus, Delay or Distorsor. Then use the Value + / - keys to modify the amount of the effect.

Pan: (Page 4) controls the panoramic assignment of the Pan / Pot on the Style parts. Select the part (which becomes black) and use Value + / - to search for the Pan Pot value desired. The available values range from 0 to 64 for Right and Left . Press both Value keys at the same time to achieve a position marked by two dashes - - , which corresponds to the central Pan Pot position.

How to save a CUSTOM STYLE : After having modified the Style using the aforelisted Arrange View functions, the new condition may be saved in the following manner:

- 1** Press Enter / Save.
- 2** Press key F 2 – Styles.
- 3** Press the Save key to confirm. Before saving, the Style name may be changed by writing the letters using the keys from C2 to F 5 and moving the sector using Cursor < >.


Important: In the Custom Style, together with the parameters relating to Sounds, Volumes, Effects and Pan Pot included in the Arrange View menu, the following functions are also automatically saved (See Arrange Mode) :

- Tempo
- Arranger Volume (Left Level)
- Octave of the 2 Lower Chords
- Retrigger on Bass and Chords
- Close / Parallel mode for the Chords
- Drum Mixer

Volume Reset: Within the Arrange View Menu, you can put an individual section of the Arranger in Mute condition with the volume at zero by pressing the two Value buttons at the same time.

In this condition, the section always remains with the volume at zero, even if a new Style is selected.

If on the other hand the volume is reset just by using the Value button, this modification is only valid for the Style in question and therefore if you select a new Style, the normal volume value will be restored.



DRUM MIXER

This section may be truly defined as a digital mixer specialized for the rhythm section of the X series. All the percussion sounds of the instrument have been grouped in 10 sections, for each of which it is possible to control: On/Off, Volume, Reverb. and Pan Pot.

1 - KICK :	Bass Drum, Grancassa, Surdo.
2 - SNARE:	Snare Drum, Rim Shot, Brush, Roll.
3 - HI HAT:	Hi Hat
4 - CYMBAL:	Ride Cymbal, Brush Cymbal, Crash, Crashrol, Crashrev, Symphonic.
5 - TOM / FX:	Toms, Timbales, Clap, Scratch, Effects, Vocals.
6 - TAMB:	Tambourine
7 - LATIN 1:	Congas, Bongos, Tambora, Cajon.
8 - LATIN 2:	Cowbell, Sticks, Agogo, Cuica, Whistle, Guiro, Vibraslap, Castagnet, Fingersnap, Claves, Woodblock, Metronome.
9 - LATIN 3:	Maracas, Shaker, Triangle, Guira, Fx, Scratch.

The Drum Mixer menu is sub-divided into 4 pages. The pages are selected using the **PAGE < >** keys. To gain access to the menu from the main display simply press the **Drum Mixer – F 10 key**.


Drum On / Off: (Page 1) this function is used to rapidly cut out or enable the 10 percussion sections of the instrument. The function is extremely useful when personally intervening on the rhythm while playing.

Drum Volume: (Page 2) controls the volumes of the individual percussion sections. Once the part has been selected the Volume value is modified using the Value + / - keys from 0 to 15 .

Drum Reverb: (Page 3) controls the reverberation.

Use keys F 1 – F 10 to select the part and the Value + / - keys to select the value from 0 to 15.

Drum Pan-Pot: (Page 4) controls the stereo panorama from 64 Left to 64 Right . The value is modified using the Value + / - keys, which if pressed together at the same time set the Pan Pot at the central value. (the central value is identified by two dashes - - .)



GROOVES

Section 10 of the Drum Mixer menu controls the Grooves. The Grooves are sampled rhythms taken from original or recorded performances or even typical modern Dance / Tecno Loops.

They may play alone or in combination with the internal Drum Set without ever falling out of step with the standard Tempo.

The instrument contains a large number of Grooves within its internal sound memory, which are used in many of the Factory and Custom Styles stored and can also control a countless number of Grooves using RAM and CARD (See RAM – CARD chapter).

In the Handbook appendage the Styles that employ the Grooves in the Arrangement are indicated and the complete List of Grooves with the indications concerning the Sound Bank, Program Changes etc. is also available.

DRUM SET: The instrument is provided with 16 Drum Sets and 8 User Drum Sets:

001 - STANDARD	029 - RAVE	066 - LATIN
009 - FOLK	030 - HIP HOP	073 - ROCK & ROLL 1 2
010 - ACOUSTIC	033 - FUSION	121 - BEAT
017 - HARD ROCK	041 - BRUSH	122 - ELECTRO
025 - DANCE	049 - ORCHESTRA	123 - COUNTRY
026 - TECHNO	057 - CONTEMPORARY	124 - R&B
028 - PROGRESSIVE	065 - LATIN	125/ 128 - USER DRUM SETS

Press key F 9 – Drum Set to gain access the Drum Set menu from the main display:

Manual On/Off: Use key F 1 to enable the Manual Drums function, namely the manual functioning of the percussion instruments on the keyboard.

Key Shift: this parameter is used to shift the position of the percussion sounds on the keyboard with a range of + / - 24 semitones. Key F 6 is used to enable the parameter and the Value < > keys to control the Shift.

Drums to: this function is used to select the association of the Drum Set and of the Groove with the internal sound generation (**Internal**) with the Ram Simm (**Ram**) or with the Flash Card (**Card**). The 3 modes are enabled by pressing key F8. The Ram mode is enabled only if the Simm is loaded with a Sound Bank; the selection of the Card mode will be enabled only if the Card is inserted in its slot. It is crucial to check this status when Drum Sets or Grooves sent from the Simm or the Card are used. I.e. if a Card containing Grooves is inserted, the Drums function must be set in the CARD position for the Grooves to run correctly.

Drum Set Edit: this function is used to program new Drum Sets starting from the 16 pre-existing ones.

Press F 9 – Edit to gain access to the Edit function.

At the center of the Display the name of the Drum Set in use at the time may be seen and beneath, the number of the User Drum Set in which the new Set edited is to be saved.

Press Escape to change the current Drum set and then select the new number using the Value < > keys.

Manual: F 1 controls the enabling of the Manual Drum on the keyboard.

Key: this parameter is used to point out the key currently concerned with Edit. To choose a new key, simply play the key desired on the keyboard or scroll using the Value + / - keys.

Group: Use key F 3 – Group to select the function and the Value + / - keys to select the percussion section concerned (Kick, Snare etc.).

Instrument: F 4 enables the choice of a certain percussion instrument within the same section.

Each section includes many instruments of the same kind. I.e. the Kick section includes 32 different kinds of Drums (Kick 1 – 32), The snare section includes 46 Snares etc.

The instrument selection is achieved using the Value + / - keys. To evaluate the sound, it may be useful to play the key concerned and scroll the various percussion instruments available at the same time using the Value keys.



Key Shift: (F 6) transposition of the keyboard in semitones. It is used to shift the entire Drum Set by an octave or even a few semitones to adapt to Midi sequences that are not programmed according to the GM standard.

Pitch: Tuning of the individual percussion instrument. The parameter is enabled using key F 7 and the Value < > keys are used to control, by semitones, the tuning of the sound currently enabled on the Display. The range is + / - 24 semitones.

Drum On/Off: this function is used to return from the Drum Edit display directly to that of Drum On/ Off.

To save the Drum Set edited, simply press key F 9 – SAVE.

A new name may be given to the Drum Set by writing the letters using keys from C 2 to F 5 and shifting the sectors using Cursor < > .



PATTERN

The Pattern section of the X series allows the user to perform the following:

- 1** Load new styles, over 198 standard stored in the ROM of the instrument.
- 2** Program complete new Styles.
- 3** Compose Styles by simply copying parts of the internal Styles or Patterns already stored.
This function enables the composition of new Styles without having to play them to program them.
- 4** Completely edit the 198 internal Styles.

All programming and modifications performed on the Styles within the Pattern section are stored in the memory (provided that they are saved correctly) even after the instrument is switched off.

The **Pattern** key (situated at the side of keys A/B and Factory/Custom) activates the Styles/Pattern section. The Patterns may be personally created Styles or Styles of the SOLTON Library for instrument. The Library Styles must be loaded in the Pattern memory via Floppy Disk (See DISK: Load Pattern).

The Pattern list

The instrument allows for the list of patterns present in the internal storage to be displayed. To do this, just press the EDIT PATTERN button when the style is in operation.

198 memory locations are provided for the Patterns, 99 on Bank A and 99 on Bank B.

The Bank is selected, as for the standard styles, using the Bank A/B key.

Bank A = LED off

Bank B = LED lit

To call-up the pattern:

- 1** Press the Pattern key.
- 2** Select Bank A or B.
- 3** Compose the pattern number using the keyboard keys from 0 - 9.

It is advisable to set the Split function on C3 before gaining access to the EDIT PATTERN menu.

EDIT PATTERN

The Edit Pattern key allows the user to gain direct access to the Edit function concerning the Pattern.

To program a pattern:

- 1** Press the Edit Pattern key.
- 2** Select the Pattern number to be programmed using the keyboard keys from 0 - 9.

The Display shows various Edit parameters in correspondence with the function keys

PARAMETER

Press key F2 to gain access to this menu.

Before programming a pattern it is advisable to set most of the parameters shown in this display.

Tempo: The Tempo is always 120 in the empty Pattern.

This value may be modified using the two Tempo Slow – Fast keys (or using the Value +/- keys).

Time signature: : Musical division of the bars.

The Time signature value is 4/4 in the empty Pattern.

Edit Pattern	
RECORD	DELETE
PARAMETER	DISK SAVE
PART CLEAR	01A POLKA
COPY	MIDI RECORD
LIST	FORMAT
Memory Free: 5 %	

Parameter	
TEMPO	120
TIME SIGN.	4 / 4
AUTOCRASH	✓
CRASH LEV.	96
Escape	Save
Memory Free: 37 %	
LOW1 OCT.	+1
LOW2 OCT.	+1
BAS OCTAV	C1
BAS TYPE	4Strings
MODE	Close
RETRIG.	No
CHORD1	Close
CHORD2	Close
CHORD3	Close
CHORD4	Close
CHORD5	Parallel

To modify the value:

- 1** Press key F2 once only. In this way, the first half of the box relating to the Time Signature becomes black.
- 2** Modify the figure using the Value +/- keys. The values that may be set range from 1 to 16.
- 3** To modify the second Time signature value in the box press key F2 again.
Modify the figure using the Value +/- keys. The values that may be selected are 4 to 8.
The Time signature may be set only when the pattern is empty. After something has been recorded (using the Record function), this value may no longer be modified, if not after having deleted the whole pattern.

Autocrash: this function is used to establish whether the automatic crash must be activated after every Fill, Break and Intro or not. The automatic crash is activated if “V” is left.

Crash level: establishes the volume at which the autocrash is to be played. This parameter is to be considered only when the Autocrash function is in use. The default value is 96, but may be modified in the following manner:

- 1** Press function key F4 to select the box relating to the Crash level parameter.
- 2** Modify the value using the value +/-keys. The values that may be selected range from 1 to 127.

Lower 1 octave: this is used to define the octave at which the Lower 1 is to be played (manual chord). The default value is + 1. To modify the Lower 1 octave:

- 1** Press function key F6.
- 2** Modify the value using the Value +/- keys. The values that may be selected range from -3 to +3.

Lower 2 octave: the same as the above. To modify the Lower 2 octave:

- 1** Press function key F7.
- 2** Modify the value using the Value +/- keys.

Bass octave: establishes the octave at which the fundamental bass is to be played. The default value is C1 but may be modified by pressing function key F8. The values provided are C1, (the most common mode) C0 and C2.

Bass type: establishes if the bass is to be played lower or higher than the E0 note. This function may be modified using function key F9.

4STRINGS: In this mode the automatic bass will never be played lower than the E0 note with 4 strings.

5STRINGS: In this mode the automatic bass may be played down to C0, just like the modern electric basses with 5strings.

The Bass octave and Bass type functions should generally work together. Let's see why in the following example:

Let's suppose we have a style in which the fundamental bass note corresponds to C0. If we want the bass to perform the pattern correctly, we must set the Bass Octave function on C0 and the Bass Type on 5strings.

Mode / Retrigger: As may be seen from the illustration below, the two Mode (relating to the Chords) and the Retrigger (relating to the Chords and Bass) functions are indicated at the centre of the Display. For the contents and meaning of these two functions, refer to the RETRIGGER & MODE paragraph within the ARRANGE MODE chapter.

To modify the Mode and Retrigger functions setting proceed as follows:

- 1** Use the Cursor < > keys to search for the parameter concerned.
- 2** Modify the value using the Value +/- keys.

Save: to make sure that all the modifications executed in the PARAMETER menu are stored in the memory, they must be saved by pressing function key F10. After the Save operation, the instrument replaces “Empty” with “Pattern”. Press function key F5 (Escape) to return to the main display of the PARAMETER menu (See “Parameter” illustration).

RECORD

Pattern recording function.

Press function key F1 to gain access to this menu.

Use the RECORD function to create complete Styles entirely similar to the 198 internal Factory Styles. The parts making up the Style that may be programmed are the following:

ARRANGE

FILL1, FILL2, FILL3, BREAK

INTRO1, INTRO2, INTRO3

END1, END2, END3.

The individual instrument sections that may be programmed are the following:

DRUM, BASS, CHORD1, CHORD2, CHORD3, CHORD4, CHORD5, GROOVE.

The Groove section is not shown in the RECORD display as it may not be programmed in the Pattern; we can however use it by copying it from the standard Styles, using the Copy function (See Pattern copy).

Before actually starting to record, the following operations must be performed:

Choose the part to be recorded:

- 1 Press function key F1.
- 2 Choose the part using the Value +/- keys.

Choose the number of the Bars:

- 1 Position the cursor on the number to the right of "BAR". The default value is 4 but the values that may be selected range from 1 to 16.
- 2 Modify the values using the Value +/- keys.

This parameter may be modified only while the part selected is completely empty. The bar numbers may be selected for the following parts: Intro1, Intro2, Intro3, Arrange, End1, End2 and End3. The Fills and the Break have a fixed time of 1 bar.

Choose the instrument section to be recorded using the Cursor < > keys.

When the Drum section is recorded, the percussion sounds and the effects located below key 36 and above key 96 may also be used.

To transpose the Drum section:

- 1 Position the cursor on Drum.
- 2 Modify the value using the Value +/- keys. The available values are: -12, +12, +24, +36 and 0. 0 is the default value and is displayed with dashes.

Choose the Quantize value:

- 1 Press key F6.
- 2 Search for the desired value using the Value +/- keys. The available values are: Real (real Tempo or no quantization), 1, 4, 8, 16, 32, 4T, 8T, 16T, 32T. The letter T stands for Triplet, or rather musical division in triplets.

How to record the individual instrument sections:

- 1 Press key F8. In this way the REC function is selected.
- 2 Press the Start/Stop key to start Recording. After one bar stand-by ("beat 4 "or" Pre-count") we may start playing.

It is crucial to bear in mind the following possibilities when recording the Pattern:

- All the notes played during the Pre-count are entered in the first step of the first bar.
- The last recording totally deletes the previous recording with the exception of the Drum section, on which subsequent over-recordings may be performed.
- The sounds for each instrument section may be selected using the Voice Banks keys.
- It is possible also to record the variations of tempo in the Drum section using the Slow/Fast keys.

Record

ARRAN.A [01A Empty] VAL. QUANT 16

SOLO [OFF] BAR : 4

TONALITY [M, m, 7th] DRUM : Standard ---

METRONOME [ON] BASS : Fingered

CHORD1 : Grand

CHORD2 : Folk

CHORD3 : Jazz

CHORD4 : Warm

CHORD5 : Brass1

Memory Free: 37 %

QUANTIZE

REC PLAY

VELOCITY

CLEAR

Playing back the Pattern:

The instrument automatically selects the PLAY function at the end of Recording. To play back all that has been recorded:

- If the Drum section is concerned, merely press the Start/Stop key.
- If the other sections are concerned a chord must be played on the Left part of the instrument and then press the Start/Stop key. This is indeed the reason why it is crucial to position the Split function on C3 before gaining access to the EDIT PATTERN menu.

If the quantization of the parts recorded is unsatisfactory we may modify it as follows:

Quantize:

- 1 Press function key F6.
- 2 Modify the value using the Value +/- keys.
- 3 Press function key F7 (Quantize), which confirms the new quantization

This function allows the re-quantization of what was played in the last recording, even a number of times.

Solo: the Solo function is used to listen to one instrument section at a time.

- 1 Select the instrument section desired using the Cursor < > keys.
- 2 Press key F2 to activate the Solo function. This is activated when a "V" appears in the relative box.

Metronome: The Metronome function may be activated or cut out using function key F4.

VELOCITY: used to modify the Key Velocity value of the trace selected.

Press key F9 to gain access to the Velocity menu.


The Velocity control may be adjusted for both the entire track and for the single note.

- 1 Press function key F1 to modify the entire track.
Press F2 and the NOTE to be edited to modify the single event.

In both cases, proceed as follows:

- 2 Press function key F3 to select VALUE.
- 3 Use the Value +/- keys to establish the increment or decrement value of the Velocity control.
- 4 Press key F10 to make the operation effective.

Press function key F5 (Escape), to return to the Record menu (See illustration)



Clear: depending on the instrument section selected, this function allows the user to delete in a number of manners. While only the global cancellation of the track is provided for the Bass and 5strings, for the Drum section on the other hand it is possible also to cancel a single note of the entire Groove section and of the Tempo variations.

To cancel Bass section or one of the 5 chords:

- 1 Search for the instrument section to be cancelled using the Cursor < > keys.
- 2 Press and hold down function key F10.
- 3 While key F10 is held down, press function key F5 to confirm the cancellation of the entire track.

To cancel in the Drum sections:

- 1 Position the cursor on Drum.
- 2 Press and hold down function key F10.

At this stage with function key F10 held down, a number of possibilities are available:

- a) Cancel the entire Drum section by pressing function key F5.

- b) Cancel the single note by playing it on the keyboard.
- c) Cancel the Tempo variations by pressing function key F2.
- d) Cancel the entire Groove section by pressing F1.

The last function indicated may be used if the standard Styles containing the Grooves are edited.

Save: Before starting to program a new part of the Style or before exiting from the Record menu, if all that has been recorded is to be stored in the memory, function F5 must be pressed (Save).

If the user forgets to press F5, the instrument will offer the user another possibility to save the last modifications performed. The display warns the user in the following manner:

"Pattern Changed; F5 Save; F10 Continue".

- Press F5 to save.

- Press F10 to continue the execution without saving the last modifications made.

To exit from the Record menu and to return to the main page of Edit Pattern press the Exit key.

PART CLEAR:

Press function key F3 to gain access to the Part Clear menu. The PART CLEAR menu is used to entirely or partially cancel the Pattern.


To cancel the entire Pattern: press key F1, then F10 to confirm the operation.

To cancel the single parts:

- 1 Select the Part to be cancelled using the function keys. To select the Intro, the Fill or the Ending press the relative function key a number of times. The Part selected is enhanced at the centre of the Display.
- 2 Press F10 to confirm the operation.
Press F5 to exit from the Part Clear menu.

You can also delete the programmed notes individually. This operation must be carried during Recording with the Start on: just insert F 10 – Clear and play the notes on the keyboard that you wish to delete.

To delete one or more notes from the whole sequence, then keep these notes pressed for the whole length of the programmed cycle.



COPY: the Copy function is used to construct a Pattern by copying Parts or individual instrument sections of Styles Factory of the instrument or of other Patterns.

Press key F4 to gain access to the Copy menu.

As may be seen from the display, the Style to be copied is shown to the left (Source) and the destination Style to the right (Destination).

To copy a Pattern:

- 1 Use function key F1 to choose the Style group from which the style to be copied is to be taken:
Factory A/B, Custom A/B, Pattern A/B.
- 2 Select the style (Source) using the keyboard keys 0 - 9.
- 3 Press F6 to set the A/B group of the destination Pattern.
- 4 Select the destination Pattern using the keyboard keys 0 - 9.


At this stage, three possibilities are available

- COPY THE ENTIRE STYLE.

Set Global using key F3, then press F10 to confirm the operation.

- COPY THE PARTS OF THE STYLE SEPARATELY (Intro, Arrange, Fill etc.).

1. Select the Part of the Style to be copied using key F3.



2. Select the destination Part using key F8. It is crucial to bear in mind that the Arrange are copied with the Arrange, the Fills/Break with the Fills/Break, the Intros with the Intros and the Endings with the Endings. It is not possible for example, to copy a Fill on an Arranger.
 3. Set All Parts using key F4.
 4. Press F10 to confirm the operation.
- COPY THE SINGLE INSTRUMENT SECTIONS SEPARATELY (Drum, Bass etc.)
1. Select the Part of the Style to be copied using key F3.
 2. Select the destination Part using key F8.
 3. Select the instrument section to be copied using key F4.
 4. Select the destination instrument section using key F8. Bear in mind that the Drum section must always be copied in the Drum section; and the same applies to the Bass section. The chords may be copied without restrictions, or rather it is possible to copy Chord 1 on Chord 3 and so on.
 5. Press F10 to confirm the operation.
- When working in the Copy menu, never loose sight of the centre of the Display, which constantly up-dates the user concerning the operations being performed.

PATTERN LIST

This function is used to view the list of Patterns stored in the instrument memory. Press function key F5 to gain access to the Pattern list menu. (The list displayed is purely indicative). You can also access this function from the main display screen of the instrument, by pressing the Pattern Edit button, on the top right-hand side of the front panel, when the style is in operation (start). If the Patterns stored are more than 33, they are displayed on a number of pages. Use Page +/- keys to scroll the pages. To exit from the Pattern List press key F5.

PATTERN LIST Page 1		
01A ACOUST	12A BALLAD_1	23A 16BEAT_1
02A FESTBARK	13A BEGUINE1	24A 16BEAT_2
03A GTRIFF	14A BLUES_1	25A 16BEAT_3
04A JAZZ	15A BOLERO_1	26A 16BEAT_4
05A LATIN	16A SAMBA	27A 16BEAT_5
06A NERT	17A GIPS4	28A 16BEAT_6
07A OLDFUN	18A DISCO_1	
08A SWING	19A 60_POP	
09A BRUSH	20A Pattern	
10A ACOUST	21A HULL4_6	
11A 16BEAT_1	22A R_NAPOLE	

Escape Memory Free: 64 %

DELETE: The Delete function is used to delete the Patterns stored in the memory of the instrument. Press the function key F6 to gain access to the Delete menu. The display shows the complete list of Patterns.

- 1 Search for the Pattern using the Cursor < > keys.
When these are more than 33, the list is displayed on a number of pages; use the Page +/- keys to scroll the pages.
- 2 Use key F9 to select those to be cancelled.
- 3 Press function key F10 to make the operation effective.

Press function key F5 to exit from the Delete menu.

PATTERN DELETE Page 1		
02A CHACHA_2	13A PRY4POLKA1	24A CHACHA_2
03A LAT.DANCE1	14A PRY4POLKA2	26A Pattern
04A MERENGUE_1	15A ROCK&ROLL2	
05A MERENGUE_2	16A ROCK&ROLL3	
06A R.NAPOLET1	17A REGGAE_2	
07A R.NAPOLET2	18A SLOWROCK_1	
08A BAUARIAN	19A TARANTELLA	
09A CANCAN	20A WESTRIDE	
10A LAT.DANCE2	21A OBERPOLKA	
11A OBERPOLKA	22A NAT_DANCE1	
12A OBERWALTZ	23A BAUARIAN	

Escape Memory Free: 37 % Select Execute

DISK SAVE: the Disk save function (F7) allows you to save one or more patterns onto Hard Disk or onto Floppy Disk:

- 1 Press F7 (Disk Save)
- 2 Set the pattern to be saved using the Cursor </> buttons
- 3 Press F9 (Select) to select the pattern
- 4 Press F10 (Execute)
- 5 Enter the name of the pattern under which you wish to save it (using the Value +/- buttons to change the character and the Cursor </> buttons to advance)
- 6 Press F10 (Exec.) to confirm.

MIDI RECORD: from the main Edit Pattern display screen, you can have access to Midi Record F9. Thanks to this function, you can record the Pattern directly from a complete sequence transmitted by Computer or Sequencer .

To record a Pattern from Computer :

- 1** Connect the Midi In 2 of the instrument to the Midi Out of the Computer and the Midi Out of the instrument to the Midi In of the computer.
 - 2** Activate the Midi Clock In of the Computer (deactivate the Thru if inserted)
 - 3** Deactivate Midi Clock In , Out and Thru on the instrument
 - 4** Prepare the sequence to transmit on the Computer
 - 5** The channel of each track of the sequence must correspond to that of the various sections of the style as they have already been selected in the Midi RX of the instrument
 - 6** Press the Edit Pattern button
- 7) Select the MIDI RECORD function using F7
- 8) Make sure that the Time Signature of the Pattern on the PARAMETER section corresponds to that of the sequence to be transmitted.
- 9) Choose the part to record (Arrange A, B,C,D, Intro, Fill etc.)
- 10) Set the Value Quantize function to the desired value. (In the event of very complex sequences, we recommend you set the REAL value).
- 11) Choose the number of Beats to record using the BAR function
- 12) Press F8 to select REC .
- 13) Press the Start button. The recording will automatically stop at the end of the set beats. All the tracks will be recorder in one go.
- 14) To listen to it again, press Start and play the Pattern normally. In this phase, you can give different Quantizations for the acquired sequence before saving it.
- 15) To save the Pattern, press F5 Save.

FORMAT: the Format function formats the Flash ROM of the instrument.

This operation deletes all the Patterns stored in the instrument, restoring the available memory percentage to a maximum of 99%.

This is quite a risky operation and for this reason some Confirm Warnings have been provided before formatting is actually executed.

If the Flash ROM of the instrument is to be formatted:

- 1** Press key F10 three times (following the warnings given on the Display)
- 2** Then press key F5 to definitely confirm the operation.

How to modify Sounds, Volumes and effects of the Pattern.

- To modify the Program Change, Volumes, Pan Pot and amount of the Effect on the Pattern programmed, the ARRANGER VIEW menu must be used, which has already been explained in the chapter dedicated to the Custom Styles (See CUSTOM SYTLE, Page 32)
- Use the EFFECTS menu to modify the type of Reverb., Chorus, Delay and Distorsor. (See page 22)

How to save the modifications.

Modifications of the Patterns using the Arrange View menu become effective only if they are saved in the memory by following the procedure below:

- 1** Press the Save/Enter key.
- 2** Press key F2.
- 3** A new name may be given to the Pattern: the letters are written using the keyboard keys from C2 to F5 (or the Value +/- keys) and the syllable is split using the Cursor < > keys.
- 4** Press key F10 to save.

SONG PLAY

The **Song Play** mode is used to allow the instrument to copy the following from Hard Disk or from Floppy Disk:

- Midi files (format 0 and 1) according to the GM protocol (General Midi standard).
- Songs Words & Music (Karaoke)
- TXT Files (Text files in TXT format)

Copying a Midi File from Hard Disk or from Floppy Disk

In SONG PLAY the call-up, search and copying procedures of the Midi-files may be performed while the instrument is playing.

To call-up a Song or Midi-file from Disk:

- 1** Press the SONG PLAY key.
- 2** Select the Hard or Floppy disk drive using the Page +/- keys.
- 3** Select the name of the folder desired using the Cursor < > keys (in the case of Hard Disk).
- 4** Press F5 Dir to display the list of Midi-files stored in the Folder or in the Floppy disk selected.

The display shows 20 midi-files for each display, arranged in two columns.



If the midi-files in the folder (or in the floppy disk), are more than 20 (this is enhanced by the arrows below the name of the last midi-file), press the Value + - key to display the rest of the directory.

- 5** Select the number of the Song desired using the Select keys. The number of the Songs is always made up of three figures, as up to 999 Midi-files may be sent to a single Folder of the Hard Disk. The number is placed to the left of the name of the Song within the directory.

Note: The selection of Songs having a number below 100 (i.e. no. 9 or no. 47) may be made by entering the relative single figure or the two figures alone. In this case however, the stand-by time of the Song will be slightly longer.

The display will show the number and name of the Song.

- 6** Press Start/Stop to start or stop the copying of the Song.



Automatic Search System of midi-files

If hundreds of Midi-files are grouped together in one folder, these would be displayed in the directory in alphabetical order. It would therefore be difficult to search for the song in this manner, and not very practical (especially when playing live).

This problem may be solved using the **Automatic Search System of the midi-file**.

- 1** After having stopped the Song or while the Song is playing, press F5 Dir. The instrument returns to the directory of the midi-files within the folder (or Floppy). Together with the midi-files directory, a rectangle will be displayed, situated below "Hard" or "Floppy Disk", in which a flashing cursor is seen. The automatic search of the songs may be executed from this position.
- 2** Enter, using the keyboard keys (from note C2 to note F5), the initial letter of the song title desired. This letter will appear inside the rectangle with the flashing cursor and the directory

will display the 20 midi-files, the title of which, starts with the letter entered previously. The Automatic Search System foresees the entry of up to eight letters. By adding more letters a more precise song search is achieved. For example:


To call-up the Song entitled “My Song”:

- 1** Press note D4 on the keyboard (corresponding to letter M). The letter “M” will appear in the rectangle and at the same time the directory will display the 20 midi-files starting with the letter “M”.
 - 2** If “My Song” should not appear on the display, enter the letter Y after M (pressing note D5). In this way the search will be more selective as the directory will display all the Midi-files that start with “My”.
- NAME ENTRY ERRORS: if the name is entered incorrectly, press F5 and repeat the entry.
- 3** As soon as the Song is found, press Enter to confirm the selection.
 - 4** Then press Start to start playing the Song.

Function keys that are useful in Song Play

In Song Play, while copying a midi-file, improvised modifications of certain parameters of the same midi-file and to the right part of the keyboard set for the Song may be performed using the following panel keys:

KeyboardTransposer.: (F3) this function is used to transpose the Right part of the keyboard only while the Song is being played. This is obtained by setting the KeybTrans function in the On position and using the Transposer function – F4 (See below) to select the transposition on the Right part only of the keyboard.



Transposer: (F4) simultaneously performs the global transposition of the Song and of the Right part of the keyboard. The range is + o – 72 semitones.

The value of the Transposer is modified using the Value +/- keys. Cancel the transposition by simply pressing both Value +/- - keys at the same time.

Effect: (F2) Press key F2 - Effect to gain direct access to the control page of the standard Effects of the instrument, which may be adjusted while a midi-file is being played (See Effect Chapter).

If the Midi-file provides the test, this must be cut out using key F10 – Lyric Off.

The type and amount of Reverb., for example, may be modified by gaining access to the Microphone and vocalist functions or by using the Equalizer.

On-Line Effects: Insert the On Line Effects button when the Song is playing to have the possibility of intervening on the Effects of the Right part or Singing

F 1 : Chorus

F 2 : Wha Wha.

F 3 : Delay

F 4 : Overdrive

F 5 : Distorsor

F 6 : Exclusion / insertion of the Effect on the Microphone. (Effect / Dry)

F 7 : Level of the Microphone's direct signal
F 8 : Level of Reverberation on the Microphone
F 9 : Vocal Set. Section of the type of Vocalizer using Value .(See KIT VOCALIZER Manual)
F 10 : Exclusion / insertion of Vocalizer. On / Off .

Note: If you wish to play over the entire keyboard, the Split Point must be positioned on C1.
The Right part is not part of the 16 GM parts of the midi file, but is an independent part.

Count/Pause/Restart: this key controls the three different functions.

Count: Selection and starting of a Song from a desired beat number.

- 1** With the Song Play enabled and in the Stop position enter the number of the song.
- 2** Press the Count/Pause/Restart key. (The Count box becomes black).
- 3** Select the beat number from which the play back is to start using the Value + / - keys.
- 4** Press the Count/Pause/Restart key again. The instrument will position itself on the beat selected and will enter into the pause position.
- 5** Press the Count/Pause/Restart key again to start the Song.

Pause: the Count/Pause/Restart key pressed while the song is played sets the actual Song in the Pause position (the letter "P" to the right of the title of the song points out the function).

Restart: Restarts the Song after the Pause. (The Restart is used also for the Style to restart the Arrange from the beginning).

GM Part: (F1) This function is used to display every single part of the midi-file. The following parameters may be modified: Volume – Amount of Reverb. Chorus and Pan Pot Key Shift, Ch.Tx and Ch.Rx, Part Mode, Mute.

The improvised modifications made to the midi-file may be saved on Disk. The following paragraph explains how to modify these parameters and how to save them on Disk (Editing of the set-up of a midi-file).

Fade Out: used during the execution of a Song, it produces the characteristic "fade out" effect.


Song Balance: the volume of the Song with regard to the Right part of the instrument may be adjusted using the Value +/- keys. The Song may be balanced only from the Song Play main display.

Editing of the set up of a Midi-file

This part extends the possibilities of editing midi-files, already dealt with in the chapter dedicated to the SEQUENCER. (Function. Optimizing and modifying a midi-file).

The procedure is quite simple and immediate. Remain in SONG PLAY:

- 1** Start the Midi-file desired.
- 2** Press Stop after 4 or 5 bars.
This will allow the instrument to set all the Midi-file controls on the various GM parts.
- 3** Press F1- GM Part.
Warning: Return to the previous display only when the modification made have been saved, otherwise these will be permanently lost.
Modify all the GM parameters (see: GM Part – General Midi chapter) as desired.
- 4** Press the Save/Enter key.
The display will ask the user whether the new



Save New Song Setup

NEW NAME
ANGELS

Escape Execute

general set-up of the Song as modified is to be saved.

- 5** Press F10 - Execute to confirm or F5 – Escape to delete.

Song Word & Music (Karaoke)


The Song Word & Music (Karaoke) Midi-files of the SOLTON Library are Midi-files containing the words of the song programmed and in time with the song. The lyrics are indicated on the display panel and the syllables change colour as the Song proceeds (Karaoke). Press the F7 button repeatedly to highlight the syllables (UNDERLINE and MARK) or to establish whether the display should indicate the song lyrics entirely (FullScreen) or indicate the words in the upper half and the directory of the folder (only with Hard Disk) in the lower half.(1/2Screen). All the functions and procedures described up to this point for the Midi-files without texts are the same also for the Songs Word & Music with Karaoke.

Juke Box: (F6)

The Juke-Box function is used to display and copy without interrupting the Midi-files, according to a NEXT selection or improvised.

Access to this function may be gained even when the Song is being played.

- 1** Press F6 – Juke-Box, while the main Song Play display is in use.
- 2** Select the Hard Disk or Floppy Disk drive using the Page < > keys (This function is possible only in the Stop position).
- 3** View, if necessary, the list of the Songs available in the Folder or in the Floppy Disk.
- 4** Select the Song number by entering the numbers using the keyboard keys 0-9. The number and name of the Song appear at the top left-hand corner of the display.
- 5** Press Start to start the Song copying function.
- 6** **Next.** While the Song is being played, it is possible to book the next song, by viewing the list of Songs using the Cursor < > keys and by selecting the Song desired using the Value +/- keys. When the Song is selected using the Value keys, its name will be displayed in the NEXT box.
- 7** When the Song being played ends or is interrupted, the number and the title of the song booked previously in the NEXT box appears at the top left corner of the display.
- 8** Press Start to start the new Song.
- 9** Start again from point 3 to continue using the JUKE-BOX function.
- 10** Press Exit to return to the main Song Play display.



Color: (F7) this function allows you to select the type of highlighting of the Song lyrics:

- 1** Mark: this is an indicator, situated on the left-hand margin of the display, which highlights the line of the lyrics synchronised at that moment with the melody.
- 2** Underline: underlines the lyrics as they proceed with the song line.
- 3** Full Screen. indicates the lyrics on the whole display
- 4** 1/2Screen: indicates the lyrics in the upper half and the directories in the lower half of the display

Lead On/Off: (F8) Cuts out or enables the melodic line of the Song.

Warning: The On or Off position for the Song remains enabled also for all the Songs that follow.

Lead Channel: (F9) Establishes on which midi channel the Song line must be played. The melody is normally recorded on the Midi 4 channel. If however, some Midi-files have their melody on channel 1, the Lead Channel may be set on number 1 (pointing out the box with F9 and changing the value using the Value + - keys), and the melody also on the other Songs may be cut out using F3.

Orchestra Off: Upon selecting the Lead Channel using the value +- buttons, after having gone beyond channel 16, the word Orchestr appears. This functions is used to put all the Midi channels in Mute, except for Bass and drums. To confirm this function, press F 8 and set the Lead section on Off .

Lyric On/Off: (F10) Enables / Disables the display of the text on the display for the Song Word & Music Midi-files.

Warning: Once the On or Off position has been chosen, this will remain active also for the Songs that follow.

Text Files in TXT format

The instrument is capable of handling Files in **TXT** format, or rather files of written documents on PC and having .txt extension. This allows the user, for example, to write Song texts on computer, to save them as text Files with .txt extension and therefore to load them from Floppy Disk onto the instrument. The TXT files may run on the keyboard in 2 different manners:

- 1** Arranger mode: the text is visible on the display while the Style is running.
- 2** Song Play mode: the text is visible on the Display while the Midi-file is running. In this case the Midi-file is loaded together with the text (provided that the text name is the same as the Midi-file as indicated below).

TXT Files in the Arranger mode

In the Arranger mode (playing with the Styles), the TXT files are loaded with the usual Disk procedure, choosing the TXT. Section using File Choice (See DISK LOAD).

- 1** The text loaded will appear on the display.
- 2** Press Page < > to proceed to the following text pages. This operation may be achieved also using the pedal switches FS 13 or FS 6).

Font 1/2: The size of the letters may be selected for the TXT files.

From the main display of the Arranger mode:

- 1** Press key F3 Utility.
- 2** Press F7- Text repeatedly to select the Font 1 position (small format), Font 2 (large format) and Off (cut out text).

In the Arranger and Song Play mode it is possible to make the TXT text disappear temporarily by pressing the Exit key. In Song Play it is not possible to choose the Font, therefore it must be done in advance.

TXT Files in the Song Play mode

Simultaneous loading of a midi-file and relative TXT text file)

In Song Play a midi-file may be automatically called-up (from Hard Disk or from Floppy Disk) and its relative text in TXT format.

To do this, a Midi-file and a TXT File having the same name must be saved on the same

Folder of the Hard Disk or on the same Floppy Disk: i.e. **mySong.mid** (midi file) and **mySong.txt** (.txt text).

To automatically call-up the Midi-file and its TXT text:

- 1** Press Song Play
- 2** Select Hard or Floppy Disk using keys Page < >
- 3** Call-up the directory using F5 Dir
- 4** Select the number of the Song of which the text having the same name is to be loaded.
The TXT text will be automatically displayed.
- 5** Press Start to start the Song.
- 6** Press Page < > to scroll the pages of the TXT text, forwards and backwards.

Synchronisation of the Txt file with the Midifile

You can synchronise in real time the feed of the pages of the Txt text within the Midifile. Just use the Page + button while the Song is playing and the text will be indicated on the Display .

Once the Song has been completed, press the SAVE / ENTER button and then confirm using F 10.

If the operation is not optimal and you wish to repeat it, just press F 4 to restore the original file.


FOOTSWITCH

The Foot switch menu enables the assignment of many functions of the X series to the Pedal control. On request 2 effects pedals may be supplied, the FS 13 (13 switches) and the FS 6 (6 switches). Below is the list of functions that may be assigned to the Footswitch :

Sustain	Rot.On/Off	Latin1 off	Jump
Soft	Rot.Slw/Fst	Latin 2 Off	Arabic1
Sostenuto	Registr.Up	Latin 3 off	Arabic2
ArrangerA	Registr.Down	Groove off	Arabic3
Arranger B	Tempo+	Drum lock	Arabic4
Arranger C	Tempo-	Bass lock	Arabic5
Arranger D	Minor	Chords lock	Arabic6
In/End.1	7th	Fall Off	Micro Dry
In/End/.2	m7th	Shake	Fade Out
In/End/3	5+	Overdrive	Crash
Fill 1	dim	Delay	Voice Down
Fill2	glide	Wha-wha	Voice Up
Fill3	kick off	Chorus	Harmony
Break	Snare Off	Reverb	Program
Start/Stop	Hi-Hat Off	Distorcor	Swell
Count In	Cymbal Off	Text Page-	Trasposer-
Key Start	Tom/Off	Text Page+	Trasposer+
Key Stop	Tamb.Off	Vocalizer	2nd Voice

To gain access to the Foot switch function from the main display:

- 1** Press F3 – Utility
- 2** Press F 5 – Foot switch.
- 3** To modify the standard configuration of the 13 switches, with Cursor < > the switch is selected and with Value -/+ all the aforelisted functions that may be assigned to the pedal are scrolled.



To save a different setting of the Foot switches: 1 – Press Save/Enter and confirm using F 10 – Save. The Default function – F 10 restores the original manufacturer's configuration.

SONG RECORD

The Song Record function consists of the registration of a sequence played in real time on the keyboard. All the Midi events and variations applied to the control panel such as Tempo, Sounds, Volumes, Effect etc. are recorded in the sequence.

The Song is directly recorded on Disk (Floppy or Hard) as standard Midi-files .

To record the Song:

- 1** Press the Song Record key.
- 2** Before starting to record, a name must be given to the sequence. Write the letters using the C 2 to F 5 keys; shift the sector using Cursor < >, then press F 10 – Save.
- 3** The Display will show a new message " Press F 10 to Start Record ". Press Start.
- 4** “**Recording**” will be enhanced on the main Display.

The sounds may be modified and the Style may be selected from this status before starting to record. Recording starts as soon as the first event is enabled, or rather the first note is played or Start, Intro or Ending is activated and ends when the Song Record key is disabled.

Enter Song File Name:

NEW NAME
_

Escape
(Letters with C2/F5 keys
sector with CURSOR<>)
Save

To listen to the Song:

- 6** When the Song Record key is disabled, the keyboard automatically pre-arranges itself in Song Play with the sequence just recorded.
- 7** To listen simply press Start.

ACCORDION

The Accordion menu is reserved exclusively to the accordion. Press key F6 to gain access to the menu. At this stage, connect the accordion to the MIDI IN 2 socket if this has not been done so previously, of which the default setting is Keyboard (See MIDI UTILITY at page 53).

How to set the parameters for the accordion.

Press the function key F10 to enable the functions of the Accordion menu. As soon as ACTIVE is set, the Midi Receive automatically positions itself on **Accordion 1**.

This automatic function has been achieved to facilitate the midi connection to the accordion. The Midi ACCORDION 1 set-up is effective with most of the accordions currently available.

INTERNAT

LEFT VELO
Fixed: 64
RIGHT VEL
Fixed: 127
LEFT DRUM
Off

Escape

Bass

click 64

fingsnap 64

Chords

stick 1 64

snare 2 64

BRS SUST.

0

Off

-1

+1

+1

Inactiv

International or Belgique: This parameter must remain on International with all types of accordions, barring those that use the recognition system of the Belgian type chords.

Press key F1 to switch over from International to Belgique.

Left Velocity: This is used to set the dynamics of the voices that are manually played with the accordion chords. To modify the value:

- 1** Press F2 to select the function.
- 2** Modify the value using the Value +/- keys.

The value to be set may vary depending on the accordion.

Right Velocity: This is used to set the dynamics of the voices that are played on the right section.

51

To modify the value:

- 1** Press F3 to select the function
- 2** Modify the value using the Value +/- keys

The Left Velocity and Right Velocity functions are extremely useful when using an accordion without the transmission of expressive control.

Left Drum: When this function is ON, the Drum section of the instrument may be played manually by means of the bass and chords of the accordion. Use key F4 to enable or disable the function. The percussion sounds and the respective dynamics value is displayed at the centre of the screen. Two percussion sounds are provided for both the bass and the chords of the accordion. To modify the sounds and the respective set dynamics value:

- 1** The sounds and the dynamics value to be modified are selected using the Cursor < > keys.
- 2** The new sounds and the respective dynamics values are found using the Value +/- keys

When a sound is to be completely cut-out, merely position the dynamics value at 0. It is advisable to use the Left Drum function when one of the styles of the keyboard is disabled.

Bass Sustain: This is used to select the length of the sustain on the manual bass. This function is operational only when the Manual key is lit. To modify the value:

- 1** Press key F6 to select the function.
- 2** Search for the value desired using the Value +/- keys.

Bass to Chord: When this function is ON, the bass note becomes part of the recognition of the chord. It is thus possible to play special chords that are not typical of the accordion. Example: By playing the Do Major chord and the Si bass, a chord of Do 7m is achieved.

Bass Octave: This is used to select the octave of the manual bass. This function too is effective only when the Manual key is lit. To modify the bass octave:

- 1** Press key F8 to select the function
- 2** Search for the new value using the Value +/- keys

Lower Octave: This is used to select the octave of the two Lowers.

- 1** Press key F9 once to select Lower 1; Press key F9 twice to select Lower 2.
- 2** Modify the values using the Value +/- keys.

Use key F9 (Escape) to exit from the Accordion menu.

Some useful tips for the accordionist

- 1** Connect the midi cable to the Midi In 2 socket.
- 2** Activate the Accordion menu
- 3** If the accordion sections (Right, Bass and chords) fail to play correctly, make sure that the midi channels have been set correctly.
- 4** If the setting of the Channel Receive is modified, save the new setting as Accordion 1. This operation is used to automatically call-up the new Midi setting when the Accordion menu is activated.
- 5** There are two Midi Set-ups reserved to the accordionist, namely Accordion 1 and Accordion 2.
- 6** Accordion 1 is advisable when automatic styles are used or when a manual accompaniment is played.
- 7** Accordion 2 is advisable when classic songs are played. In fact, it is thus possible to control all 16 parts of the Midi In 2 from the accordion.
- 8** The Accordion menu may be saved in Registration.
- 9** To set the bass in Manual mode, activate the MANUAL function using the appropriate key.

OUT ASSIGN

This menu controls the assignment of the various parts of the instrument on the 4 Audio outputs available. There are 2 separate modes for the audio assignment, one concerning the keyboard and the other concerning the General Midi (GM).

Keyboard Out Assign

To gain access to the menu from the main display:

- 1** Press F 3 – Utility
- 2** Press Page > to proceed to the second Utility page.
- 3** Key F 6 – Keyboard Out Assign enables the control function of the outputs for the Keyboard, or rather over the various parts: Drums, Bass, Chords, Lower, Right, Microphone.

L&R Standard: (F 1) normal stereo functioning mode of the keyboard with the Left/Mono 1 and Right 2 outputs.

L&R Out 3: (F 2) this function is used to send one or more parts of the instrument to Output 3 using the 2 L/R stereo outputs at the same time.

Use Cursor < > to scroll all the parts and use Value + / - to confirm which parts are assigned to Out.3.

The effects remain activated on Left and Right. Output 3 is without effects.

L&R	Keyb. Out Assign	Default
Standard	DRUM	PARTS
L&R Out 3	Kick	Right
L&R Out 3&4	Snare	Bass
Separate 1 2 3 4	Hi-Hat	Chord1
Escape	Cymbal	Chord2
	Tom	Chord3
	Tamb.	Chord4
	Latin1	Chord5
	Latin2	Lower1
	Latin3	Lower2
	Groove	Mike

L&R Out 3 & 4: this function is used to send one or more parts of the instrument to either Output 3 or Output 4. The control is the same as above for L&R Out3.

Using this combination, only the Chorus, Delay and Distorsor effects remain activated on the Left and Right (the Reverb. is cut out).

Separate 1, 2, 3, 4: this function enables the free assignment of the parts of the keyboard to any of the 4 Outputs available. Using this combination, all the internal instrument Effects are cut out. The Cursor is used to select the parts and the Value + / - keys to select the Output. The Default function restores the initial conditions on each of the Out Assign combinations.

GM Out Assign: Assignment of the separate outputs for the 16 GM parts. To gain access to the menu from the main display:

- 1** Press F 3 - Utility
- 2** Press Page > to proceed to the second Utility page.
- 3** Press key F 7 – GM Out Assign.

This section controls the assignment of the outputs on the Percussion sections and on the 16 General Midi parts

L&R	GM Out Assign	Default
Standard	DRUM	GM PARTS
L&R Out 3	Kick	P.1
L&R Out 3&4	Snare	P.2
Separate 1 2 3 4	Hi-Hat	P.3
Escape	Cymbal	P.4
	Tom	P.5
	Tamb.	P.6
	Latin1	P.7
	Latin2	P.8
	Latin3	P.9

The selection of the parts and the assignment of the Outputs is performed in the same way as for the aforesaid Keyboard Out Assign.

The Default function – F 6 restores the standard mode on each of the combinations.

ARABIC


The Arabic Menu enables the modification of the standard tuning of the X series, adapting it to the types of tuning commonly used in Arabic countries.

The variations of the Transposer also act on the Arabic scale.

To gain access to the menu from the main display:

- 1** Press F 3 – Utility
- 2** Press key Page > to proceed to the second Utility page.
- 3** Press F 1 – Arabic.

Left: (F 1) this parameter is used to establish whether the Arabic scale intervals are to be operational also on the Arranger and Lower part of the instrument. By pressing F1 repeatedly the mode is selected. In the NO position, the Arabic functioning is cut out from the whole left part.



Footswitch: (F 6) This button activates the **NOTE MAPPING** function that allows you to assign the alterations of the Arabic scale to the Footswitch buttons and the **ARABIC SET** function that automatically activates the 6 Arabic combinations that the instrument can store on the first 6 switches of the Footswitch (FS6 or FS 13).


Arabic Scale: The selection of the intervals of the Arabic scale is achieved using the keyboard keys from C 5 to B 5. Each time a key is pressed, the corresponding note on the Display becomes black. The number - 50 refers to the tuning of a quarter of a tone (the exact semitone would have a value of 100).

Using the Value + / - keys the tuning of each key may be modified with extreme preciseness within the range of – 100 / + 99.

If the same key is pressed twice the value is reset.

The Normal key – F 10 restores the standard tuning.

6 different types of tuning may be saved according to the Arabic scale on 6 Arabic locations.



Proceed as follows to save a certain Arabic scale setting after having modified it:

Press Save / Enter.

Use Cursor < > to select the Arabic location and F10 to confirm. After saving, the Display returns to the Arabic Scale display.

The 6 Arabic locations saved may be easily activated while playing live using the pedal switches FS 6 and FS 13 (see Foot switch).

REGISTRATION

The Registration function consists of the global saving of the general status of the instrument with its main functions. Two types of Registrations are available on the X series: Block Registrations and Single Registrations.

The selection between the 2 types is achieved in the following manner:

- 1 - Press key F3 - Utility
- 2 - Press Page >
- 3 - Press key F8 to select Block or Single.

Block Registrations

The Block registration concerns the entire block of 198

Registrations within the instrument, split up into 2 Banks of 99 registrations each (A and B). The Block mode will be that enabled when the instrument is turned on. All the external panel commands together with their relative functions may be programmed in Registration and also the internal parameters of the various operational menus. The selection is made, as for the Styles, by means of the numerical keyboard from 0 to 9.

To save a Registration: supposing we have already set the instrument panel as desired, having selected the Style and modified the Tempo, Volumes, Sounds etc..

To save, simply:

- 1 - Press Save / Enter.
- 2 - Press F 1- Registration.
- 3 - Use the keyboard 0 – 9 to select the destination number of the Registration and the A/B key to select the Bank. A name may also be given to the Registration by writing the letters using keys C 2 to F 5 and shifting the sector using Cursor < > .
- 4 - Press F 10 – Save to confirm.

The Registrations thus saved are stored in the memory even after the instrument has been switched off.

Single Registration



The Single Registration is a Registration exactly the same as the internal Registrations of the Block Registrations group, with the exception that it is controlled via Disk only (Hard or Floppy) and therefore is saved and called-up from Disk individually, one at a time. (The Single mode is selected in the manner described at the beginning of the Registration chapter).

How to save a Single Registration on Disk (after having set the instrument panel in the mode desired):

- 1 - Press Save/Enter
- 2 - Press key F1 - Registration
- 3 - Name the Single Registration
- 4 - Select the folder of destination by means of the numeric keypad 0-9
- 5 - Press key F10 to confirm

The Single Registrations are saved on Disk in alphabetical

order and with their individual progressive number. To call them up, merely type-in the number using the keyboard from 0 to 9. Unlike the Block Registrations, the number of the Single Registration is made up of 3 figures which allows, for example, up to 999 Single Registrations to be sent to a single folder of the Hard Disk. For numbers made up of 1 to 2 figures simply type-in only the single figure or the 2 relative figures. If there are files.TXT or Midifiles on the Disk bearing the same name as the Registration, the homonymous text file as well as the Song will instantly be loaded together with the Single Registration. To activate the Song, just press the Song Play button and Start. These functions are most definitely useful for musicians who love performing live using the Styles, because they allow them to manage the Style, the sound of the Song, the song lyrics and the Midifile using just the one Single Registration.



MIDI

The Midi, Musical Instrument Digital Interface, is an international communication interface that enables equipment provided with Midi to exchange musical information.

The X series is provided with a wide range of Midi functions that allow it to adequately interface with complex Midi systems.

The keyboard may function with **32 Midi channels**, 16 related to the GM standard and 16 related to the internal instrument sections. (Rhythm, Bass, Arranger etc.).

Note: Never use Midi cables longer than 15 meters as this could cause errors during data transfer.

To gain access to the Midi menu from the main display, press F 6 – MIDI.

This display shows all the main functions relative to the Midi for the internal instrument sections.

Lets take a closer look at them in order.

Channel Transmit: (F 1) Press key F 1 to gain access to the control of the Midi Transmission Channels for all the instrument sections. Cursor < > is used to select the various parts and Value + / - to select the number of the Midi Channel from 1 to 16.

The function key F 4 enables the automatic switch-over between the two Receive and Transmit menus.

The Escape key – F 5 is used to return to the initial display.

Channel Receive: (F 2) controls the Midi Reception Channels. It functions identically to the Transmit Channel section.

Midi		FILTER RX
CHANNEL TRANSMIT	01A 8BEAT_1	F. CHANGE TX
CHANNEL RECEIVE	Custom	F. CHANGE RX
TRANSP. TRANSMIT	♩ = 100	CLOCK SOFTTHRU
TRANSP. RECEIVE	Tran.: --- Left: 55	UTILITY
FILTER TX	GRAND PIANO 55	
	Violas	

Channel tx				
Right	--	Preset	1 Groove	9
Left	--	2nd Voice	2 Drum	10
Global	--	Lower1	3 Chord4	11
Registr.	--	Lower2	4 Chord5	12
		Bass	5 Prog.Voi.1	13
		Chord1	6 Prog.Voi.2	14
		Chord2	7 Prog.Voi.3	15
		Chord3	8 Prog.Voi.4	16
CHANNEL RECEIVE				
Escape		MIDI SETUP		
		General		

Midi Set up: these are pre-fixed Midi setting combinations, typical for some types of keyboard connections to external devices. The Midi Set Up are available for both the Midi Transmit section and Midi Receive section.

The Midi Set up may be freely edited and therefore saved by means of the Power On Set Up function (See the relevant passage), so that it is automatically enabled when the instrument is switched on.

Midi Set Up Transmit: General, Master Keyboard, User 1, User 2, User 3, User 4.

Midi Set Up Receive: General 1, General 2, Accordion 1, Accordion 2, User 1, User 2.

Transposer Transmit / Receive: (F 3 - F 4) Controls the Midi transposition in transmission and reception.

The overall range is + / - 72 semitones (6 octaves). The Cursor keys are used to select the part and the Value + / - keys to select the value.

Filter Tx / Rx: the 2 Filter functions (F 5 – F 6) control the enabling or otherwise to receive/transmit on behalf of the instrument of some Midi information concerning exclusive Messages, Keys, Volume, Effects etc. To select the type of message use the Cursor < > keys; the cut out of the reception/transmission part is achieved using the Select key – F 10 (an asterisk points out the part cut out) .

Midi Transp. tx		FILTER RX
CHANNEL TRANSMIT	Bass	F. CHANGE TX
CHANNEL RECEIVE	Chord1	F. CHANGE RX
TRANSP. TRANSMIT	Chord2	CLOCK SOFTTHRU
TRANSP. RECEIVE	Chord3	UTILITY
FILTER TX	Chord4	
	Chord5	
	Lower1	
	Lower2	
	Right	
	Left	

Program Change Tx / Rx: (F 7 - F 8) control function for the transmission/reception of Program changes on the various instrument sections. The second box (2nd / Prg) refers to the Program change of the 2nd Voice and to that of the Programs dealt with as a single voice.

The last 4 boxes (Voice 1 – 4) refer on the other hand to the individual Program change of the 4 Voices that may be assigned to the Program.

Use the Cursor key to select the part and the Select key to disable the tx/rx function for the program change (an asterisk appears on the part cut out).

Midi Filter tx		
CHANNEL TRANSMIT	Excl. Mess.	FILTER RX
CHANNEL RECEIVE	Tabl. Mess. *	P. CHANGE TX
TRANSP. TRANSMIT	Volume	P. CHANGE RX
TRANSP. RECEIVE	Pan	CLOCK SOFTTHRU
FILTER TX	Reverb	Select
	Chorus	
	Modulation	
	Expression	
	RPN	
	NRPN	
	Pitch Bend	

Clock - SoftThru: (F 9) this parameter controls 2 functions: the Clock and the Soft Thru . Use the Cursor to select the part and Select - F10 (asterisk) to confirm the activation of the function.

Clock In: Clock is a standard message for Midi synchronization. If the Clock In is enabled the Start of the instrument awaits the incoming Midi synchronization message sent from external units.

Clock Out: When Clock Out is enabled, the Clock Start signal is sent from the instrument to the external Midi units, which consequently activate their start in perfect timing.

Soft Thru 1/2: the Soft Thru function consists of the direct re-transmission on the Midi Out of the data received to the Midi In. It may be separately enabled on Midi In1 – GM (Soft Thru 1) and on Midi In 2 – Keyboard (Soft Thru 2). The Cursor is used to select the Soft Thru 1 or 2 and the Select key to enable the function.

Progr. Change tx		
CHANNEL TRANSMIT	Pre/Rig	FILTER RX
CHANNEL RECEIVE	2nd/Prg	P. CHANGE TX
TRANSP. TRANSMIT	Lower1	P. CHANGE RX
TRANSP. RECEIVE	Lower2	CLOCK SOFTTHRU
FILTER TX	Bass	Select
	Chord1	
	Chord2	
	Chord3	
	Chord4	
	Chord5	
	Voice1	
	Voice2	
	Voice3	
	Voice4	

Clock, Soft-Thru		
CHANNEL TRANSMIT	Clock Out	FILTER RX
CHANNEL RECEIVE	Clock In	P. CHANGE TX
TRANSP. TRANSMIT	Soft-Thru1	P. CHANGE RX
TRANSP. RECEIVE	Soft-Thru2	CLOCK SOFTTHRU
FILTER TX		Select

MIDI UTILITY

Access is gained to some special Midi functions using key F 10 – Utility

Midi In 1: (F 1) this function enables the modification of the initial Midi setting according to which the GM is always combined with Midi In 1 (16 parts). Press F 1 to establish that the Midi In 1 may function in the two GM or Keyboard modes.

Midi In 2 / Computer: (F2) as above but related to the Midi In 2. This function establishes also which type of Midi Input is used by the Computer Interface socket.

Midi Out: (F 3) this parameter selects which Midi configuration (GM, Keyboard or GM+Keyboard) must be sent to the Midi Out.

Computer Out: (F 4) as for Midi Out but related to the Computer Interface socket.

Computer: (F6) this parameter is used to select the type of Computer (PC or McIntosh) to which the instrument is to be connected if the Computer Interface socket is used. The condition is selected by pressing repeatedly key

Midi Utility		
MIDI IN1	GM	COMPUTER
IN2/COMP.	Keyboard	NO
MIDI OUT	23A POPFUNK_2	LOCAL
GM+Keyb.	Factory	On
COMP. OUT	♩ = 103	
GM+Keyb.	Tran.: --- Left: 51	
Escape	JAZZ ORGAN 53	
	Click	

F 6. In the NO position the Comp.Interface socket is not enabled.

Local On /Off: (F 7) when the Local parameter is set in the OFF position, all the internal sections that are set in Midi Reception will no longer function via keyboard. In this case the instrument may be used only as a sound module via Midi.

GM PARTS (General Midi)

The GM section of the instrument enables the accurate control over the contents of the 16 parts that make up the General Midi Standard.

The Midi In 1 (GM) socket is that pre-arranged for the correct functioning in General Midi Standard.

To gain access to the GM menu from the main display simply press F 1 – GM.

The Display will appear as follows:

To modify the parameters within the first GM display:

- 1** Use the Page < > keys to select the Midi parts from 1 to 16.
- 2** select the function using the F 1 – F 10 keys and modify using the Value + / - keys.

Volume - Reverb- Chorus - Pan Pot: (F 1- F2 - F3 - F 4) Reverb- Chorus – Pan Pot : (F 1- F2 – F3 – F 4) Volume, Reverberation, Chorus, Pan Pot controls. The Delay and Distorsor effects are also included in the Chorus parameter, which may be selected using Cursor < >.

The amount of the effect is controlled using the Value + / - keys.

The Pan Pot ranges from 0/64 Left to 0/64 Right ; Press both Value keys together to set to zero which corresponds to the Pan Pot in central position.

Filter: the Filter function is used to enable/disable the reception of some Midi messages on the single 16 parts of the General Midi. To gain access to the function press key F5.

Use key F 1 or F 6 to select the first 4 channels; with F 2 or F 7 channels from 5 to 8 and so on through to 16.

Use the Value + / - keys to select the various Midi controls that may be disabled namely:

Note, Control Change, Program Change, After Touch, Pitch Bend, Volume, Pan Pot, Reverb, Chorus, Modulation Wheel, Expression, RPN, NRPN. For each one of these controls, it is possible to establish whether they are to be filtered or not by means of key F 10 – On/Off. In the ON position a certain function is disabled; in the OFF position it is enabled.


Key Shift: Tuning transposition + / 24 semitones. The value is changed using the Value + / - keys.

Channel Tx / Rx: transmission and reception channel control. Use key F 7 to select Tx or Rx; use the Value + / - keys to select the channel.

Part Mode: this parameter is used to establish whether a certain Midi part must function as Voice or as Drum Set. This mode may be useful if the Midi-file is programmed with 2 separate Drum Sets. Press key F 8 repeatedly to select the mode.

Mute: (F 9) cut out of the single part. If the 16 Parts function is enabled when Mute is in use, the Volume display appears (see below).

16 Parts: (F 10) This function is used to globally display the mode of all the 16 Midi parts related to the single parameter in use at the time (Volume, Reverb, Chorus etc.). I.e. if the





Volume parameter is in use (F 1), and the 16 Parts function is enabled (F 10) the Display will appear as follows: Use key F 1 or F 6 to select the first 4 parts, with F 2 or F 7 the parts from 5 to 8 and so on through to 16. The Volume value is modified using the Value + / - keys. When a single part is selected, this becomes black and it may be Muted by pressing key F 10. To cut out the Mute on the part, simply press key F 10 again while the part is selected.

(The Mute mode is not enabled in the case of the GM Filter function).

When one of the 16 Parts display is shown, the next display may be pulled up or the previous display using the PAGE < > keys.

REMOTE GM LEVEL. Global Volume control for all 16 GM parts of a Module connected to the Midi In 1 of the instrument. To activate this control, use the two Page + / - buttons with Volume values ranging from 0 to 16 and only intervene during Song Play with Start inserted.



HOW TO CALL-UP THE INSTRUMENT SOUNDS VIA MIDI

Voices Type	Control Change 0 (Bank)	Program Change
Voices Bank A	Value: 0	1-128
Voices Bank B	Value: 1	1-128
User Voices	Value: 2	1-128
Flash Card Voices	Value: 3	1-128
Grooves (Internal)	Value: 4	1-36
Grooves (Flash Card o Simm)	Value: 4	113-128
Drawbars	Value: 5	1-16
Simm Voices	Value: 6	1-128
MSP o Files.Wave	Value: 7	1-8
Drum sets (Internal)		1-112
		121-124
User Drum set		125-128
Drum sets (Card)	Value: 3	113-120
Drum sets (Simm)	Value: 6	113-120
Programs		1-128
One touch		1-48
Registrations	Value: 0	1-128
	Value: 1	1-70

Program: To call-up a Program via Midi, the relative Program change must be sent to the Right midi channel. To perform this operation the Program key must be lit.

One touch : To call-up a One touch selection via Midi, the relative Program change must be sent to the midi channel of the Right section. To perform this operation the One touch key must be lit.

Registration: To call-up a Registration via Midi, the relative Program change must be sent to the Registration midi channel. The Registration may be called-up even if the key is OFF.

DISK

The Disk menu controls all the functions relating to the Floppy Disk and to the Hard Disk of the X series. The **Floppy Disk** drive driver supplied with the instrument controls disks from 730 and 1.44 Kbytes.

The **Hard Disk** (optional) is the ATA – IDE 2,5” type with a capacity of 1Gbyte to 8Gbytes.

The installation of the Hard Disk may be achieved at an authorized centre and in any event by highly skilled personnel.

The Hard Disk is sub-divided into **99 Folders** (or files) each of which can control up to **999 files** of various types.

To gain access to the Disk functions:

- 1** Press the Disk key.
- 2** Use the Page < > keys / Hard /Floppy to select the Hard or Floppy drive. (If the Hard Disk is not inserted, the Floppy drive will always be activated).
- 3** The Display supplies the screen relating to the global directory of the Files stored on Disk.

The directory pages are scrolled using the Cursor keys (if these are more than one) and the single file is selected using the Value + / - keys.

Each file is identified by its extension:

- Midi-file: .Mid
- Pattern: .Pat
- Custom Style: .Sty
- Program: .Prg
- User Voice: .Usv
- Registration: .Reg
- MS DOS Text: .Txt
- Sound Bank: .Snd
- Single samples: .Wav
- Multiple samples: .Msp

Let's see the Disk functions in detail.

DIR: (F1) The Dir function supplies the global directory of the Disk at all times.

LOAD: (F2): File loading function from Disk (Floppy or Hard) to the internal memory of the instrument. The loading function may be performed by directly pointing the file from the general directory (in which all the files stored on Disk are listed). This solution is useful if the directory does not contain a large number of files (i.e. floppy).

When the files are many and different, such as on Hard Disk, then the Load operation may be performed after having selected the desired section first (Pattern, Programs, User etc.) by means of the **File Choice** parameter (F5). (See below).


The loading operation may be single or multiple.

In the case of **single** loading the file selected (or rather the black file) is loaded by simply pressing Load.

In the case of **multiple** loading 2 procedures are possible:

PARTIAL LOAD: Select the files to be loaded using the Value + / - keys and the **Select** function – F10. The files selected will be indicated by an arrow at the left-hand side. Press F2 – Load to confirm.

GLOBAL LOAD: make the global selection of all the files shown on the Display by pressing both Value keys simultaneously (an arrow to the left of all the files will appear). Then press F2 - Load



to confirm.

The Load operation concerns all types of files with the exception of the Midi-files (. Mid). If File Choice is pressed and Midi-file is selected and the Load function is disabled.

The multiple Load function may be useful for the Pattern, Custom Styles, Wave and Multiple sample files. In the other cases, simply load the single file, as each file already includes all the effects of the same type within the keyboard.

For example, a Program or User file includes all the 128 Programs and the 128 Users programmed on the instrument, a Registration file includes all the 198 Registrations available and so on.

Load Sound: The Loading of the Sound Files is simpler than that of the other files. There are three types of Sound files:

- SOUND: corresponds to a complete Sound Bank of the SOLTON Library for X 1 and consists of a block of Sounds (or Grooves) of 8 or 16 Mbytes that may be loaded on Ram (Siam) or Card (See RAM / CARD chapter).

- WAVE: the .Wave files are samples in Sample standard format (Microsoft) that the keyboard is capable of importing, reading, saving. The .Wav extension is also applied to the new single samples achieved on the instrument by means of the Sampler function (See SAMPLER).

- MSP : Multiple-sample. The Multiple-sample is a sound made up of a number of samples (.Wave) assigned to various areas of the keyboard. The samples may be the new ones achieved with the instrument or also external.Wave samples.

To enable the loading of one of the three types of Sound from Disk to Ram Simm:

1 Select the type of sound using keys F1, F2 or F3.

2 Choose the file to be loaded using the Value +/- keys.

3 Press key F2 – Load to confirm the operation.

We remind you that the .SOUND file related to a complete Sound Bank will take up 8 free Mbytes of the Simm and may be selected by enabling the RAM key.

The .wave files and .Msp (Multi-sample) files will be allocated on the first free location between the 8 available on User Voice – Bank 2 , from no. 17 to no. 24.

SAVE: (F3) The Save function is used to save the data stored within the keyboard on Disk (Floppy or Hard).

Before gaining access to the Save function, select the Floppy or Hard drive to be used for saving using the Page < > keys.

Press the Save key – F3. The Display sets itself in the File Choice display (See below) allowing the choice of which section to be saved on Disk.

Select the section to be saved using function keys F2 – F10. The Display appears for the saving of all the other functions in the same way as for the example illustrated for the Programs:

Give the File a new name and press F10 – Execute to confirm.

Save Program [GRAND]

001 GRAND

NEW NAME

GRAND

Undo

Escape

Save To Disk

Save

Letters with C2/F5 keys sector with CURSOR<>

Disk Menu

Floppy Disk

GLOBAL

PROGRAM

BLOCK REGISTR.

PATTERN

MIDIFILE

CUSTOM STYLES

SOUND & VOCAL

TEXT

U.VOICE

U.DRUM

COPY


the Disk Copy function enables the copying of files from Hard Disk to Floppy (and vice versa). How to copy the files from Floppy to Hard Disk.

- 1** Insert the Floppy Disk containing the files to be copied in the instrument Drive.
- 2** Select **Hard Disk** using the Page < > keys.
- 3** Select the TargetFolder using the keyboard from 0 to 9, namely the folder in which the files will be copied.
- 4** Select **Floppy Disk** using the Page < > keys. The display will thus indicate all the files stored in the disk
- 5** Select the files to be copied. Scroll the page using the Cursor < > keys and move from one to file to the other using the Value +/- keys. Use key F10-Select to select the files to be copied. If only files having a certain type of extension (i.e. only midifiles) are to be displayed before making the selection, press F5 (Files choice), then choose the extension desired using the function keys from F1 to F10 (in this case, F5 Midifile).
At this stage select the files to be copied following the procedure described in point 5. Once the files have been selected, press key F4-

Copy.

We have the following possibilities in the Disk Copy menu:

- Press F10 (Execute) to copy one file at a time.
- Press F9 (Copy All) to copy all the files selected.
- Press F8 (Skip) to skip the copy of a certain file and to proceed to the next one.
- Press F5 (Escape) to cancel the operation and to return to the main page of the Disk menu.



How to copy the files from Hard to Floppy Disk

- 1** Insert a Floppy Disk with a certain amount of available memory in the instrument Drive.
- 2** Select **Hard Disk** using the Page < > keys.
- 3** Select the Source Folder using the keyboard from 0 to 9, namely the folder containing the files to be copied. The display will thus indicate all the files contained in the folder.
- 4** Select the files to be copied. Use the Cursor < > keys to scroll the page and the Value +/- keys to move from one file to another. Use key F10 to select the files to be copied. If only files having a certain type of extension (i.e. only midifiles) are to be displayed before making the selection, press F5 (Files choice), then choose the extension desired using the function keys from F1 to F10 (in this case, F5 Midifile). At this stage select the files to be copied following the procedure described in point 5.
- 5** Once the files have been selected, press F4 - **Copy**.
- 6** We have the following possibilities in the Disk Copy menu:
 - Press F10 (Execute) to copy one file at a time.
 - Press F9 (Copy All) to copy all the files selected.
 - Press F8 (Skip) to skip the copy of a certain file and to proceed to the next one.
 - Press F5 (Escape) to cancel the operation and to return to the main page of the Disk menu.
 See figure.

FILE CHOICE: the File Choice function (F5) enables the selection of a certain group of Files from the general directory of the Disk. This is quite useful when rapidly searching for a file or a number of files on Hard Disk, where hundreds of files of various extensions may be saved in the same Folder. The groups of files are:

- Program

- Registration
- Pattern
- Custom Styles
- Sound (Sound, Wave, Smp)
- Text
- User Voice
- User Drum

To select the type of file simply press the corresponding function key and the Display automatically supplies the directory of the Files pre-selected.

DELETE:

This function is used to delete files on Disk. Likewise for all said above for the Disk Load operations, the Delete function may be Single or Multiple and may be performed from the main directory or in a more selective manner, section by section by means of the File Choice function.

To delete:

- 1** first select the file using the Value + / - keys (Select for multiple selection)
- 2** press Delete – F6.
- 3** The display will request further confirmation. Press F10 – Execute to confirm the cancellation or F5 - Exit to exit.

RENAME:

To change the name of the file. The renaming may be performed individually.

To rename a file:

- 1** select the file using the Value + / - keys. The file may be selected from the general directory or from the pre-selected section using the File Choice function.
- 2** Press Rename – F7.
- 3** Write the new name using the keys from C 2 to F5 and moving the sector using the Cursor < > keys.

FOLDER: the Folder menu (F8) enables the display and editing of the Folders stored on Hard Disk. The folder is selected by means of the 0-9 Select keyboard.

- **New:** (F1) the New function enables the creation of a new Folder. To do this, simply write the name of the new Folder and confirm using key F10 – Execute.

- **Delete:** (F2) global cancellation of the Folder.

To delete, select the Folder concerned (which will become black) using the Value + / - keys and press F2 – Delete.

The display will request the user to confirm the operation twice before allowing the Folder to be effectively cancelled with key F10 – Execute. To cancel the operation press F5 – Exit.

Warning: the Delete Folder operation permanently cancels all the Files stored in the Folder.

Before performing the operation it is advisable to carefully evaluate if there are any files to be recovered, copying them onto another Folder of Floppy Disk.

- **Rename:** (F3) Folder renaming function. Write the new name and confirm using key F10 – Execute.

- **Lock:** (F4) the Lock function allows the user to enable a safeguard against accidental Folder canceling or modifications. The Lock function makes it impossible to Delete or Rename a Folder.

To enable the safeguard select the file using the Value +/- keys and press F4 – Lock.

To disable the safeguard press Lock once again while the Folder concerned is activated.

- **Report:** the Report function allows the user to save the document related to the contents of the Folder currently in use on Floppy Disk.

The document will have a .TXT extension and will bear the same name as the Folder. The directories it contains are divided up according to extension and are ranked in alphabetical order. This document may be easily read and printed using a normal IBM compatible personal computer.

The possibility of printing the directory of the various Folders on paper may prove quite useful if the Folder holds many Files.

To save the document on Floppy disk simply select the Folder concerned and then press F6 – Report.

Copy: This function enables the copying of files from one folder to another on the Hard Disk..

In order to copy files from one folder to another:

- 1** Press F7 to gain access to the Copy menu.
- 2** Select the Source Folder, containing the files to be copied, using the keyboard from 0 to 9.
- 3** Select the files to be copied, which will be displayed in the center of the display.
Use the Cursor < > keys to scroll the page and the Value +/- keys to move from one file to another. Use key F10 (Select) to select the files to be copied.
- 4** Press F8 (Target folder) to select the target folder.
- 5** Use the Value +/- keys to select the folder into which the files are to be copied (These folders must be already existing and must be named).
- 6** Press F10 Execute to perform the copy.
- 7** We have the following possibilities available:
Press F10 (Execute) to copy one file at a time.
Press F9 (Copy All) to copy all the files selected.
Press F8 (Skip) to skip the copy of a certain file and to proceed to the next one.
Press F5 (Escape) to cancel the operation and to return to the main page of the Folder menu.

DISK UTILITY: from the main Disk directory by pressing F9 access is gained to the Disk Utility menu, which includes the following functions:

Info: (F1) this function illustrates the properties of the Disk (Hard or Floppy), indicating the capacity, the number of the Files, the Folders and the percentage of free memory.

Tempo: (F2) this function allows the user to change the initial Tempo of the Song or Midi-file stored on the Disk. To change the tempo:

- 1** Press F2 – Tempo. The display shows the directory of the Midi-files stored on the Disk.
- 2** Select the Midi-file using the Value + / - keys. (the file becomes black).
- 3** Press F10 – Execute.
- 4** Use the Value keys to select the tempo variation + / - .
- 5** Press F10 – Execute.
- 6** Before saving the new Midi-file with the different tempo the name may be written.
Then press F10 – Execute to confirm.

Transposer: this function allows the user to perform the global transposition of the midi-files on Disk.

To transpose the Midi-file:

- 1** Press F3 – Transp. The Display shows the directory of the midi-files.
- 2** Select the file using the Value + / - keys.
- 3** Press F10 – Execute.

Format: Hard Disk formatting. **This function permanently deletes the entire contents of the Hard Disk** and is therefore to be executed only if the entire Disk is to be re-configured.

For this reason, a safeguard function has been provided (Lock Format) that prevents any kind of accidental formatting.

If key F4 is pressed to gain access to the Format function no modifications will be made.

To gain access to the Format function:

- 1** Press key F6 – Lock Format.
- 2** If the user intends to proceed press F10 – Execute to disable the Lock Format safeguard.
- 3** Now press F4 to enable the Format function.
- 4** The message “Hard Disk Format. Are you sure ??” warns the user that the Hard Disk is going to be formatted. Press F10- Execute if the operation is to be actually performed.
- 5** A second message appears: “Warning ! All Disk data will be deleted”.

By pressing F5 – Escape the function may be exited; by pressing F10 – Execute on the other hand, the Hard Disk will be formatted.

Chain Edit: (F7) this function enables a chain of Midi-files to be programmed.

To save a chain:

- 1** Press key F7 – Chain Edit. The display shows the Midi-files directory.
- 2** Select the first Midi-file of the chain using the Value +/- keys and press F10 – Select to assign number 1 to the file.
- 3** Proceed in the same manner using the Value and Select keys for the Midi-files that follow. Finally press F7 – Save Chain to confirm the selection.
- 4** Assign a name to the chain and press F10 – Execute to save.

Chain List: (F8) this function enables all the Song chains stored on disk to be displayed.

Use Escape to return to the main directory.

Surface Control: Hard Disk surface control. This function takes a few minutes and is used to check if the Disk drive is efficient. If the control detects abnormal running conditions or faults of the Hard Disk, “Fatal Error” will appear.

In this case an authorized service centre must control the unit (or a specialized technician) who will check the type of fault possibly encountered on the Hard Disk drive and replace it if necessary.

If the Surface Control detects no abnormal running conditions at the end of the execution (100% Completed) the display returns to the Disk Utility directory.

SAMPLER


The Sampler section of the X series enables the direct **Sampling** of any sound by means of the Microphone input and also enables the control of **Wave** files loaded externally via Floppy Disk. The .Wave files are samples in Midi Sample standard Microsoft format.

The memory available for Sampling and .Wave files on the Ram Simm is **8 Mbytes**.

Sampling is performed with 16 linear Bits with 44,1 KHz sampling frequency.

The individual samples may be modified by means of a sophisticate Edit and may be sub-divided into a number of Splits (up to 32) to create Multiple-samples (Multiple-sample .MSP).

The individual .Wave samples or the Multiple-samples are assigned to **Bank 2 - User Voice in the 8 locations from no.17 to no. 24**.



SAMPLER menu

To gain access to the Sampler menu:

- 1** Press F2 – Effects in the main display.
- 2** Then press key F3 – SAMPLER. The display shows the main Sampler display with a series of functions.

Load: (F1) this function allows you to load Samples or Wave files present on Disk with an immediate operation and without entering the general Disk menu.

To load the Samples from Disk:

- 1** Press F1- Load
- 2** Select the folder containing the samples from the Hard Disk using the numeric keypad
- 3** Choose the file to load using the Value buttons.
- 4** Press F 2 - Load to confirm. The file will be placed in the first free location among the 8 provided for the Sampler (Bank 2 - User Voice from no. 17 to no. 24).

Time: (F2) sampling time. The default value is 3,5 secs. but may be modified using the Value +/- keys up to 7 secs.

Trigger: (F3) Input signal level threshold beyond which the Sampling starts automatically when in the Start position. Lower the Trigger value, less input signal is required to start sampling; vice versa if the Trigger value is higher, the sampling will start only when the signal reaches a high level.

However careful attention must be paid: in many cases (see Voice, Wind Instruments, Piano, Guitar sampling) if a high Trigger value is left, there is the risk that the sound attack is cut with the outcome of the original sound becoming rather unnatural.

It is therefore advisable to sample with Trigger values that are not excessively high (i.e. between 1 and 10). Any empty spaces between the sampling start and the actual sound attack may be eliminated later in Edit.

Loop: (F4) control of the type of Loop to be assigned to the samples. By pressing key F4 repeatedly the 4 available Loop options are selected:

- FORWARD : in the Forward mode the Loop repeats a certain portion of the sample in a cyclic manner, outlined by Loop and End points (See Edit), reading the sample forwards at all times. This is the most commonly used Loop and may be achieved on a single sample Period (PERIOD LOOP) or on a rather long portion (LONG LOOP).
- REVERSE : in the Reverse mode the sample is read backwards, from the end towards the beginning. The sample transformation from Forward to Reverse mode is achieved automati-

cally when Reverse is selected.

- ALTERNATE: in the Alternate mode the sample Loop, outlined by the Loop and End points, is read once forwards and once backwards in a cyclic manner.
- REVERSE LOOP: the Loop repeats its cycle starting from the end of the sample and not from the Loop point as in the Forward mode.

Pitch: (F7) The Pitch function is used to establish whether the sample must be played with a normal tuning (STANDARD) or with a fixed tuning (FIXED). The selection is achieved using function key F7.

Key: (F8) is used to establish on which key the sample must play with its true frequency. The selection is made using key F8 and select the key desired using the Value keys. The default value is C 3.

Fine: (F 9) controls the fine tuning of the sample with a range of 1 semitone only upwards (+ 99 cents). If a fine tuning downwards is required it is advisable to lower the Key value by 1 semitone first and then to adjust the tuning with Fine.


SAMPLING

Before starting the sampling operation, bear in mind that:

- A** Only 1 sampling may be performed at a time. The beginning of a new sampling deletes the whole Ram Simm dedicated to the Sampler section.
- B** Before proceeding with another sampling, the sound sampled previously must be Saved (if it is to be stored) otherwise it would be deleted.
- C** The Sampling memory may be optimized in various manners depending on the length of the samples. For short samples it may be useful to use the Loop to save memory space.
- D** Up to 8 multiple-samplings may be achieved (Multiple-sampling) with a maximum of 32 samples for every Multiple-sample.
- E** All samples are saved with extension. Wav.

How to record the sample

- 1 Connect the sound source to be sampled to the Micro Input.
We will use one microphone as an example.
Adjust the voice level on the microphone so that there is no distortion.
(The luminous Micro Input Overload indicator in the Voice Bank area lights up when the signal is slightly too high).
- 2 Press F2 – Effects in the main display.
- 3 Press F3 – SAMPLER.
- 4 Choose the timing of the sampling using the Time function (See above).
- 5 Press key F 10 – Start. Sampling will start only when a signal is present on the microphone input and when the keyboard is in a waiting position, without performing other functions.
- 6 Speak or sing into the microphone.
Sampling ends when the dark bar that indicates the sampling time reaches zero.
- 7 Play the keyboard to play back the sample. If the KEY value has not been modified, the original sample will play on C3.



How to save the sample

Before saving the sample it is advisable to make the modifications required on the actual sample to optimize it (See View and Loop function).

If the sample is valid, it may be saved as follows:

- 1** Press Save/Enter. Give the sample a name (if you wish to do so).
- 2** Select the folder of destination using the numeric keypad 0-9
- 3** Press F10 - Execute to confirm
- 4** Press F5 to go back to the main Sampler menu.

VIEW - LOOP

The View menu (F6 on the main Sampler display) enables the display of the sample recorded and to modify its Start, Loop and End points to find an ideal Loop.

Start: (F1) sample starting point. It is extremely difficult to make the Start coincide with the actual start of the sound in the sampling phase especially when low Trigger values are set. Start enables the precise achievement of the actual start of the sound eliminating the initial empty or unrequired part of the sample.

Press F1 to shift the Start point and modify the value using the Value +/- keys. To better display the wave shape it is advisable to modify the Zoom values (See below).

Loop: (F 2) this function is used to establish the starting point of the Loop. Press key F2 and modify the point using the Value +/- keys.

End: (F3) End establishes the end of the sample and also that of the Loop if a Loop has been achieved on the sound.


Zoom: (F4) the Zoom function is used to proportionally enlarge the image of the wave shape of the sample. When searching for the Loop the Zoom function must be used to precisely fix the starting and ending points of the actual Loop.

To modify the Zoom simply press F4 and select the available values using the Value +/- keys:

ENVEL supplies the global image of the sample envelope.

X 10, X 100, X 1600 supplies the different Zoom resolutions, i.e. in the case of a Loop on the period, (See illustration), the value x 100 may be used to roughly identify the period on which a Loop is to be achieved, while the value x 1600 is used to

display and exactly fix the starting and ending point of the actual period.



Some useful tips for finding the Loop

The most appropriate Loop finding for each sample is a work phase that requires a certain amount of skill and also some time.


The type of most commonly used Loop is the Loop Forward, which may be on the Period or Long Loop.

- LOOP on the PERIOD: The Loop on the period is advisable when the wave shape is quite constant and even (i.e. a Guitar or Organ sound) and when there are no beats, modulations, vibrato or similar.

The first operation to perform is to select the sample area where the period is to be selected. To do this, use the Zoom values x 10 or better still x 100.

Once the area has been identified, the Period must be isolated. The period is usually quite clear as it is a wave shape repeated a number of times within the actual sample.

Use the Value + / - keys to shift the Loop and End point of the sample until the period is found. Then the zero point must be searched for accurately at the beginning and end of the period, or




rather the point in which the mean line intersects with the wave shape. To find the zero point, shift the Zoom on the maximum value, namely x 1600.

If the period has been cut precisely, the sample should have an ideal Loop.

- **LONG LOOP:** Long Loop is advised for songs that are rich in modulation (i.e. Arcs, Chorus, Pads) for which it is more or less impossible to achieve a Loop on the single period.

The sample portion must be selected first and foremost, which will be repeated with the Loop in a cyclic manner. It is advisable, as a general rule, to identify a rather even sample portion.

Once the sample area has been outlined with the End and Loop points, search for the zero point at the beginning and end of the sample. Then gradually shift the Loop cursor using the Value +/- keys until an Ideal Loop point is found. This operation may require some time, but if the sample is valid, it will surely be worth the while. A good Long Loop should not contain clicks or annoying noises, but should play in as natural a manner as possible.



MSP

MSP stands for **Multiple-sample**, in other words the instrument section that controls the assignment of a number of samples to various areas of the keyboard or splits.

As the sampling and saving of the sound as .Wave files are referred to a single sample, the MSP function allows the user to call-up a number of .wave files at the same time from Disk and to edit them until new more complex sounds are composed, made up of a number of splits and a number of samples.


Up to 8 Multisamples are available (each made up of a maximum of 64 splits), situated in the User Voice - Bank 2 section from no. 17 to no. 24.

The Multiple-sample may be achieved using samples recorded directly on the instrument or also using .Wave files acquired externally via Disk. The achievement or the editing of a new Multiple-sample involves the cancellation of the Ram Simm area dedicated to Sampling.

To gain access to the MSP functions from the main display:

Press F3 – Utility/Smp .

- 2 Press F9 – MSP New if a new Multiple-sample is to be created or press F8 – MSP Edit if an MSP previously achieved is to be modified.



MSP New: (F9) this function introduces the creation of a new Multiple-sample, for which .Wave files must be loaded first of all that are to be used to compose the various splits.

Press Load F10 to access the folder containing the files: To modify it, use the numeric keypad 0-9.


The file selection is achieved using the Value +/- keys.

The files loading may be **Single** or **Multiple**.

For the Single Loading, simply press F 2 – Load to load the file selected at the time (namely the black file).

For the Multiple Loading first select all the files concerned using key F 10 – Select then press F2- Load.

Once the .Wave files have been loaded, the instrument automatically sets itself in the Edit function of the Multiple-sample or MSP Edit with this first display:



The Editing of the Multiple-sample is sub-divided into 2 pages. Lets examine the functions of the 1st Page:

Start / End: (F1 - F2) the Start and the End are used to establish the lowest and highest note of

each split associated with a certain sample. The .Wave file in which the Start and End points are modified is always the file in use at the time on the display (black file). The note may be selected by simply pressing F1 or F2 and playing the note on the keyboard (from C#0 to G8). It is with this function that the structure of the Multiple-sample is made up on the keyboard, assigning a certain sound to each split and establishing how many keys are part of the same split.

Volume: (F3) volume control of the individual .Wave file associated with the split. The value is modified using keys Value +/- .

Remove: (F4) this function eliminates the .Wave file in use at the time from the Ram.

Pitch: (F6) Press F6 to select the type of tuning of the sample that may be normal (Standard) or fixed (Fixed), or rather identical over the entire keyboard.

Key: (F7) is used to establish to which key the original sample frequency is to be assigned. It may prove useful to correct a frequency incorrectly assigned to the sample before this was saved on disk. The key is selected using the Value keys.

Fine: (F8) fine tuning of the sample with a shift of 1 semitone upwards (+99 cents).

Max Wave: (F 9) selection of the number of splits expected for the Multisample. Choose from 16, 32 or 64. Press the Page > key to proceed to the Multiple-sample functions of the **2nd Page**, with ADSR, Filter and Dynamic controls on the single samples and also the global assignment of the Effects of the Multiple-sample.

Attack, Decay, Sustain, Release, Cut Off: (F1 - F6) these parameters enable an accurate control to be achieved on the ADSR and on the Filter of each single .Wave file in use and displayed (black file). To modify the value simply press the key concerned and use the Value +/- keys.

ATTACK		Multisample P.2/2		CUTOFF	
0		GLOBAL EFFECT		127	
DECAY		OFF		DCA OFFS	
99		Reverb 0		1	
SUSTAIN				DCA SLOP	
0				4	
RELEASE				DCF OFFS	
0				7	
FINE TUNE		Coarse Tune ---		DCF SLOP	
---		Global Level 32		7	
		Rotor Off			

Fine Tune: controls the Multiple-sample fine tune.

Dca / Dcf Offset e Slope: these 4 parameters control the dynamic action (Key Velocity) applied to the amplitude or to the filter of the Multiple-sample. The Offset controls the amplitude or filter level with minimum dynamics, whereas the Slope controls the sound amplitude level or the opening of the filter with maximum dynamics.

To modify the dynamics values simply press the corresponding key and change using the Value +/- keys.

Global Effect: this section controls the Effects that may be assigned to the Multiple-sample (Chorus, Reverb, Distorsor etc.). The effects are split up into blocks with the same structure, already described in the Programs chapter. (See Effects on Programs). Use the Value keys to select the group of Effects and the Cursor is used to scroll the boxes relating to the amount of the various effects; the amount may be modified using the Value +/- keys.

Coarse Tune: this function achieves the transposition of +/- 2 octaves on the Multiple-sample. This transposition is valid only if the Multiple-sample is used on the Right part. The value is modified using the Value +/-keys.

Global Level: global Volume control of the Multiple-sample. The value is modified using the Value +/-keys.

Rotor: this function enables the Rotor effect of the Multiple-sample and is inserted using the two buttons Rotor/On – Slow/Fast.

How to save the Multiple-sample

Once the Edit has been completed, the Multisample can be saved onto Disk as follows:

- 1** Press Enter / Save.
- 2** Give the Multisample a new name (if you wish to do so).
- 3** Select the folder of destination using the numeric keypad 0-9
- 4** Press F 10 - Execute to confirm the saving operation

The Wave files are in this way saved with the pitch value selected within the MSP Edit menu described above. N.B.: the MSP (Multisamples) sounds can also be inserted within the 1 Touch voices .

SEQUENCER

Introduction

The internal sequencer of the instrument allows the user to create or modify midi sequences in a rapid and functional manner, being provided with advanced functions that are typical only to sophisticated computer programs. Press the SEQUENCER button to access the main page. Note. All operations performed on the sequencer must always be saved on disk (see LOAD/SAVE) before exiting the menu or turning the keyboard off. Otherwise, the recorded data will be lost forever. When in the Sequencer mode, the first track out of the 16 available is selected. All the tracks are empty, including the MASTER TRACK. The various functions can be accessed from the main page.

NAME: Use the Cursor<> buttons to access this box and give a new name to the sequence ("SEQUENCE" by default). Press the Save/Name button: an edit window will appear, bearing the current name of the sequence. Every letter that is highlighted by the blinking cursor can be changed by typing on the keyboard. Each key corresponds to a letter that is clearly marked in the serigraphy on the ketyboard. After each letter entry from the keyboard, the cursor automatically moves forward by one letter (you may enter up to 8 letters). As an alternative to the keyboard, the Value-/+ buttons may be used. In this case the cursor will not move forward automatically. If the Value-/+ buttons are pressed together, all edited letters, starting from the current cursor position, will be cancelled. The Cursor<> buttons can be used to move the cursor from one letter to another. Press F10 (Execute) to confirm the new name, press F5 (Escape) to cancel editing.

POSITION	NAME	TEMPO	SIGN	SYNCSTART
1 1 1	SEQUENCE	120	4/4	On
	Stat:Free:100%		Chan.	
RECORD Overdub	01 TRACK_01	All		DELETE
	02 TRACK_02	All		
QUANTIZE	03 TRACK_03	All		COPY
	04 TRACK_04	All		
FUNCTION	05 TRACK_05	All		MUTE
	06 TRACK_06	All		
	07 TRACK_07	All		
EDIT	08 TRACK_08	All		SOLO

TEMPO: It is the speed, expressed in quarters per minute, with which the sequence will be played once it has been recorded. The tempo default value is the one of the last style selected. Use the Cursor <> buttons to access the TEMPO box and change the tempo value by pressing the Value-/+ buttons. When the recording starts, the tempo is memorized in the MASTER TRACK. During recording, use the Fast/Slow buttons to register any tempo variations on the MASTER TRACK. Tempo events can be entered, modified and cancelled after recording, by using the MASTER TRACK menu functions as explained below.

TIME SIGNATURE: It is the bar musical division. The default value is 4/4, i.e. each bar is divided into four quarters. Use the Cursor <> buttons to access the SIGN box and change the numerator/denominator values by pressing the Value-/+ buttons. When the recording starts, the SIGNATURE is memorized on the MASTER TRACK. As with tempo, the SIGNATURE can be entered, modified and cancelled by using the MASTER TRACK menu.

POSITION: It indicates the current position of the sequence. It is divided into three areas that can be accessed by means of the Cursor<> buttons or by pressing the F1 button in succession. The first value indicates the bars, the second value indicates the quarters, the third value indicates the

steps making up one quarter. Each quarter is made up of 48 steps. Once the position has been selected, its default value [1 1 1] can be changed by pressing the Value +/- buttons. Pressing the Value +/- buttons together will reset the default value.

TRACKS: The sequencer is divided into sixteen tracks, plus one MASTER TRACK. Track names are given in the center of the page, preceded by a progressive number.

Track default name is "TRACK_n". Single track names can be changed by means of the OPTIONS menu described hereafter. Recording is performed on the highlighted track; therefore, the track on which one wants to record must be selected before recording begins.

Tracks are selected by pressing the Page<> buttons. The display will show only the group of tracks from 01 to 08 or the group from 09 to 16. Therefore, every time you scroll the tracks, passing from track 08 to 09 by pressing Page> or from 09 to 08 by pressing Page<, the display is updated with the new group of tracks. Tracks can be selected also by using the Cursor <> buttons, but in this case you must pass through the field [Chan.] reserved for playback midi channels. In any case, even if the midi channel field stays highlighted, the selected running track is the one on the left-hand side of the highlighted area.

CHAN: The playback midi channel is shown on the right-hand side of each track name. Use the Cursor <> buttons to access the channel box and the Value +/- buttons to change the playback channel. By default, the channel is set on [All]; this means that when playing back, the midi channels will be reproduced on the originally recorded channels. Instead, by selecting values from 1 to 16, all the midi events recorded on the related track will play on the selected channel. For example, events belonging to the same midi channel can be recorded on different tracks (for example, by playing on the right-hand side of the keyboard), and different midi playback channels can later be set for each recorded track.

STAT: The [Stat] column shows the status for each track. Initially, the column is empty; this means that nothing has been recorded. During recording, the display shows an arrow ">" indicating that each event will be recorded on the selected track. When the recording stops, if at least one event has been recorded, the display will show an "i" (initialized track). The initialization status is removed from the display only if the track is completely deleted. If a track is in the Mute mode, the Status is '*' (although the track contains data, it is not played back). If a track is in the Solo mode, the Status is 's' (during playback, only the Solo track plays).

FREE: This indicates the percentage of memory available. (see DEFrag function for memory optimization).

SYNCSTART: It can be switched on/off by pressing the F6 function button. If SYNCSTART is [Off], the sequence (clock) starts moving forward as soon as the recording begins, starting from the selected POSITION. If the first midi event falls in the PRECOUNT phase (see OPTIONS function), this will force the POSITION into the selected value. Instead, if SYNCSTART is [On], the sequence starts moving forward only when the first event arrives. In this case the PRECOUNT is switched off. Recording with the SYNCSTART switched on is very useful when you want to record an internal style on the sequencer. In this case, recording begins only after the style has been switched on (START buttons, Fills buttons, Key Start, etc.).

RECORD: Recording is switched on/off by pressing the F2 button. There are two recording modes:

Overdub and Replace, which can be selected from the OPTIONS menu.

Overdub: At every recording (run), the recorded events are mixed temporally to the events recorded during the previous runs.

Replace: The new recorded data replace the previous ones.

HOW TO RECORD A SEQUENCE

Introduction.

There are various ways of recording a sequence starting from an empty sequencer (no initialized track). How to load sequences from disks (midi files) and how to use the editing functions for already-recorded sequences are topics that will be discussed in specific paragraphs. Before describing the recording procedure, here is some general preliminary information about midi events and about how to deal with them (if you already have this information, you can skip this sub-paragraph).

Midi Events: The sequencer is capable of recording and playing back events in the midi format. Every midi event is represented by a small set of data. Each datum is normally called “byte” and contains coded “musical” information. For example, every note that is transmitted to the sequencer is coded in a set of three bytes, so that parameters such as timbre, volume, pan-pot, amount of reverb, expression, sustain, etc., are coded. In general, every midi event is made up of 2 or 3 bytes; the first one indicates the type of event and is called STATUS, while the other bytes are data and have different meanings depending on the STATUS.

STATUS	Dati	1st	2nd
NOTA (NOTE ON/OFF)	2 bytes	Note, Velocity	
CONTROLLO (CONTROL CHANGE)	2 bytes	Type, Value	
PROGRAMMA (PROGRAM CHANGE)	1 byte	Program(timbre)	
ALTERAZIONE ALTEZZA (PITCH BEND)	2 bytes	Pitch value	
PRESSIONE DOPO TOCCO(AFTERTOUCH)	1 byte	Key pressure value	

SYSTEM MESSAGES or EXCLUSIVE MESSAGES are particularly important; they are made up of a greater and variable number of data. They contain information (type of effect, lyrics, sound parameters, etc.) in a format that is typical to the instrument. System messages will be described in the MASTER TRACK paragraph.

MIDI CHANNEL: Every Note, Control, Program, Pitch bend, Aftertouch event is associated with information about the midi channel to which the event is directed. There are 16 midi channels and, thanks to channeling feature, 16 different instruments can be made to play separately. Example. One normally says “The piano is playing on channel 1”. This means that the change program relating to a piano timbre has been sent on channel 1; therefore, all the notes sent on channel 1 will be played with the piano timbre and they will take up the controls (volume, reverb, etc.) that were previously set for that specific channel. System messages (for example, exclusive systems) are not associated with a midi channel; in the sequencer, they are memorized only on the MASTER TRACK. In the NOTE events, the first of the two data bytes contains the note that was played, while the second one contains information about the speed with which the key generating the note was pressed. The speed value will determine the musical timbral response of the instrument; for example, many timbres will play at a higher or lower volume depending on the speed of the note. In the CONTROL events, the first byte indicates the type of control, for example, 7 for Volume, 10 for pan-pot, while the second byte normally expresses the amount of control. A number of controls and related codes are given below (see midi implementation in the Instructions Handbook for a more detailed list).

Banco suoni	0
Sounds Desk	0
Modulation Wheel	1
Vocal Glide Tempo	5
Volume	7
Pan-pot	10
Expression Pedal	11
Sustain on/off Pedal	64
Vocal Glide/off	65
Reverb	91
Amount of Effects	93
NRPN LSB	98
NRPN MSB	99
RPN LSB	100
RPN MSB	101
DATA ENTRY RPN/NRPN	6

RPN(Registered Parameter Numbers), NRPN (Non-Registered Parameter Numbers), are special controls that are used to change sound parameters such as, for example, musical entry, release, filter, timbral resonance. Some NRPN are used to change volume, pan, reverb, chorus, pitch of every single percussion instrument, e.g. drum, roll, etc. for drum sets. In general, this type of control is divided into three events.

RPN/NRPN MSB (Most significant byte).

RPN/NRPN LSB (Least significant byte).

RPN/NRPN DATA ENTRY (data) (see midi implementation in the Instructions Handbook for more details).

Every event that is recorded by the sequencer is associated with the temporal position in which the event was “seized” (see EDIT menu), represented in bars, bar quarters, steps per quarter.

Notes are also associated with their duration, which is given by the difference in the amount of time elapsing between the On note (depressed key) and the Off note (released key).

Recording: Once recording is switched on by pressing the F2 button, every midi event is recorded on the selected track, regardless of the event output channel. Thus, events coming from any channel can be recorded on one single track (therefore, do not confuse track with midi channel). For example, if a style is recorded on track 01, when track 01 is played back, all the parts of the style will play because each one of them is associated with a midi channel (see MIDI FILTER function). To select only one or some parts of a style, the midi-in channel of those parts that are not to be recorded must be “shut” (see MIDI FILTER function). If a style is recorded internally or by using the midi plug In 2 (Keyb), the channels are the ones set in the MIDI Channel Tx menu (see Instructions Handbook). Instead, if recording is made from the midi 1 (GM), the channels are those set in the General Midi Chan Rx menu(see Instructions Handbook).

Summarizing, in order to record a track::

- 1** From the MIDI FILTER menu, close the in-coming channels that you do not want to record.
- 2** Use Page <> or Cursor <> buttons to select the track you want to record.
- 3** Set the channel of the track you want to record on All, so that you can playback what you recorded.
- 4** Select the recording mode Overdub/Replace as already described.
- 5** Set SYNCSTART on On or Off as already described.
- 6** Determine the initial recording position.

- 7** Press F2 to start recording.
- 8** At this point, you may start playing: every midi event will be recorded.
- 9** Press F2 again to stop recording.

How to play back recorded tracks:

It is possible to playback during recording whatever was previously recorded. If, instead you simply want to play back, you need to press the Seq. Play (Save/Enter) button. Playback will start from the set POSITION. Note. The POSITION can be brought back rapidly to [1 1 1] by pressing the Value -/+ buttons together, even without selecting the box. In order to playback the track on a channel that is different from the recorded one, you will have to work on the column [Chan.] that is to the right of the recorded track. Be careful, though, because if several midi channels were recorded and you enter values that are different from All, all the events will play on the same playback channel, thus generating unwanted effects.

MUTE: It switches off the selected track. After selecting a track, it is switched off (no event is reproduced) by pressing F9 (MUTE); pressing F9 once more will switch it on again

SOLO: Allows you to switch off all tracks except the one in Solo. After selecting a track, it is put in solo by pressing F10 (SOLO); pressing F10 again will remove the solo.

NOTE. Only one track at a time can be in solo.

SEQUENCE QUANTIZATION

Quantization means changing the position of the recorded events so that the selected musical division can be followed exactly, thus eliminating small performance imperfections.

QUANTIZE: Enter the QUANTIZE menu by pressing the F3 button.

The track that is selected in that precise moment or part of it can be quantized.

The name of the track chosen for quantization and the locators indicating the FROM: position (where quantization will start from) and TO: position (where quantization will end) will appear in the center of the page.

Use the Cursor<> buttons to select the locator and the Value -/+ buttons to change its position.

The locators are represented by the usual three numbers indicating bar, bar quarter and step.

In order to quantize a track, proceed as follows:

- 1** Use F1(NOTE), F2(CONTROL), F3(PROGRAM CHANGE), F4(ALL) to select the type of event you want to quantize. If you press F4(ALL), all the events will be quantized and, therefore, the NOTE, CONTROL and PROGRAM CHANGE events will automatically be deselected. Pressing F1 or F2 or F3 will automatically deselect ALL if the latter had been previously selected. By default, quantization is performed only on notes (most commonly used condition).

- 2** pressing F6 repeatedly to select the desired quantization value. The following values are available:

real	no quantization
64T	1/96 of a bar (triplet)

64	1/64 of a bar
32T	1/48 of a bar (triplet)
32	1/32 of a bar
16T	1/24 of a bar (triplet)
16	1/16 of a bar
8T	1/12 of a bar (triplet)
8	1/8 of a bar
4T	1/6 of a bar
4	1/4 of a bar
2	1/2 bar
1	1 bar

3 Use F7(LAST RECORD), F8(PART), F9(ALL TRACK) to select the part of the track that will be quantized.

LAST RECORD: The last recording is quantized; the locators are automatically set on the positions of the last recording.

PART: Any part of the track. This condition is automatically highlighted when a locator is changed.

ALL TRACK: The whole track. By pressing F9, the locators are positioned at the beginning and at the end of the track respectively. “Beginning” is the position of the first event, “end” is the position of the last event.

4 Press F10(Execute) to perform the operation. If the result of this operation is unsatisfactory, you can use a different quantization value and repeat the operation.

Editing single events (EDIT function):

EDIT: This function allows you to edit every event that has been recorded on the selected track. Access the first page of the EDIT menu by pressing the F5 button. The menu is divided into two pages. For both pages, the midi events with their temporal position are centered on the display. Let us have a detailed look at the fields relating to the events that are centered on the display.

1 1 1			EDIT (1 of 2)				MODIFY
View	Posit.	Length	2nd	1st	Event	Chn	
ALL	1 1 1		0	Bank	90	Progr	3
	1 1 1				0	Vol.	3
	1 1 1				64	Rev.	3
	1 1 1				64	Cho.	3
	1 1 1				64	Pan.	3
	1 1 1	1 0 19	28	F#2	Note		3
	1 1 1		0	Bank		4	
	1 1 1				5	Progr	4
	1 1 1				0	Vol.	4
	1 1 1				64	Rev.	4
	1 1 1				64	Cho.	4
	1 1 1				64	Pan.	4

Position: The Position column gives you the temporal position of the event in bars, quarters, steps. Every quarter is divided into 48 steps.

Length: It indicates the length of the note events alone; the field is blank for the other events. E.g. Length 1 2 0 indicates a note lasting 1 bar + 2 quarters; Length 0 3 24 indicates a note lasting _ plus 24 steps.

1st: The meaning of this parameter changes according to the midi event that is represented. The range of values for this field is 0-127. In the case of NOTES, it indicates the note that was played. E.g. C_4, G_3. In the case of control, it indicates the type of control – as shown in the table below, where the most commonly used controls are given (see midi implementation in the Instructions Handbook for a more detailed list).

- 1st = 0 Bank (sound bank selection marked "Bank" on the display).
 1 Modulation (modulation wheel marked "Modul" on the display).
 5 Portamento Time
 6 Data Entry (contains RPN and NRPN controls data and is marked "DtaEn" on the display).
 7 Volume (marked "Vol." on the display).
 10 Pan-Pot (marked "Pan" on the display).
 11 Expression (expression pedal marked "Expr." on the display).
 64 Sustain (marked "Sust." on the display).
 65 Portamento on/off (marked "Port." on the display).
 66 Sustain pedal on/off (marked "Sost." on the display).
 67 Soft pedal on/off (marked "Soft" on the display).
 84 Wha-wha on/off.
 85 Wha-wha amount.
 91 Reverb amount (marked "Rev." on the display).
 93 Effects amount (marked "Cho." on the display).
 98 Byte LSB (significant menu) NRPN (marked "NrpnL").
 99 Byte MSB (most significant) NRPN (marked "NrpnM").
 100 Byte LSB RPN (marked "RpnL").
 101 Byte MSB RPN (marked "RpnM").
 121 Reset all controllers (sets main controls at default value and is marked "RstCn" on the display).
 123 All notes Off (reset played notes marked "Allof" on the display).

In the case of PROGRAM, it indicates the timbre (see list of voices in the Instructions Handbook).

if Bank = 0 (first sound bank)

Program = 0	Piano
1	Rock Piano
2	Upright
3	Honky Tonk
"	"
16	Leslies
17	Jazz Organ
"	"

Bank = 1 (second sound bank)

Program = 0	Concert
1	Digipiano
2	House Piano
3	Stage Piano
"	"
16	Rotor B3
17	Pop Organ
"	"

Bank = 2 (user voices bank)

Program	0 timbre user 1 will play
"	1 timbre user 2 will play

Bank = 3 (card bank) the flash card timbres will play

Bank = 4 (groove bank) the grooves will play

Bank = 5 (drawbars bank) the drawbars will play

Bank = 6 (ram bank) the ram timbres will play

Bank = 7 (msp bank) the msp timbres will play (selected through sampling)

In the case of PITCH BEND (or WHEEL) both 1st and 2nd indicate the pitch value of the bend wheel.

2nd: The meaning of this parameter, too, is different according to the type of event that is represented. The range of values of this field is 0-127. In the case of note events, the parameter indicates the speed at which the note was played. In the case of control events, it indicates the amount of such control; for example, the amount of volume (7), reverb (91), chorus (93), expression (11), etc. For the pan-pot (10), value 64 means that the pan is centered, while for smaller values the pan is moved to the left and for greater values it is moved to the right. For the sustain (64), portamento (65), wha-wha (84), soft (67), sustained (66), value 0 means that the effect is Off while value 127 indicates that it is On.

Event: It indicates the type of Note, Control, Program, Pitch Bend, Aftertouch event (there are no exclusive messages since they are recorded only on the MASTER TRACK).

Channel: It is the midi channel where the event was recorded.

Let us now have a look at the functions available in the EDIT pages.

EDIT (page one).

EDIT Position: The F1 and Value +/- buttons can be used to change the position of the sequence and the display will be updated accordingly. Use the Cursor<> buttons to scroll events. If OPTIONS is set on On STEP TRACE in the menu, use the Cursor <> buttons to listen to the notes played. This function is useful to trace parts of the sequence.

EDIT View: It allows you to select only certain types of events. Pressing F2 repeatedly will allow you to select in succession: ALL -> NOTE -> CONTROL -> PROGRAM CHANGE. The display will be updated accordingly.

EDIT Modify: It allows you to change the selected sequence. Press the F6 button to access an edit window; use the Cursor <> buttons to move around the various fields of the event that you want to change; use the Value +/- buttons to change the selected field. Press F10 (Execute) to confirm the operation or F5 (Escape) to cancel it. If, for example, you want to change the timbre, select the event marked Progr in the Event field; press F6 (MODIFY), use the Cursor <> buttons to access the related box on field 1st; use the Value +/- buttons to select the new timbre, press F10 (Execute). For example, if you want to move a note, simply replace its Position field with the new position.

EDIT Insert: This function allows you to insert a single event in any position. Press the F3 (INSERT) button to access an editing window. The Event field is selected by default. Use the Value <> buttons to

select the event type you want to insert. Use the Cursor <> buttons to move around the various event fields to edit parameters. Press F10 to confirm the operation, or F5 to cancel it.

EDIT Delete: This function deletes a single event; press F4 (DELETE) to open the window (non editable) containing the selected event. If you confirm by pressing F10, the event will be deleted. Press F5 to cancel the operation and the event will not be deleted.

EDIT (seconda pagina):

Press Page > to access the second edit page. Two important functions can be accessed from the second page; FADER and LOGICAL.

EDIT FADER: This function allows you to insert controls continuously so that you can give expression to the sequence. This function is useful if, for example: You want to obtain a crescendo or fade an orchestra instrument. You want to move the Pan-pot continuously Left-center-Right to simulate movement. You want to change the filter of an instrument gradually (Cut-Off) in order to obtain, for e.g., effects such as Wha-Wha.

1 1 1			EDIT (2 of 2)				MODIFY
	Posit.	Length	2nd	1st	Event	Chn	
View	1 1 1		0	Bank	Ctrl	3	
ALL	1 1 1			90	Progr	3	
	1 1 1		0	Vol.	Ctrl	3	
	1 1 1		64	Rev.	Ctrl	3	
FADER	1 1 1		64	Cho.	Ctrl	3	
	1 1 1		64	Pan	Ctrl	3	
	1 1 1	1 3 17	24	D_3	Note	3	
LOGICAL	1 1 1		0	Bank	Ctrl	4	
	1 1 1		5	Progr	Ctrl	4	
	1 1 1		0	Vol.	Ctrl	4	
	1 1 1		64	Rev.	Ctrl	4	
Escape	1 1 1		64	Cho.	Ctrl	4	
	1 1 1		64	Pan	Ctrl	4	

Let us make an example so that the use of this function becomes clearer: Say you want to obtain a volume crescendo from 1 to 96 and then a decrescendo from 96 to 20. Let us suppose that the crescendo should go from bar 31 to bar 33; the decrescendo from bar 33 to bar 36. Use the Cursor <> buttons to access the various function fields.

- Use the Value -/+ buttons to select "VOLUME" from the EVENT box.
- In the three position boxes (1st POSIT, 2nd POSIT, 3rd POSIT) enter the following settings:
 - 1st Position** [31 1 1]. Crescendo start position
 - 2nd Position** [33 1 1]. Decrescendo start position (in this position the volume reaches its maximum value)
 - 3rd Position** [36 1 1]. Fading end position.
- In the three Value boxes (1st VALUE, 2nd VALUE, 3rd VALUE) enter the following settings:
 - 1st VALUE:** 1. Crescendo start volume value.
 - 2nd VALUE:** 96. Crescendo end and decrescendo start volume value.
 - 3rd VALUE:** 20. Decrescendo end value.

Note. If you want to perform only one crescendo or decrescendo, press the Value -/+ buttons together and set the 3rd VALUE field on Off. Interposed arrows between the VALUE fields indicate whether you are performing a crescendo or a decrescendo.

- In the STEP box, select the number of steps for which each volume crescendo or decrescendo is to take place. Use the Value -/+ buttons to change the value. In the REPEAT box, select the number of bars for which the entire FADER cycle is to be repeated. If, for example, you use the Value -/+ buttons to enter value 2, the volume crescendo and decrescendo will take place for two consecutive bars.
- Press F10(Execute) to confirm the operation. Press F5(Escape) to return to the EDIT page EDIT.

EDIT Logical: Press F4 to access the LOGICAL function. This is a quite complicated but powerful function. It allows you to edit in a complete manner groups of events of the running track. Let us start by describing the various fields making up the page (use the Cursor <> buttons to access them).

COND:

Condition relating to the operational range (top left-hand side of the display). It selects the temporal interval that will be affected by the edit function. If you select All with the Value +/- buttons, the changes will be applied to the entire track. If you select Equal, only the events with position visualized in RANGE OP (operational interval) will be affected. The position can be changed by using the Cursor <> buttons to select the desired box and then pressing the Value +/- buttons accordingly. If you select Internal, only the events with position falling inside the position values shown in RANGE OP will be affected. The events with position outside this interval will not be changed. Therefore, the changes will affect all the events starting from the position shown at the top of the RANGE OP box and down until the events in the position shown at the bottom of the same box. If you select External, the changes will affect only the events in the position outside the operational interval, while the events falling inside the interval given in RANGE OP will not be changed.

STATUS: This box allows you to select the event types that will be affected by the changes. They are ALL, NOTE, PROGRAM, CONTROL, PITCH WHEEL(BEND), AFTERTOUCH.

COND: Condition relating to the event fields.

1st:

All: the operation will affect the events, regardless of the value (see above). For example, in the case of STATUS NOTE, all the notes will be considered, in the case of STATUS PROGRAM, all the timbres will be considered.

Equal: the operation will affect only one event type shown and editable in the FROM field. For example, in the case of NOTES, only the note shown in the FROM field will be changed, in the case of CONTROL, the operation will affect only the control with the number shown in the FROM field. If, for example, the number shown is 7, the operation will affect the volume; if, instead, the number shown is 1, the operation will affect modulation.

Internal: The operation will affect only the events with values falling inside the editable interval given by FROM and TO. If the STATUS is NOTES, only the notes inside the interval will be changed.

External: The operation will affect only the events with values falling outside the editable interval given by FROM and TO. If the STATUS is NOTES, all the notes falling inside the interval will be excluded.

2nd: The same considerations made for field 1st hold true, except that the conditions All, Equal, Internal, External refer to the 2nd value of the event (second byte). For example, in the case of notes, 2nd is the velocity; in the case of control, 2nd normally indicates the amount of control, for example the amount of reverb if 1st = 91. For example, Internal can be used to select notes where the dynamics falls inside a given value (shown in the related FROM TO box).

Chann: Conditions relating to the midi channel field. The All, Equal, Internal, External conditions will affect events represented by 1st and 2nd which will also satisfy the condition on the midi channel as set in the related box.

Len: Condition relating to the duration of notes. This condition can be accessed and is valid only if NOTES is selected on the STATUS. If ALL is selected, this condition will in any case affect only the notes.

LOGICAL operations: Once the conditions relating to intervals and events have been selected as described above, one can decide what operations to perform.

OPERATIONS on events (RESULT fields): All events satisfying the conditions relating to the operational interval and the conditions relating to their values can be transformed as follows:

STAT: Status transformation. The status will be transformed into the one shown in the left-hand box; therefore, a note event can become, for example, a control event. If the status is not changed, there will be no transformation of events, i.e. notes will remain notes, etc. We suggest not to change the result status unless specific sound effects are desired.

1 (1st): By selecting this field you can perform operations such as addition subtraction equality. For example, in the case of STATUS NOTES, you can transpose the notes by one octave upwards by entering [+] (addition) and entering 12 (amount that will be added to the notes) in the value box. If None is selected, no operation will be performed on the first byte of the event.

2 (2nd): By selecting this field you can perform operations such as addition subtraction equality. For example, in the case of STATUS NOTES, you can change the velocity of the notes downwards by 10 points by entering [-] (subtraction) and value 10. If None is selected, no operation will be performed on the second byte of the event.

CH (Channel): You can change the midi channel of the events by entering for instance the value 16. All the events that satisfy the set conditions will take up midi channel 16. If None is selected, no operation will be performed on the channel of the event. Contrarily to the other functions, this one does not allow you to choose any of the three operations -/+/=; in fact, the = sign is fixed. You can only choose the midi channel.

LEN (length): This is valid only for note events. For example, you can “stretch” the duration of a note by one quarter by entering [+] and [0 1 0]. You can give the notes a fixed duration of 2 quarters with [=] and [0 2 0]. If None is selected, no operation will be performed on the duration of the note event.

QUANTIZE: Use F6 to select the quantization value and press F10 (Execute): the events will be quantized.

EXTRACT: Press F7 for selection and then F10 to execute: the events will be moved from the running track to the first available track.

COPY: Use F8 to select the function and then use F10 to enter the end position in the COPY POSITION box: starting from the position set in COPY POSITION, all the events will be copied.

DELETE: Use F9 to select the function and then press F10: all the events will be deleted. The Quantize, Extract, Copy, Delete operations take place according to the conditions set in the upper part of the display and they do not take into account the Result part. The Copy function, as mentioned earlier, takes into account also the parameter that is in the lower part of the “Copy Posit” display.

Example. Let us suppose you are editing the notes of a

The screenshot shows a software interface for the 'DELETE' function. On the left is a vertical column of buttons: 'NOTE', 'CONTROL', 'P.CHANGE', 'PITCH', and 'Escape'. The 'NOTE' button is highlighted. In the center, a box titled 'DELETE' contains the text 'DELETE TRACK' and 'TRACK 01'. Below this, it shows 'FROM: 1 1 1' and 'TO : 1 1 1'. On the right side of the interface is another column of buttons: 'ALL', 'LAST RECORD', 'LINK', 'DEFRAG', and 'Execute'. The 'Execute' button is highlighted.

track on the basis of the following characteristics:

- They are in the interval going from bar 32 to 64.
- They are different from C_2.
- Their velocity ranges from 32 to 48.
- They are on midi channel 14.
- Their duration is _.

To select the notes with the above-mentioned characteristics:

- Go on COND (top left) and select **Internal**:
- Go on RANGE OP and set [32 1 1] in the upper part of the box and [65 1 1] in the bottom part of the box.
- Set NOTES in the STATUS box.
- In the COND 1st field select the **External** condition and set C_2 in the FROM section and again C_2 in the TO section.
- In the COND 2nd field select **Internal** and set 32 in the FROM field and 48 in the TO field.
- In the CHANN field select Equal and enter 14 in the FROM field.
- In the LEN field select Equal and enter [0 1 0] in the FROM field.

At this point you have set the desired conditions on the notes. You may now perform the various editing operations as described above.

COPY/MOVE: The COPY/MOVE function allows you to copy or move parts of a track or an entire track to other positions on the same track or to a different track. Access the function by pressing the F8 button. Two windows will appear in the center of the COPY/MOVE page. The upper window refers to the source track, the lower one to the end track. You can access the various editing fields by pressing the Cursor <> buttons and you can set values by using the Value -/+ buttons. Set the source track on the source track window together with the track interval that will be copied/moved FROM -> TO. On the end track window, set the track and the starting point where the source track interval will be positioned after copying or moving. When you access the menu, the entire selected running track is selected by default as source track and the ALL box is highlighted. This implies that all midi type-events will be copied or moved. You may select only certain events by pressing the buttons F1 (NOTES), F2 (CONTROL), F3 (PROGRAM CHANGE), F4 (PITCH BEND). Press F9 to choose between copying or moving the events. Press F10 to execute or F5 to exit the operation.

Examples. Suppose you have recorded a few drum beats on a track. Your objective is to repeat the beat so as to obtain a complete sequence. To do so, the COPY function can be used more than once.

Suppose you have recorded a track that is shifted by one bar compared to the other tracks. By moving the track to the position anticipated by one bar, you can bring the track concerned back into "phase".

By copying notes that are positioned close together, you can create an "echo" effect.

NOTE	COPY/MOVE	ALL
CONTROL	SOURCE: TRACK_01	
P.CHANGE	FROM: 1 1 1	
PITCH	TO : 1 1 1	
Escape	DEST. : TRACK_01	MODE
	TO : 1 1 1	COPY
		Execute

DELETE It allows you to delete entirely or partially the events of the selected track. Press the F7 button to access this function. A window will be highlighted in the middle of the display. In this window you can enter the interval that will be deleted FROM -> TO. When you enter the menu, the entire track is selected by default and the ALL box is highlighted. This means that all midi type-events will be deleted. You may select only certain events to be deleted by pressing F1 (NOTES), F2 (CONTROL), F3 (PROGRAM CHANGE), F4 (PITCH BEND). Press F7 LAST RECORD if you want to delete only the last recording.

DELETE LINK: Press F8 to select/deselect the DELETE LINK mode. Selecting this function will allow you to link the events that are positioned at the two ends of the deleted interval, so that you will not have a “hole” in the deleted interval. Press F10 to execute the deletion but, before that, confirmation will be requested by means of the message “Are you sure?”. Press F5 to exit without deleting.

DEFRAG: When you perform several deletions, the memory space is not freed completely. Therefore, you might be “short” of memory even if your sequence is a short one. Press F9 (DEFRAG) to “format” the memory and free the spaces lost through deletion.

FUNCTION: When FUNCTION is selected by pressing the F4 button, new functions of the sequencer become operational such as OPTIONS, MIDI FILTER, MASTER TRACK LOAD/SAVE, DEMIX, MIXDOWN, VELOCITY, TRANSPOSER.

OPTIONS: Access this menu by pressing the F2 button after you have entered the FUNCTION mode by pressing F2. Press the F5 button (Escape) to exit the menu.

METRONOME: Press F1 to switch the metronome On/Off during recording.

MODE RECORD: Press F1 to select the two recording modes Overdub and Replace (see RECORD).


RECORD PRECOUNT: By repeatedly pressing F3 you may select the bars that will pass between the moment the recording is launched and the moment it actually starts. You can choose from 0 to 5 precount bars. The precount is shown on the POSITION box with a negative sign (-). The precount is interrupted when the first event arrives. When in the SYNCSTART mode, it is automatically switched off since it is not necessary.

CHASE EVENTS: When this function is On (F4 button), regardless of the position from which the sequence starts, the CONTROL CHANGE and the PROGRAM CHANGE of the sequence are transmitted in any case, even when recorded in previous positions. If, for example, the starting point of a sequence is set at number 20 and the controls are set at bar 1, the sequencer will immediately send all the controls that are present from the beginning of the sequence up to bar 20. This functions allows the notes to play in the set manner, regardless of the starting point of the sequence.

RESET STOP: If this function is On (F6 button), at every stop the suspended notes are deleted and the pitch bend is reset.

STEP TRACE: If this function is On (F8 button), you can use the Cursor<> buttons to move around the EDIT menu and play back the recorded notes while scrolling them. This function is useful to trace parts of the sequence.

TRACK NAME: Use the Cursor<> buttons to scroll through the names of the tracks shown in the middle of the display. Press the F7 button if you want to change the name of a track with a selected number. This way you will access the usual name editing window. The procedure to edit a new name is the same as the one already described in the NAME paragraph. Press F10 (Execute) to save, press F5 (Escape) to exit.



MIDI FILTER: Before describing in detail the various menu functions, here is some information about the musical parts and the channels on which such parts play. The sequencer is capable of managing up to 16 musical parts for each track. Every part is associated with a midi channel. If a sequence is recorded using the styles of the musical instrument, the instrument parts will be

recorded on channels set in the MIDI channel Tx menu. With MIDI SETUP set on “General”, by default the part -> channel association is the following (recommended one):

Part		Channel
Preset	(right)	1
2nd Voice	(right)	2
Lower1	(left)	3
Lower2	(left)	4
Bass	(left)	5
Chord1	(left)	6
Chord2	(left)	7
Chord3	(left)	8
Groove	(left)	9
Drum	(left)	10
Chord4	(left)	11
Chord5	(left)	12
Program voice1	(right)	13
Program voice2	(right)	14
Program voice3	(right)	15
Program voice4	(right)	16

By playing the keyboard on the left hand side of the split, the left parts are switched on, while by playing on the right hand side the right parts are switched on. For example, on the left hand side in the stop mode only the two lowers play whereas, if you keep start pressed and set a chord, the drums will play together with the other parts of the style. The preset plays on the right hand side but if you enter the program, the parts of the program or the 2nd voice will play if you access by pressing the related button. If a channel is switched off, it will not be recorded by the sequencer. The MIDI FILTER can be used to filter the events and the incoming and outgoing channels (by default no event or channel is filtered). In order to filter the events so that they are not recorded, you must first use the Cursor <> or Page <> buttons to select the event box on the IN column (incoming). You can filter:: Note, Control Change, Program change, Pitch Bend, Aftertouch, Exclusive Messages. In order to switch the filter on, press the F10 button to make the dot appear in the box. The procedure is the same also for the channels. If you want to record an event or a channel without playing it and exit at the midi out, the filter must be put in the OUT column.

Special mention must be made for the clock IN OUT boxes.

In this case, an empty box means that the clock is switched off. When the clock is set on IN, the clock inside the sequencer is switched off. It has to be powered from the outside by means of a midi or by switching on the internal mode (Start, Fills, etc.). If the clock is set on OUT, both midi events and the midi clock will pass through the midi out. If the sequencer IN clock is switched on and so is the MIDI out clock (see MIDI CLOCK SOFTTHRU Menu), when the style is switched on by pressing the Start button, the style clock out will also start the recording. On the contrary, if the MIDI FILTER clock out and the MENU MIDI CLOCK SOFTTHRU clock in are switched on, also the internal style will automatically start when the recording.

DEMIX: This function allows you to pick out every single recorded channel from a track and to transfer it to other tracks so that, in the end, every track will have only one channel associated to it. To demix a track from the main menu, select the track by using the Cursor<> or Page <> but-

tons and then press F4 (FUNCTION) followed by F7 (DEMIX). Example: Suppose you have recorded an internal style on track 01 and you want to change the bass round. By using the Demix function, the events on the bass channel will be transferred to a separate track (e.g. track number 5 since by default the bass plays on channel number 5). At this point, select track 05 which contains the information about the bass alone. The Chan. column highlights the number of the demixed channel. The track can be deleted and recorded again, it can be edited, etc. and you can be sure that the operations will concern only the bass.

MIXDOWN: This function allows you to mixdown the contents of one or more tracks unto a track. The original midi channels of the events will be maintained.

To select the tracks that you want to mix, use the Cursor <> or Page <> buttons, then press F8 (MIXDOWN) to show that the track will be mixed. Note. Only initialized tracks (status 'i') can be selected.

When you press MIXDOWN, an 'M' will appear in the status column. Once all the tracks to be mixed have been selected, press F10 (Execute). A window will appear in the middle of the display; use the Value -/+ buttons to choose the end track. By pressing F10 (Execute), all the tracks that have been selected for mixage will be mixed down unto the end track. The original tracks will be lost forever.

VELOCITY/TRANSPOSER: This function affects only note events.

It allows you to:

a) Transpose notes (in semitones) so that you may for example change the tone of a sequence or re-establish the natural interval of a musical instrument.

b) Change the velocity, i.e. the volume in general of each note, to achieve improved performance. Access the menu by pressing F4 (FUNCTION) and then F9 (VELOCITY/TRANSP.). The display will show the selected running track on which changes will be made and the FROM -> TO position locators outlining the temporal interval where the operation will be performed.

The two fields VELOCITY, TRANSPOSER are in the lower part of the display. Use the Cursor <> buttons to select the locators and the VELOCITY or TRANSPOSER controls. Controls can be accessed directly also by pressing the F5 button. Use the Value -/+ buttons to change the values.

Example:

If you set	FROM:	1 1 1
	TO:	4 1 1
VELOCITY:		-23
TRANSPOSER:		+12

The first 3 bars of the running track will be raised by one octave, while the velocity will be lowered by 23 (less volume for every note).

MASTER TRACK: The MASTER TRACK is the track on which all bar, signature and exclusive messages controlling parameters such as effects, lyrics, etc. are recorded. Press F4 (FUNCTION) and then F4 (MASTER TRACK) again to access the master track from the main menu. The recorded events are shown in the center of the display.

Position: gives you the position of the events (bars, quarters, steps)

Event:

Tempo: performance tempo

Signature: musical division

ExcMsg: exclusive messages of other producers

Solton:	Solton exclusive messages
Part:	name of the musical part
Lyrics:	lyric events (rows of letters)

How to edit exclusive messages.

An exclusive message is made up of a set of bytes with values ranging between 0 and 127. Data in the sequencer are given in hexadecimal notation in the 00h-7fh range. For the list of Solton exclusive messages, please refer to the annex in the Instructions Handbook. Press F6 (EXCL.MSG.) to enter an exclusive message. At this point you will access a window with 24 boxes which will allow you to enter up to 24 bytes (Solton messages have a smaller number of bytes). The position of the message is given on the top left-hand corner; you may change this position by pressing the Value +/- buttons. For every box you may enter or change a message byte, using the Cursor<> buttons to select and the Value +/- buttons to make changes. By pressing both Value +/- buttons together you will cancel the content of the selected box.

NOTE. The boxes must be filled one after the other, without leaving blank boxes.

Solton exclusive messages are already part of the instrument and can be recognized by the fact that the first data byte (ID) is 26h(38).

The general form of a Solton exclusive message that can change the instrument parameters is:

F0h, 26h, 7Bh, parameter code value_1, value_2, .. ,value_n, F7

Values F0h and F7h are entered automatically by the sequencer.

Let us see some examples:

By entering 26h in the first box and 7bh in the second box, the third box gives you the message parameter code.

Third box: 00h reverb type
01h chorus type
02h reverb level
06h delay type
11h distorsor type
" "

For the complete list, please refer to the annexes in the Instructions Handbook.

From the fourth box onwards, you must enter one or more values according to the parameter in the third box. For example, by entering 26H 7BH 00H 00H, the instrument will set the reverb type 00h = box1.

By entering 26H 7BH 00H 07H you will set reverb number 07h(Hall2).

By entering 26H 7BH 06H 02H you will set delay number 02h(Delay3).

By entering 26H,7Bh,0Bh,00h as first 4 bytes, the fifth byte will indicate the part and the sixth effect that the sound will take up on that part.

Example (effect allocation).

In general: F0H, 26H, 7BH, 0BH, 00H, Part, Effect, F7H

By entering in the boxes 26H 7BH 0BH 00H 00H 02h, the distorsor will go on part 0 (See table below).

Part

0	Preset (right)
1	2nd Voice (right)
2	Lower1 (left)
3	Lower2 (left)
4	Bass (left)
5	Chord1 (left)
6	Chord2 (left)
7	Chord3 (left)
8	Groove (left)
9	Drum (left)
10	Chord5 (left)
11	Program voice1 (right)
12	Program voice2 (right)
13	Program voice3 (right)
14	Program voice4 (right)

Effect	00h	no effect
	01h	Leslie
	02h	Distorsor
	03h	Chorus
	04h	Delay
	05h	Delay + Chorus
	06h	Distorsor + Chorus
	07h	Distorsor + Delay
	08h	Distorsor + Delay + Chorus

Press F10 to save the message, F5 to cancel the operation. NOTE. The message is always added to the master track; therefore, if you want it to replace another message, you will first have to delete the old one.

Master track DELETE EVENT: Pressing F4 will immediately delete the selected event (without confirmation request) from the master track.

Master track INS/MOD TEMPO: It allows you to insert/modify tempo events. Press F2 to open the edit window. Use the Cursor <> buttons to access the Position and Value fields, and the Value -/+ buttons to perform changes. Press F10 to execute, F5 to cancel.

Master track INS/MOD SIGNATURE: It allows you to insert/modify signature events. Press F3 to open the edit window. Use the Cursor <> buttons to access the Position and Value fields, and the Value -/+ buttons to perform changes. Press F10 to execute, F5 to cancel.

Master track LYRIC: Press F8 to access the LYRIC page where you can insert lyric events in the

sequence. The lyric events available in many MIDIFILES contain the text of a song and if they are inserted into the sequence on a syllabic basis, you will have a KARAOKE-type effect when you play it back in the PLAY SONG mode.

LYRIC INSERT/MODIFY: It allows you to insert/modify lyric events. Press F2 to open an edit window where you can select the position; place the cursor to the right of the position and open a new window where you can edit letters. The letter above the cursor can be inserted by using the keyboard or the Value +/- buttons. Some buttons have special functions. The B_1 button allows you to change the letters associated with the keys from small letters to capital letters. The G_5 button is the Carriage Return button shown on the display by an arrow to the right. The F#_5 button selects a number of international signs. The F_5 button deletes the cursor position up to the end of the sentence (this can be done also by pressing the Value +/- buttons together). Use the Cursor <> buttons to move from one letter to the other. Once the sentence is edited, it can be memorized in the lyric event by pressing F10; press F5 to go back to the position field; pressing F5 again will cancel the operation.

LYRIC AUTOMATIC: It allows you to insert lyric events automatically, changing the notes of a selected channel of the running track into lyric events. You can choose the channel where there is a melodic line that follows the singing. Every lyric event can later be edited to insert a new syllable.

In other words:

Once the track on which changes are to be made has been selected from the main menu, enter the MASTER TRACK.

Press F8 (LYRIC).

Press F6 to select (with Value +/-) the channel where the track melodic line is.

Press F3 (AUTOMATIC).

At this point, position the locators From and To in the set interval.

Press F10 to confirm the operation. By doing so, the notes of the selected track interval will be copied on the MASTER TRACK as lyric events.

At this point, empty lyric events will be made available for editing with INSERT/MODIFY as previously described.

LYRIC DELETE EVENT: Pressing F4 (DELETE EVENT) will delete the lyric event that was previously selected with the Cursor <> buttons.

NAME PART: It allows you name every part of the sequence. Once the sequence names have been entered, the name will appear in the POSITION box of the sequencer main page.

Example: x.1.1 can be called "Strophe 1", y.1.1 "Strophe 2", and z.1.1 "Refrain" in order to have an automatic reference point. Press F9 to name a part. A window is opened where you can set the initial position of the part and the name of the part itself. Use the Cursor <> buttons to move from one Position value to the other and the Value +/- buttons to change the values. Once the position has been chosen, place the cursor on the default name "Part". Another window will automatically open so that you can give a new name to the part. Syllables are selected by using the Value +/- buttons or by using the keyboard. If the Value +/- buttons are used, use the Cursor <> buttons to move along from one syllable to the next. Press F10 to confirm the operation, F5 to exit.

VIEW: It allows you to choose the type of event to show in the MASTER TRACK menu. Press F6 (VIEW) repeatedly to select the events. ALL : all events are displayed.

LYRIC: only lyric events are displayed.

PART : only part name events are displayed.

TEMPO: tempo and signature are displayed.

EXCL : exclusive messages are displayed.

OPTIONS: Press F4 to enter the FUNCTION mode and then F2 to access this menu. Press F5 (Escape) to exit the menu.

METRONOME: By pressing F1, the metronome is switched on/off during the recording stage.

MODE RECORD: By pressing F1, the two recording modes, Overdub and Replace, are selected (see RECORD).

RECORD PRECOUNT: By repeatedly pressing F3 you select the bars that must elapse between the moment in which the recording command is given and the moment in which the recording actually starts. You can have from 0 to 5 precount bars. The precount is displayed in the POSITION box, marked with a negative sign (-). The precount is interrupted when the first event starts. In the SYNCSTART mode it is automatically switched off since it is not required.

CHASE EVENTS: When this function is On (F4 button), regardless of the position from which the sequence starts, the CONTROL CHANGE and the PROGRAM CHANGE of the sequence are transmitted in any case, even if they were recorded in previous positions. If, for example, the starting point of a sequence is set at number 20 and the controls are set at bar 1, the sequencer will immediately send all the controls that are present from the beginning of the sequence up to bar 20. This functions allows the notes to play in the set manner, regardless of the starting point of the sequence.

RESET STOP: If this function is On (F6 button), at every stop the suspended notes are deleted and the pitch bend is reset.

STEP TRACE: If this function is On (F8 button), you can use the Cursor<> buttons to move around the EDIT menu and play back the recorded notes while scrolling them. This function is useful to trace parts of the sequence.

TRACK NAME: Use the Cursor<> buttons to scroll through the names of the tracks shown in the middle of the display. Press the F7 button if you want to change the name of the track with a selected number. This way you will access the usual name editing window. The procedure to edit a new name is the same as the one already described in the NAME paragraph. Press F10 (Execute) to save, F5 (Escape) to exit.

LOAD/SAVE: A sequence can be imported from outside (disk), provided it is in a midi file format. The instrument is capable of interpreting the midi file format (see SONG PLAY section of the Instructions Handbook). During the LOAD phase, the midi file (MID extension) is automatically translated into a format that the sequencer can read and it is loaded in the memory. Therefore, it can be edited for changes, additions, deletions by using the sequencer's functions. Once the sequence imported through LOAD or recorded from zero has been edited, it can be saved in the midi file format. To this end, the SAVE function is used. Once saved on disk, the sequence can be reproduced (by accessing the SONG PLAY menu).

In detail:

LOAD: Access the function from the main menu by pressing F4 (FUNCTION) and then F6 (LOAD/SAVE). You will access a page on the display with the following arrangement: The midi files directory is in the center of the display. If the HARD DISK is selected, the directory refers to the midi files that are in the Folder that is selected and shown in the upper part of the display. For example, if HARD [03 Newfold] is shown, the files are those belonging to folder number 3 named Newfold. If Floppy Disk is shown, the files are those belonging to the main directory of the floppy. Use the numeric buttons 0-9 to change Folders; use the Page <> buttons to select the Floppy from the Hard Disk and vice versa. If you change a diskette in the floppy and you want to update the display so that it shows also the contents of the new diskette, press F4 (Dir) because updating in this case is not automatic. To select the midi file that has to be loaded, use the Cursor <> buttons to change page; use the Value -/+ buttons to move between files. Loading modes are highlighted in the MODE box which can be changed by pressing F3. They are:

REPLACE: The midi file will replace any sequence that is in the memory (this sequence will be deleted). In this case press F1 (Load) and the selected midi file will be loaded in the memory, deleting everything else that was already in the memory.

MERGE: The midi file will merge with the sequence that is already in the memory. Once the MERGE mode is set, a window appears in the middle of the display. You can select the position (by using the Cursor <> and Value -/+ buttons) where the midi file will be “hooked” unto the already-existing sequence. This function can be used to merge several midi files by selecting their positions accordingly. If you want the midi files to play in the proper manner, we recommend that you use the Merge function for midi files saved in 0 format (i.e. made up of one single track). Once the midi files have been loaded in the memory, use the Demix function to assign one track to every channel. To load the selected midi file, set its position and then press F10. After the loading procedure, the sequencer will automatically return to the main menu. The tracks containing midi files will take up the “i” status; if the midi file is in the multitrack format, a reproduction channel (Chan. column) will be automatically set for every track. Instead, the tempo and signatures of the midi files, and any lyrics or exclusive messages, will be recorded on the MASTER TRACK.

SAVE: A recorded or loaded sequence can be saved on disk in the midi file format by using the SAVE function. The SAVE procedure is similar to the LOAD one, except that F6 (SAVE) must be pressed instead of F1. Once a name has been assigned to the sequence that will be saved, press F10 (Execute) to confirm the operation. Press F5 (Escape) to exit the menu without performing any operation. We recommend that you save the sequence not only at the end of your work session but also before performing risky operations such as Delete, Mixdown, Copy/Move. In this way, should any of these operations not give you the desired results, you can always use LOAD to reload your original sequence. After saving, press F5 to return to the main menu.

VOICES BANK 1

GRAND PIANO	1	CONTRABASS	44	SAW 5TH	87
ROCK PIANO	2	TREMOLO STR	45	FM LEAD	88
UPRIGHT	3	PIZZICATO	46		
HONKY TONK	4	HARP	47	FANTASY	89
RODES PIANO	5	TIMPANI	48	WARM	90
DX PIANO	6			SCORE	91
HARPSICHORD	7	PHILARMONIC	49	SPACE	92
CLAVINET	8	SLOW STRING	50	DARK	93
		SYNSTRINGS1	51	METAL	94
CELESTA	9	SYNSTRINGS2	52	HALO	95
GLOCKEN	10	CHOIR 1	53	SWEEP	96
MUSIC BOX	11	CHOIR 2	54		
VIBRAPHONE	12	SYNVOICE	55	ICE RAIN	97
MARIMBA	13	ORCH. HITS	56	SOUNDTRACK	98
XYLOPHON	14			CRYSTAL	99
BELLS	15	TRUMPET	57	ATMOSPHERE	100
SANTUR	16	TROMBONE	58	BRIGHTNESS	101
		TUBA	59	GOBLIN	102
LESLIES	17	MUTE TRUMPT	60	ECHODROPS	103
JAZZ ORGAN	18	FRENCH HORN	61	STAR THEME	104
ROCK ORGAN	19	BRASS1	62		
CHURCH ORG.	20	SYNBASS1	63	SITAR	105
THEATRE ORG	21	SYNBASS2	64	BANJO	106
MUSETTE 1	22			SHAMISEN	107
HARMONICA	23	BLOWED SAX	65	KOTO	108
ACCORDION	24	ALTO SAX	66	KALIMBA	109
		ROCK SAX	67	BAG PIPE	110
FLAMENCO	25	TENOR SAX	68	FIDDLE	111
FOLK	26	OBOE	69	SHANAI	112
JAZZ	27	ENGL. HORN	70		
CLEAN	28	BASSOON	71	TINKLE BELL	113
MUTED	29	CLARINET	72	AGOGO	114
OVERDRIVE	30			STEEL DRUMS	115
ROCK LEAD	31	PICCOLO	73	WOODBLOCK	116
HARMONICS	32	FLUTE	74	TAIKO	117
		RECORDER	75	MELOTOM	118
ACOUSTIC	33	ANDES PIPE	76	SYNT DRUM	119
FINGERED	34	BOTTLE	77	REVERSE CYM	120
PICKED	35	SHAKUHASHI	78		
FRETLES	36	WHISTLE	79	FRET NOISE	121
SLAP 1	37	OCARINA	80	BREATH	122
SLAP 2	38			SEASHORE	123
SYNBASS1	39	SQUARE LEAD	81	BIRD	124
SYNBASS2	40	SAW LEAD	82	TELEPHONE	125
		CALLIOPE	83	HELICOPTER	126
VIOLIN	41	WHA LEAD	84	APPLAUSE	127
VIOLA	42	PLATE LEAD	85	GUN SHOT	128
CELLO	43	VOX LEAD	86		

VOICES BANK 2

CONCERT	1	OCTASTRING1	44	HOUSEBAS	87
DIGIPIANO	2	OCTASTRING2	45	TECNOBAS	88
HOUSE PIANO	3	MARCATO STR	46		
STAGE PIANO	4	ORCHESTRA	47	2ND PERC.	89
ELECTRO PNO	5	SLOW ARCOS	48	3RD PERC.	90
FUNKY PIANO	6			CLICK	91
FM PIANO1	7	STRING ENS.	49	EL. ORGAN 1	92
FM PIANO2	8	DIGISTRINGS	50	EL. ORGAN 2	93
		LAAAH	51	EL. ORGAN 3	94
MALLET	9	MMMH	52	HARD ORGAN	95
CHIMES	10	TOOOH	53	HOUSE ORGAN	96
HAMMER	11	UUUH	54		
DAMP VIBES	12	AAAH	55	POWER GUIT.	97
MALIMBA	13	UAP & BOOM	56	FUNKY	98
CARILLON	14			SOLID BODY	99
TINKLES	15	TIJUANA	57	STRATO	100
WINDCHIMES	16	CORNET	58	TREMOLO GUI	101
		TUBA & BASS	59	TELECAST	102
ROTOR B3	17	MILES MUTED	60	ROCK STOPS	103
POP ORGAN	18	FLUGELHORN	61	WHA GUITAR	104
DRAWBARS	19	BRASS 2	62		
POSITIVE	20	GROWBRASS1	63	HAWAIIAN	105
MUSETTE 2	21	FX BRASS	64	MANDOLIN	106
ORGANETTO	22			DARK JAZZ	107
CASSOTTO	23	SOPRANO SAX	65	BOUZUKI	108
BANDONEON	24	CIRCUS SAX	66	PEDAL STEEL	109
		ALTOSOFT	67	POP GUITAR	110
SPANISH	25	GROWL SAX	68	FISA 8'	111
COUNTRY	26	MARIACHI	69	SAX BLOW	112
PLUCKED	27	GROWBRASS2	70		
60'S MUTED	28	BLARE	71	FX 1	113
STOPPED 5TH	29	HORNS	72	FX 2	114
BLUES LEAD	30			FX 3	115
12 STRINGS	31	ALTO FLUTE	73	FX 4	116
MELOBAR	32	FIFE	74	FX 5	117
		VOICE FLUTE	75	FX 6	118
SINUS	33	PAN FLUTE	76	FX 7	119
FUSION	34	ANALOGS	77	FX 8	120
FUNK	35	FLANGER	78		
FM BASS1	36	BRIGHTSAW	79	VOCAL 1	121
FM BASS2	37	WIRING	80	VOCAL 2	122
SYNBAS3	38			VOCAL 3	123
SYNBAS4	39	WOW	81	VOCAL 4	124
SYNBAS5	40	SAW WAVE	82	VOCAL 5	125
		SQUARE WAVE	83	JODLERS	126
SYMPHONY	41	SINUS WAVE	84	SCIENCE-FX	127
VIOLAS	42	POP BASS	85	SCRATCHES	128
GLOCKSTRING	43	UNDERBAS	86		

STYLES BANK A

01A 8BEAT_1
 02A 8BEAT_2
 03A 8BEAT_3
 04A 8BEAT_4
 05A 8BEAT_5
 06A 16BEAT_1
 07A 16BEAT_2
 08A 16BEAT_3
 09A 16BEAT_4
 10A 16BEAT_5
 11A 8BALLAD_1
 12A 8BALLAD_2
 13A 8BALLAD_3
 14A 8BALLAD_4
 15A 16BALLAD_1
 16A 16BALLAD_2
 17A 16BALLAD_3
 18A 16BALLAD_4
 19A LIGHTPOP_1
 20A LIGHTPOP_2
 21A LIGHTPOP_3
 22A POPFUNK_1
 23A POPFUNK_2
 24A POPFUNK_3
 25A HIPHOP_1
 26A HIPHOP_2
 27A HIPHOP_3
 28A EASYRAP_1
 29A EASYRAP_2
 30A TECHNO_1
 31A TECHNO_2
 32A TECHNO_3
 33A HOUSE_1
 34A HOUSE_2
 35A HOUSE_3
 36A DISCO_1
 37A DISCO_2
 38A DISCO_3
 39A DISCO_4
 40A ACIDJAZZ_1
 41A ACIDJAZZ_2
 42A ACIDJAZZ_3
 43A RAP_1
 44A RAP_2
 45A JUNGLE
 46A GRUNGE
 47A R&BGROOVE
 48A SOUL
 49A MOTOWN
 50A R&BLUES_1

51A R&BLUES_2
 52A R&BLUES_3
 53A FUNKY_1
 54A FUNKY_2
 55A FUNKY_3
 56A FUNKY_4
 57A BLUES_1
 58A BLUES_2
 59A SLOWBLUES
 60A ROCK_1
 61A ROCK_2
 62A ROCKBALLAD
 63A ROCKSHUFFLE_1
 64A ROCKSHUFFLE_2
 65A B.B.ROCK
 66A PARTYBEAT1
 67A PARTYBEAT2
 68A JAZZORGAN1
 69A JAZZORGAN_2
 70A BROADWAY
 71A MOONLIGHT
 72A SWING_1
 73A SWING_2
 74A SLOW_1
 75A SLOW_2
 76A WESTERN_1
 77A WESTERN_2
 78A CTRYROCK_1
 79A CTRYROCK_2
 80A CTRYSLOW_1
 81A CTRYSLOW_2
 82A CNTRYPOP_1
 83A CNTRYPOP_2
 84A CNTRYPOP_3
 85A CNTRYFOX_1
 86A CNTRYFOX_2
 87A BLUEGRAS_1
 88A BLUEGRAS_2
 89A CNTRYWALZ1
 90A CNTRYWALZ2
 91A CNTRYBEAT
 92A 5/4
 93A DJANGO
 94A JAMSESSION
 95A GOSPEL
 96A MOVIESONG
 97A NEWAGE
 98A CELTIC_1
 99A CELTIC_2

STYLES BANK B

01B	BIGBAND_1
02B	BIGBAND_2
03B	BIGBAND_3
04B	BIGBAND_4
05B	SLOWDIXIE
06B	CHARLESTON
07B	FOXBALLAD1
08B	FOXBALLAD2
09B	SLOWFOX
10B	FOXTROT_1
11B	FOXTROT_2
12B	QUICKSTEP
13B	POP_60
14B	TWIST_1
15B	TWIST_2
16B	TEX_MEX
17B	ROCK&ROLL1
18B	ROCK&ROLL2
19B	ROCK&ROLL3
20B	BOOGIE
21B	BUGG
22B	SHUFFLE
23B	SLOWROCK_1
24B	SLOWROCK_2
25B	SLOWROCK_3
26B	SLOWROCK_4
27B	BEGUINE_1
28B	BEGUINE_2
29B	BEGUINE_3
30B	BOSSANOVA1
31B	BOSSANOVA2
32B	CHACHA_1
33B	CHACHA_2
34B	SAMBA_1
35B	SAMBA_2
36B	JAZZSAMBA
37B	DISCOSAMBA
38B	SALSA_1
39B	SALSA_2
40B	SALSAFUNK
41B	MAMBO
42B	MERENGUE_1
43B	MERENGUE_2
44B	BOLERO
45B	CUMBIA
46B	BACHATA
47B	GUAJIRA
48B	RUMBA FLAMENCA
49B	SEVILLANA
50B	RANCHER

51B	PASODOBLE1
52B	PASODOBLE2
53B	GIPSY
54B	CARIBE
55B	LATIN DANCE1
56B	LATIN DANCE2
57B	LIMBO
58B	REGGAE_1
59B	REGGAE_2
60B	BAJON
61B	PARTY POLKA1
62B	PARTY POLKA2
63B	BAVARIAN
64B	WALTZ_1
65B	WALTZ_2
66B	WALTZ_3
67B	SLOWALTZ_1
68B	SLOWALTZ_2
69B	JAZZWALTZ
70B	POLKA_1
71B	POLKA_2
72B	POLKA_3
73B	TANGO_1
74B	TANGO_2
75B	TANGO_3
76B	MAZURKA_1
77B	MAZURKA_2
78B	WIENER
79B	MUSETTE
80B	MARCH_1
81B	MARCH_2
82B	OBERPOLKA
83B	OBERWALTZ
84B	HULLY GULLY_1
85B	HULLY GULLY_2
86B	MACARENA
87B	MENEITO
88B	LAMBADA
89B	LETKISS
90B	TARANTELLA
91B	RUMBA NAPOLETANA 1
92B	RUMBA NAPOLETANA 2
93B	SALTARELLO
94B	JIGS
95B	REELS
96B	ROMANTIC
97B	WESTRIDE
98B	BAROQUE
99B	CANCAN

GROOVES

P Ch	Name	Key	Groove	Key	Groove	Key	Groove	Key	Groove
1	Bachata	C1	Bachata						
2	Bolero	C1	Bolero						
3	ChaCha	C1	ChaCha A	C3	ChaCha B	C5	ChaCha C		
4	Cumbia	C1	Cumbia	C4	ChaCha C				
5	Guajira	C1	Guajira						
6	Mambo	C1	Mambo A	C3	Mambo B	C5	ChaCha C		
7	Salsa	C1	Salsa A	C3	Salsa B	C5	Salsa C	C0	ChaCha C
8	Rhumba	C1	Rhumba						
9	Merengue 1	C1	Merengue 1						
10	Merengue 2	C1	Merengue 2A	C3	Merengue 2B				
11	Congas 1	C1	Congas 1						
12	Congas 2	C1	Congas 2						
13	Gipsy	C1	Gipsy A	C3	Gipsy B				
14	Maracas	C1	Maracas						
15	Tambourine	C1	Tamb A	C2	Tamb B	C3	Tamb C		
16	Brush	C1	Brush						
17	House	C1	House A	C2	House B				
18	Rap 1	C1	Rap 1						
19	Rap 2	C1	Rap 2						
20	Rap 3	C1	Rap 3						
21	Techno 1	C1	Techno 1						
22	Techno 2	C1	Techno 2						
23	Ethnic 1	C1	Bachata	F#1	Maracas	D2	Brush	F#3A #4	Congas 1 Rhumba
24	Ethnic 2	C1	Bachata	F#1	Maracas	D2 A#3	Brush Rap 1	F#3 D5	Tamb A Rap 2
25	Groovemix 1	C1	Rap 2	C#2	Gipsy A	F3	Mambo A	A4 C5	Congas 1 Techno 2
26	Groovemix 2	C1	Rap 2	C#2	Gipsy A	F2	Salsa A	A#4 C#6	Rhumba Techno 3
27	Groovemix 3	C1	Techno 2	G#1	Salsa A	C3	Merengue 1	C#4 C#5	Merengue 2A Merengue 2B
28	Groovemix 4	C1	Congas 2	G#1	Congas 1	C3	Gipsy A	E4 A5	Gipsy B House B
29	Groovemix 5	C1	Salsa A	E2	Salsa C	E3	Mambo A	G#4	Mambo B
30	Groovemix 6	C1	Mambo A	E2	Mambo B	G3	Congas 1	B4	Rap 3
31	Groovemix 7	C1	ChaCha A	E2	ChaCha B	G#3 A5	Guajira Bachata	C5 D#6	Bolero ChaCha C
32	Groovemix 8	C1	Cumbia	C#2	House A	D#2 B3	House B Guajira	C3 G#4	Techno 1 Maracas 2
33	Groovemix 9	C1	Rap 1	E2	Rap 2	F3	Rap 3	A4 F5	Tamb B Techno 4
34	Groovemix 10	C1	Rap 1	E2	Rap 2	F3	Congas 1	A4 F5	Tamb B Techno 4
35	Groovemix 11	C1 E3	Tamb A Bachata	E1 A#3	Maracas Rhumba	C2 D5	Congas 2 House A	G#2 E5	Bolero House B
36	Groovemix 12	C1 C4	Merengue 2A Rap 2	C2 D#5	Merengue 2B Tamb A	C#3 F5	House A Snare 1	D#3 F#5	House B Snare 2

DRUM SETS

Standard	Program change 1
24 Crash roll	76 Wood block hi
25 Snare 35	77 Wood block low
26 Fingersnap	78 Cuica 1
27 Slap	79 Cuica 2
28 Spings	80 Triangle 2
29 Scratch up	81 Triangle 1
30 Scratch down	82 Shaker 1
31 Sticks 1	83 Shaker 2
32 Click 1	84 Sticks 2
33 Metronome 1	85 Castagnet
34 Metronome 2	86 Tambourine 2
35 Kick 1	87 Rim shot 2
36 Kick 5	88 Snare 3
37 Rimshot 1	89 Snare 11
38 Snare 33	90 Snare 10
39 Clap 1	91 Stick 4
40 Snare 1	92 Stick 2
41 Standard tom 6	93 Close 2
42 Stick 1	94 Open 2
43 Standard tom 5	95 Reverse
44 Close 1	96 Applause
45 Standard tom 4	97 Belltree
46 Open 1	98 Telephone
47 Standard tom 3	99 Hua
48 Standard tom 2	100 Hay
49 Crash 2	101 Hey
50 Standard tom 1	102 Huu
51 Ride 1	103 Uhh
52 Crash 3	104 Fx 1
53 Bell	105 Fx 2
54 Tambourine 1	106 Arriba
55 Splash	107 Ayombre
56 Cowbell 3	108 Cadera
57 Crash 1	109 Cumbia
58 Vibraslap	110 Sabor
59 Ride 2	111 Salsa
60 Bongo hi	112 Brrr
61 Bongo low	113 Aaah
62 Conga middle	114 Haihai
63 Conga hi	115 Rico
64 Conga low	116 Seashore
65 Timbales hi	117 Pfif
66 Timbales low	118 Jodler 1
67 Agogo hi	119 Jodler 2
68 Agogo low	120 Laser
69 Cabasa	121 Sexwhisp
70 Maracas 1	122 Scratch 1
71 Whistle short	123 Scratch 2
72 Whistle long	124 Scratch 3
73 Guiro 1	125 Scratch 4
74 Guiro 2	126 Scratch 5
75 Claves	

Folk	Program change 9
24 Crash roll	76 Wood block hi
25 Snare 35	77 Wood block low
26 Fingersnap	78 Cuica 1
27 Slap	79 Cuica 2
28 Spings	80 Triangle 2
29 Scratch up	81 Triangle 1
30 Scratch down	82 Shaker 1
31 Sticks 1	83 Shaker 2
32 Click 1	84 Sticks 2
33 Metronome 1	85 Castagnet
34 Metronome 2	86 Tambourine 3
35 Kick 3	87 Rim shot 3
36 Kick 9	88 Snare 7
37 Rimshot 5	89 Snare 2
38 Snare 17	90 Snare 20
39 Clap 2	91 Stick 3
40 Snare 19	92 Stick 1
41 Standard tom 6	93 Close 1
42 Stick 1	94 Open 1
43 Standard tom 5	95 Reverse
44 Close 2	96 Applause
45 Standard tom 4	97 Belltree
46 Open 2	98 Telephone
47 Standard tom 3	99 Hua
48 Standard tom 2	101 Hay
49 Crash 2	101 Hey
50 Standard tom 1	102 Huu
51 Ride 3	103 Uhh
52 Crash 3	104 Fx 1
53 Bell	105 Fx 2
54 Tambourine 1	106 Arriba
55 Splash	107 Ayombre
56 Cowbell 2	108 Cadera
57 Crash 1	109 Cumbia
58 Vibraslap	110 Sabor
59 Ride 2	111 Salsa
60 Bongo hi	112 Brrr
61 Bongo low	113 Aaah
62 Conga middle	114 Haihai
63 Conga hi	115 Rico
64 Conga low	116 Seashore
65 Timbales hi	117 Pfif
66 Timbales low	118 Jodler 1
67 Agogo hi	119 Jodler 2
68 Agogo low	120 Laser
69 Cabasa	121 Sexwhisp
70 Maracas 3	122 Scratch 1
71 Whistle short	123 Scratch 2
72 Whistle long	124 Scratch 3
73 Guiro 1	125 Scratch 4
74 Guiro 2	126 Scratch 5
75 Claves	

DRUM SETS

Acoustic		Program change 10	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Castagnet
34	Metronome 2	86	Tambourine 1
35	Kick 9	87	Rim shot 1
36	Kick 1	88	Snare 1
37	Rimshot 6	89	Snare 15
38	Snare 12	90	Snare 16
39	Clap 2	91	Stick 4
40	Snare 13	92	Stick 3
41	Acoustic tom 6	93	Close 2
42	Stick 1	94	Open 2
43	Acoustic tom 5	95	Reverse
44	Close 1	96	Applause
45	Acoustic tom 4	97	Belltree
46	Open 1	98	Pandero 1
47	Acoustic tom 3	99	Pandero 2
48	Acoustic tom 2	100	Pandero 3
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 3	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Hard Rock		Program change 17	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 1
34	Metronome 2	86	Tambourine 3
35	Kick 11	87	Rim shot 2
36	Kick 12	88	Snare 13
37	Rimshot 3	89	Snare 1
38	Snare 23	90	Snare 4
39	Clap 2	91	Middle 2
40	Snare 5	92	Stick 3
41	Standard tom 6	93	Close 1
42	Stick 2	94	Open 1
43	Standard tom 5	95	Reverse
44	Close 2	96	Applause
45	Standard tom 4	97	Belltree
46	Open 2	98	Telephone
47	Standard tom 3	99	Hua
48	Standard tom 2	101	Hay
49	Crash 2	101	Hey
50	Standard tom 1	102	Huu
51	Ride 3	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 2	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 4	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 3	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Dance		Program change 25	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 3
34	Metronome 2	86	Tambourine 3
35	Kick 22	87	Rim shot 4
36	Kick 5	88	Snare 31
37	Rimshot 6	89	Snare 28
38	Snare 1	90	Snare 8
39	Clap 1	91	Middle 7
40	Snare 3	92	Stick 9
41	Acoustic tom 6	93	Kick 6
42	Stick 1	94	Kick 32
43	Acoustic tom 5	95	Reverse
44	Close 1	96	Applause
45	Acoustic tom 4	97	Belltree
46	Open 2	98	Telephone
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	100	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 3	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 1	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 3	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Techno		Program change 26	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 1
34	Metronome 2	86	Tambourine 2
35	Kick 20	87	Rim shot 5
36	Kick 19	88	Snare 21
37	Rimshot 7	89	Snare 24
38	Snare 27	90	Snare 11
39	Clap 3	91	Kick 21
40	Snare 28	92	Kick 18
41	Standard tom 6	93	Middle 6
42	Stick 9	94	Middle 4
43	Standard tom 5	95	Middle 5
44	Stick 8	96	Applause
45	Standard tom 4	97	Belltree
46	Open 3	98	Telephone
47	Standard tom 3	99	Hua
48	Standard tom 2	101	Hay
49	Crash 2	101	Hey
50	Standard tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Progressive		Program change 28	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 1
34	Metronome 2	86	Tambourine 2
35	Kick 13	87	Rim shot 6
36	Kick 16	88	Snare 2
37	Rimshot 2	89	Snare 1
38	Snare 32	90	Snare 24
39	Clap 2	91	Stick 7
40	Snare 10	92	Stick 6
41	Standard tom 6	93	Kick 15
42	Stick 8	94	Kick 14
43	Standard tom 5	95	Reverse
44	Stick 5	96	Applause
45	Standard tom 4	97	Belltree
46	Middle 5	98	Telephone
47	Standard tom 3	99	Hua
48	Standard tom 2	100	Hay
49	Crash 2	101	Hey
50	Standard tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 3	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 2	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Rave		Program change 29	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 2
34	Metronome 2	86	Tambourine 3
35	Kick 25	87	Rim shot 1
36	Kick 23	88	Snare 27
37	Rimshot 7	89	Snare 11
38	Snare 21	90	Snare 28
39	Clap 3	91	Middle 6
40	Snare 24	92	Stick 5
41	Acoustic tom 6	93	Kick 26
42	Middle 5	94	Kick 27
43	Acoustic tom 5	95	Reverse
44	Middle 4	96	Applause
45	Acoustic tom 4	97	Belltree
46	Middle 3	98	Telephone
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	101	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 2	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Hip Hop		Program change 30	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 3
34	Metronome 2	86	Tambourine 3
35	Kick 29	87	Rim shot 2
36	Kick 24	88	Snare 29
37	Rimshot 6	89	Snare 30
38	Snare 9	90	Snare 10
39	Clap 1	91	Middle 1
40	Snare 8	92	Stick 7
41	Acoustic tom 6	93	Kick 31
42	Stick 3	94	Kick 30
43	Acoustic tom 5	95	Reverse
44	Close 2	96	Applause
45	Acoustic tom 4	97	Belltree
46	Open 2	98	Telephone
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	100	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 3	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 1	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 3	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Fusion		Program change 33	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Castagnet
34	Metronome 2	86	Tambourine 2
35	Kick 9	87	Rim shot 5
36	Kick 17	88	Snare 10
37	Rimshot 3	89	Snare 7
38	Snare 18	90	Snare 5
39	Clap 1	91	Stick 7
40	Snare 11	92	Stick 2
41	Standard tom 6	93	Close 2
42	Stick 3	94	Open 2
43	Standard tom 5	95	Reverse
44	Close 1	96	Applause
45	Standard tom 4	97	Belltree
46	Open 1	98	Telephone
47	Standard tom 3	99	Hua
48	Standard tom 2	101	Hay
49	Crash 2	101	Hey
50	Standard tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 2	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Brush		Program change 41	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Castagnet
34	Metronome 2	86	Tambourine 3
35	Kick 7	87	Rim shot 4
36	Kick 8	88	Brush 1
37	Rimshot 1	89	Brush 3
38	Brush 5	90	Snare 7
39	Brush 2	91	Stick 4
40	Brush 4	92	Stick 3
41	Tom brush 6	93	Close 2
42	Stick 1	94	Open 2
43	Tom brush 5	95	Reverse
44	Close 1	96	Applause
45	Tom brush 4	97	Belltree
46	Open 1	98	Telephone
47	Tom brush 3	99	Hua
48	Tom brush 2	100	Hay
49	Crash 2	101	Hey
50	Tom brush 1	102	Huu
51	Ride brush	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 2	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Orchestra		Program change 49	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Stick 1	79	Cuica 2
28	Close 2	80	Triangle 2
29	Open 1	81	Triangle 1
30	Ride 1	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Fingersnap
34	Metronome 2	86	Pandero 1
35	Kick 9	87	Rim shot 5
36	Kick 28	88	Snare 14
37	Rimshot 4	89	Snare 15
38	Snare 12	90	Snare 16
39	Castagnet	91	Middle 2
40	Snare 6	92	Stick 2
41	Timpani 13	93	Close 1
42	Timpani 12	94	Open 2
43	Timpani 11	95	Reverse
44	Timpani 10	96	Applause
45	Timpani 9	97	Belltree
46	Timpani 8	98	Telephone
47	Timpani 7	99	Hua
48	Timpani 6	101	Hay
49	Timpani 5	101	Hey
50	Timpani 4	102	Huu
51	Timpani 3	103	Uhh
52	Timpani 2	104	Fx 1
53	Timpani 1	105	Fx 2
54	Tambourine 3	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 1	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Symphonic Cymbal	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 3	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Contemporary		Program change 57	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Castagnet
34	Metronome 2	86	Tambourine 3
35	Kick 2	87	Rim shot 2
36	Kick 5	88	Snare 20
37	Rimshot 6	89	Snare 10
38	Snare 13	90	Snare 2
39	Clap 2	91	Middle 2
40	Snare 1	92	Stick 4
41	Standard tom 6	93	Close 2
42	Stick 2	94	Open 1
43	Standard tom 5	95	Reverse
44	Close 1	96	Applause
45	Standard tom 4	97	Belltree
46	Open 2	98	Telephone
47	Standard tom 3	99	Hua
48	Standard tom 2	100	Hay
49	Crash 2	101	Hey
50	Standard tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Latin 1		Program change 65	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Castagnet
34	Metronome 2	86	Tambourine 2
35	Kick 4	87	Rim shot 5
36	Kick 1	88	Snare 22
37	Rimshot 3	89	Snare 17
38	Snare 19	90	Snare 1
39	Clap 1	91	Middle 1
40	Snare 20	92	Stick 3
41	Acoustic tom 6	93	Close 1
42	Stick 1	94	Open 2
43	Acoustic tom 5	95	Cowbell 2
44	Close 2	96	Applause
45	Acoustic tom 4	97	Belltree
46	Open 1	98	Telephone
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	101	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 1	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Latin 2		Program change 66	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Maracas 4	78	Cuica 1
27	Timbales middle	79	Cuica 2
28	Pandero 1	80	Triangle 2
29	Pandero 2	81	Triangle 1
30	Pandero 3	82	Shaker 1
31	Surdo 2	83	Shaker 2
32	Surdo 2	84	Sticks 2
33	Cascara	85	Castagnet
34	Metronome 2	86	Tambourine 1
35	Kick 12	87	Rim shot 1
36	Kick 10	88	Snare 23
37	Rimshot 2	89	Snare 13
38	Snare 6	90	Snare 12
39	Clap 1	91	Guira 2
40	Snare 4	92	Guira 1
41	Standard tom 6	93	Tambora 1
42	Stick 3	94	Tambora 2
43	Standard tom 5	95	Tambora 3
44	Close 1	96	Applause
45	Standard tom 4	97	Cowbell 2
46	Open 2	98	Telephone
47	Standard tom 3	99	Hua
48	Standard tom 2	100	Hay
49	Crash 2	101	Hey
50	Standard tom 1	102	Huu
51	Ride 3	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 3	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 4	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 2	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Rock & Roll		Program change 73	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Castagnet
34	Metronome 2	86	Tambourine 3
35	Kick 5	87	Rim shot 1
36	Kick 1	88	Snare 1
37	Rimshot 6	89	Snare 13
38	Snare 34	90	Snare 22
39	Clap 2	91	Stick 4
40	Snare 1	92	Stick 2
41	Acoustic tom 6	93	Close 2
42	Stick 1	94	Open 2
43	Acoustic tom 5	95	Reverse
44	Close 1	96	Applause
45	Acoustic tom 4	97	Belltrees
46	Open 1	98	Telephone
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	101	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 2	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Beat		Program change 121	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Springs	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click	84	Sticks 2
33	Metronome 1	85	Castagnet
34	Metronome 2	86	Tambourine 3
35	Kick 5	87	Rim shot 1
36	Kick 1	88	Snare 11
37	Rimshot 6	89	Snare 18
38	Snare 17	90	Snare 5
39	Clap 2	91	Stick 3
40	Snare 8	92	Stick 2
41	Acoustic tom 6	93	Close 2
42	Stick 1	94	Open 2
43	Acoustic tom 5	95	Reverse
44	Close 1	96	Applause
45	Acoustic tom 4	97	Cowbell 2
46	Open 1	98	Telephone
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	100	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 2	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

Electro		Program change 122	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 1
34	Metronome 2	86	Tambourine 2
35	Kick 21	87	Rim shot 5
36	Kick 21	88	Snare 8
37	Rimshot 7	89	Snare 24
38	Snare 27	90	Snare 11
39	Clap 3	91	Stick 3
40	Snare 28	92	Stick 3
41	Acoustic tom 6	93	Middle 6
42	Stick 9	94	Middle 2
43	Acoustic tom 5	95	Middle 5
44	Stick 8	96	Applause
45	Acoustic tom 4	97	Belltree
46	Open 3	98	Kik 24
47	Acoustic tom 3	99	Reverse
48	Acoustic tom 2	101	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

DRUM SETS

Country		Program change 123	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Springs	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click	84	Sticks 2
33	Metronome 1	85	Clap 2
34	Metronome 2	86	Tambourine 3
35	Kick 5	87	Rim shot 1
36	Kick 1	88	Snare 1
37	Rimshot 5	89	Snare 11
38	Snare 33	90	Snare 13
39	Clap 3	91	Stick 2
40	Snare 5	92	Stick 3
41	Acoustic tom 6	93	Stick 4
42	Stick 3	94	Open 2
43	Acoustic tom 5	95	Reverse
44	Stick 2	96	Applause
45	Acoustic tom 4	97	Belltree
46	Open 2	98	Telephone
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	100	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 2	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		


R & B		Program change 124	
24	Crash roll	76	Wood block hi
25	Snare 35	77	Wood block low
26	Fingersnap	78	Cuica 1
27	Slap	79	Cuica 2
28	Spings	80	Triangle 2
29	Scratch up	81	Triangle 1
30	Scratch down	82	Shaker 1
31	Sticks 1	83	Shaker 2
32	Click 1	84	Sticks 2
33	Metronome 1	85	Clap 1
34	Metronome 2	86	Tambourine 2
35	Kick 18	87	Rim shot 7
36	Kick 24	88	Snare 8
37	Rimshot 6	89	Snare 28
38	Snare 31	90	Snare 11
39	Clap 3	91	Stick 3
40	Snare 24	92	Stick 6
41	Acoustic tom 6	93	Middle 6
42	Stick 9	94	Middle 2
43	Acoustic tom 5	95	Middle 5
44	Stick 8	96	Applause
45	Acoustic tom 4	97	Belltree
46	Open 3	98	Kik 26
47	Acoustic tom 3	99	Hua
48	Acoustic tom 2	101	Hay
49	Crash 2	101	Hey
50	Acoustic tom 1	102	Huu
51	Ride 1	103	Uhh
52	Crash 3	104	Fx 1
53	Bell	105	Fx 2
54	Tambourine 1	106	Arriba
55	Splash	107	Ayombre
56	Cowbell 3	108	Cadera
57	Crash 1	109	Cumbia
58	Vibraslap	110	Sabor
59	Ride 2	111	Salsa
60	Bongo hi	112	Brrr
61	Bongo low	113	Aaah
62	Conga middle	114	Haihai
63	Conga hi	115	Rico
64	Conga low	116	Seashore
65	Timbales hi	117	Pfif
66	Timbales low	118	Jodler 1
67	Agogo hi	119	Jodler 2
68	Agogo low	120	Laser
69	Cabasa	121	Sexwhisp
70	Maracas 1	122	Scratch 1
71	Whistle short	123	Scratch 2
72	Whistle long	124	Scratch 3
73	Guiro 1	125	Scratch 4
74	Guiro 2	126	Scratch 5
75	Claves		

ACCESSORIES

9AC118	Kit Hard Disk
9AC093	Footswitch FS 13
9AC103	Footswitch FS 6
9AC112	Hardcase mod. Ketron X1 / X8
9AC113	Volume Pedal
9AC114	Sustain Pedal piano-type
9AC121	Sustain Pedal
9AC115	Flash Card 8 Mbytes
9AC116	Flash Ram 2 Mbytes Pattern Expansion
9AC117	Simm Ram 4 Mbytes Sequencer Expansion
9AC119	Kit Vocalizer
9AC120	Kit Video Interface
9PEMK8	Midi Pedalboard
9AC102	9 Effect Manual Switch
9AC101	4 Switch Volume Pedal
9AC124	Hardcase mod. Ketron X4
9AC128	Bag mod. Ketron X4
9AC123	PC Connection Cable



9AC093 - 9AC103



9AC119



9AC118



9AC124



9AC113



9AC114




9AC115



9AC116



9AC117



9AC120



9AC121



9PEMK8

MIDI IMPLEMENTATION

MIDI MESSAGE	HEX CODE	DESCRIPTION
NOTE ON	9nH kk vv	Midi channel n (0-15) note ON #kk(1-127, velocity vv (1-127) vv=0 means NOTE OFF
NOTE OFF	8nH kk vv	Midi channel n(0-15) note OFF #kk(1-127) vv is don't care
PITCH BEND	EnH Bl bh	Pitch bend as specified by bh/bl (14 bits) Maximum swing is +/- 1 tone (power-up). Can be changed Using "pitch bend sensitivity". Center position is 00H 40H.
PROGRAM CHANGE	CnH pp	Program (patch) change. Specific action on channel 10 (n=9): select drumset. Refer to sounds / drumset list. Drumsets can be assigned to other channels (see SYSEX MIDI channel to part assign and part to rhythm allocation)
CHANNEL A. TOUCH	DnH vv	Vv pressure value. Effect set using Sys. Ex. 40H 2nH 20H-26H
MIDI RESET	FFH	Reset to power-up condition
CTRL 00	BnH 00H cc	Bank select
CTRL 01	BnH 01H cc	Modulation Wheel. Rate and maximum depth can be set using SYSEX
CTRL 05	BnH 05H cc	Portamento Time
CTRL 06	BnH 06H cc	Data entry : provides data to RPN and NRPN
CTRL 07	BnH 07H cc	Volume (default=100)
CTRL 10	BnH 0AH cc	Pan (default=64 center)
CTRL 11	BnH 0BH cc	Expression (default=127)
CTRL 64	BnH 40H cc	Sustain (Damper) pedal
CTRL 65	BnH 41H cc	Portamento ON/OFF
CTRL 66	BnH 42H cc	Sostenuto pedal
CTRL 67	BnH 43H cc	Soft pedal
CTRL 84	BnH 54H cc	Wha-Wha ON/OFF
CTRL 85	BnH 55H cc	Wha-Wha Amount
CTRL 91	BnH 5BH vv	Auxiliary channel 1 send level vv=00H to 7FH
CTRL 93	BnH 5D vv	Auxiliary channel 2 send level vv=00H to 7FH
CTRL 119	BnH 77H 00H	Reset all nrpn
CTRL 120	BnH 78H 00H	All sound off (abrupt stop of sound on channel n)
CTRL 121	BnH 79H 00H	Reset all controllers
CTRL 123	BnH 7BH 00H	All notes off
CTRL 126	BnH 7EH 00H	Mono on
CTRL 127	BnH 7FH 00H	Poly on (default power-up)
RPN 0000H	BnH 65H 00H 64H 00H 06H vv	Pitch bend sensitivity in semitones (default=2)
RPN 0001H	BnH 65H 00H 64H 01H 06H vv	Fine tuning in cents (vv=00 – 100, vv=40H 0, vv=7FH+100)
RPN 0002H	BnH 65H 00H 64H 02H 06H vv	Coarse tuning in half-tones (vv=00-64, vv=40H 0, vv=7FH+ 64)
NRPN 0108 H	BnH 63H 01H 62H 08H 06H vv	Lfo 1 rate modify (vv=40H > no modif)
NRPN 0109 H	BnH 63H 01H 62H 09H 06H vv	Dco depth modify (vv=40H > no modif)
NRPN 010AH	BnH 63H 01H 62H 0AH 06H vv	Lfo 1 delay modify (vv=40H > no modif)
NRPN 0110 H	BnH 63H 01H 62H 10H 06H vv	Lfo 2 rate modify (vv=40H > no modif)
NRPN 0111 H	BnH 63H 01H 62H 11H 06H vv	Lfo 2 delay modify (vv=40H > no modif)
NRPN 0112 H	BnH 63H 01H 62H 12H 06H vv	Dcf depth modify (vv=40H > no modif)
NRPN 0113H	BnH 63H 01H 62H 13H 06H vv	Dca depth modify (vv=40H > no modif)
NRPN 0120H	BnH 63H 01H 62H 20H 06H vv	TVF cut off freq modify (vv=40H > no modif)

MIDI IMPLEMENTATION

NRPN 0121H	BnH 63H 01H 62H 21H 06H vv	TVF Resonance modify (vv=40H > no modif)
NRPN 0130H	BnH 63H 01H 62H 30H 06H vv	FM amplitude 1 (vv=40H > no modif)
NRPN 0131H	BnH 63H 01H 62H 31H 06H vv	FM amplitude 2 (vv=40H > no modif)
NRPN 0132H	BnH 63H 01H 62H 32H 06H vv	FM amplitude 3 (vv=40H > no modif)
NRPN 0133H	BnH 63H 01H 62H 33H 06H vv	FM amplitude 4 (vv=40H > no modif)
NRPN 0163H	BnH 63H 01H 62H 63H 06H vv	Env. attack time modify (vv=40H > no modif)
NRPN 0164H	BnH 63H 01H 62H 64H 06H vv	Env. decay time modify (vv=40H > no modif)
NRPN 0166H	BnH 63H 01H 62H 66H 06H vv	Env. release time modify (vv=40H > no modif)
NRPN 016BH	BnH 63H 01H 62H 6BH 06H vv	Env. sustain level modify (vv=40H > no modif)
NRPN 18rrH	BnH 63H 18H 62H rr 06H vv	Pitch coarse of drum instr. note rr in semitones (vv=40H > no modif)
NRPN 1ArrH	BnH 63H 1AH 62H rr 06H vv	Level of drum instrument note rr (vv=00 to 7FH)
NRPN 1CrrH	BnH 63H 1CH 62H rr 06H vv	Pan of drum instrument note rr (40H=middle)
NRPN 1DrrH	BnH 63H 1DH 62H rr 06H vv	Reverb send level of drum instrument note rr (vv=00 to 7FH)
NRPN 1ErrH	BnH 63H 1EH 62H rr 06H vv	Chorus send level of drum instrument note rr (vv=00 to 7FH)

EXCLUSIVE MESSAGES

TABS: F0H 26H 7CH **Code_Tab** **Status** F7H

Code Tab = 00H – 7FH

Status = 7FH Tab pressed

Status = 00H Tab released

Code tab

00H	Piano	10H	Voice A	20H	Drum Volume -	30H	Right Volume -
01H	Chrom	11H	Voice B	21H	Drum Volume +	31H	Right Volume +
02H	Organ	12H	Voice C	22H	Lower 2 Volume -	32H	One touch
03H	Guitar	13H	Voice D	23H	Lower 2 Volume +	33H	Bass to root
04H	Bass	14H	Voice E	24H	Bass Volume -	34H	Pianist
05H	Violin	15H	Voice F	25H	Bass Volume +	35H	Not Used
06H	Ensemble	16H	Voice G	26H	Chords Volume +	36H	Not Used
07H	Brass	17H	Voice H	27H	Chords Volume -	37H	Bank
08H	Sax	18H	Program	28H	Orchestral Volume -	38H	Fill 1
09H	Flute	19H	User	29H	Orchestral Volume +	39H	Fill 2
0AH	Lead	1AH	Sequencer	2AH	Lower 1 Volume -	3AH	Fill 3
0BH	Pad	1BH	Ram	2BH	Lower 1 Volume +	3BH	Fill 4
0CH	Synth	1CH	Fade	2CH	Arrange A	3CH	Registration
0DH	Ethnic	1DH	Intro/Ending 1	2DH	Arrange B	3DH	Octave
0EH	Percussive	1EH	Intro/Ending 2	2EH	Arrange C	3EH	Pattern
0FH	Effects	1FH	Intro/Ending 3	2FH	Arrange D	3FH	On live effects
40H	Bass to Lowest	50H	Key start	60H	Number 0	70H	F1 GM part
41H	Manual	51H	Key stop	61H	Number 1	71H	F2 Effects
42H	Jump	52H	Not Used	62H	Number 2	72H	F3 Utility
43H	Lock drum	53H	2 nd Voice	63H	Number 3	73H	F4 Arrange mode
44H	Lock bass	54H	2 nd Voice Edit Bass lock	64H	Number 4	74H	F5 Arrange view
45H	Lock chord	55H	Disk	65H	Number 5	75H	F6 Midi
46H	Song record	56H	Song play	66H	Number 6	76H	F7 Edit Voice
47H	Not Used	57H	Not Used	67H	Number 7	77H	F8 Edit Program
48H	Portamento	58H	Not Used	68H	Number 8	78H	F9 Drumset
49H	Harmony	59H	Cursor <	69H	Number 9	79H	F10 Drum Mixer
4AH	Count/Pause/Restart	5AH	Cursor >	6AH	Enter	7AH	Pattern edit
4BH	Tempo -	5BH	Rotor ON/OFF	6BH	Value -	7BH	Not used
4CH	Tempo +	5CH	Rotor Slow/Fast	6CH	Value +	7CH	Not used
4DH	Start/Stop	5DH	Split	6DH	Page -	7DH	Not used
4EH	Style bank A/B	5EH	Aftertouch	6EH	Page +	7EH	Not used
4FH	Factory/Custom	5FH	Exit	6FH	Hold	7FH	Not used

FOOTSWITCH: F0H 26H 79H **Code_footswitch** **Status** F7H

Code footswitch: 00H – 7FH

Status = 7FH F.Switch pressed

Status = 00H F.Switch released

Code footswitch

00H	Sustain	10H	Key Start	20H	Hi hat Off	30H	Chorus
01H	Soft	11H	Key Stop	21H	Cymbal Off	31H	Reverb
02H	Sostenuto	12H	Rotor On/Off	22H	Tom/Fx Off	32H	Distorsor
03H	Arranger A	13H	Rotor Slow/Fast	23H	Tambourine Off	33H	Text Page -
04H	Arranger B	14H	Registration Up	24H	Latin 1 Off	34H	Text Page +
05H	Arranger C	15H	Registration Down	25H	Latin 2 Off	35H	Vocalist
06H	Arranger D	16H	Tempo +	26H	Latin 3 Off	36H	Jump
07H	Intro/End 1	17H	Tempo -	27H	Groove Off	37H	Arabic 1
08H	Intro/End 2	18H	Minor	28H	Drum lock	38H	Arabic 2
09H	Intro/End 3	19H	7 th	29H		39H	Arabic 3
0AH	Fill 1	1AH	Minor 7 th	2AH	Chord lock	3AH	Arabic 4
0BH	Fill 2	1BH	5 +	2BH	Fall off	3BH	Arabic 5
0CH	Fill 3	1CH	Diminuita	2CH	Shake	3CH	Arabic 6
0DH	Break	1DH	Glide	2DH	Overdrive	3DH	Micro Dry
0EH	Start/Stop	1EH	Kik Off	2EH	Delay	3EH	Fade Out
0FH	Count In	1FH	Snare Off	2FH	Wha-wha	3FH	Crash

EXCLUSIVE MESSAGES

PARAMETER GENERAL FORM: F0H 26H 7BH **Code** **Data_1** .. **Data_n** F7H

Effect type

Reverb type	F0H 26H 7BH 00H Rev type F7H	Rev type = 00H – 13H	Reverb OFF = 7FH
Reverb level	F0H 26H 7BH 02H Level F7H	Rev Level = 00H – 10H	
Chorus type	F0H 26H 7BH 01H Chorus type F7H	Chorus type = 00H – 0BH	Chorus OFF = 7FH
Delay type	F0H 26H 7BH 06H Delay type F7H	Delay type = 00H – 0BH	Delay OFF = 7FH
Distorsor type	F0H 26H 7BH 11H Dist type F7H	Distorsor type = 00H – 0BH	Distorsor OFF = 7FH

TYPE EFFECTS CHANNEL ASSIGN: F0H 26H 7BH 00H **Channel** **Effect_Type** F7H

Channel: 00H – 0FH **Keyboard**

Channel: 10H – 1FH **GM Song Play mode**

Effect type

0	No effects	3	Chorus	5	Delay + Chorus	7	Distorsor + Delay
1	Leslie	4	Delay	6	Distorsor + Chorus	8	Distorsor + Delay + Chorus
2	Distorsor						

CHORUS PARAMETERS

F0H 26H 7BH **Delay_parameter** 00H **Value** F7H

Delay parameter	Value
2BH Feedback	0 – 7FH
2CH Filter	0 – 68H
Microphone parameter Value	

DELAY PARAMETERS

F0H 26H 7BH **Chorus_Parameter** 00H **Value** F7H

Chorus parameter	Value
3BH Volume	0 – 7FH
74H Delay	0 – 7FH
75H Feedback	0 – 7FH
76H Rate	0 – 7FH
77H Depth	0 – 7FH

DELAY PARAMETERS

F0H 26H 7BH **Delay_parameter** 00H **Value** F7H

Delay parameter	Value
2BH Feedback	0 – 7FH
2CH Filter	0 – 68H

DELAY TIME: F0H 26H 7BH 29H 00H **Time_center** (0 – 7FH) **Time_left** (0 – 7FH) **Time_right** (0 – 7FH)

DELAY VOLUME: F0H 26H 7BH 2AH 00H **Vol_center** (0 – 7FH) **Vol_left** (0 – 7FH) **Vol_right** (0 – 7FH)

DISTORSOR PARAMETER

F0H 26H 7BH **Distorsor_parameter** 00H **Value** F7H

Distorsor parameter	Value
22H Volume	00H - 7FH
25H Tone	10H - 66H
26H Resonance	18H - 7FH

MICROPHONE PARAMETER

F0H 26H 7BH **Micro_parameter** 00H **Value** F7H

50H	On	7FH
50H	Off	00H
51H	Right Volume	00H – 7FH
52H	Left Volume	00H – 7FH
53H	Right Pan	00H – 7FH
54H	Left Pan	00H – 7FH
55H	Right Echo	00H – 7FH
56H	Left Echo	00H – 7FH
57H	Right Reverb	00H – 7FH
58H	Left Reverb	00H – 7FH

EXCLUSIVE MESSAGES

EQUALIZER PARAMETER

F0H 26H 7BH **Equalizer_parameter** 00H **Value** F7H

Equalizer parameter		Value
78H	Low	00H – 0CH
79H	Mid	00H – 0CH
7AH	Hight	00H – 0CH

SPLIT POINT

F0H 26H 7BH 03H 00H **Key** F7H

Key = 00H - 7FH

GLOBAL TRANSPOSER

F0H 26H 7BH 07H 00H **Value** F7H

Value = 28H – 58H

No transposer = 40H

STYLE NUMBER

F0H 26H 7BH 08H 00H 00H **Style** F7H

Style = 01H – 63H

SONG NUMBER:

F0H 26H 7BH 09H 00H **Song_C** **Song_D** F7H

Song_C = 0 – 9 Centinaia

Song_D = 0 – 99 Decine

SCALE TUNING (ARABIC)

F0H 26H 7BH 0AH **Channel** **Data1...** **Data12** F7H

Data = 00H – 7FH

No detune = 40H

Channel = 00H – 0FH

Right channels = 10H

Lower channels = 7EH

All channel = 7FH

MASTER TUNE

F0H 26H 7BH 0CH 00H **Data1** **Data2** F7H

Data1 = 00H – 0CH High nibble

Data2 = 00H – 0FH Low nibble

Examples:

Data1 = 06H

Data1 = 00H

Data1 = 0CH

Data2 = 64H No tune

Data2 = 00H -100 % Tune

Data2 = 08H Tune

GM PART

GM PART MUTE	F0H 26H 7BH 0DH 00H Part Mute_On/off F7H	Part: 01H – 10H	On =7FH Off =0FH
GLOBAL GM RESET	F0H 26H 7BH 0EH 00H Value F7H	Reset: 00H	Reset + All note Off 01H
DRUM PART	F0H 26H 7BH 0FH 00H Part Value F7H	Part: 00H – 0FH	Voice: 00H Drum
MIDI RX CHANNEL	F0H 26H 7BH 12H 00H Part Channel F7H	Part: 00H – 0FH	Channel: 00H – 10H Off: 00H
MIDI TX CHANNEL	F0H 26H 7BH 18H 00H Part Channel F7H	Part: 00H – 0FH	Channel: 00H – 10H Off: 00H
KEY SHIFT	F0H 26H 7BH 1AH 00H Part Shift_Value F7H	Part: 00H – 10H	Shift Value: 10H – 70H No Shift: 40H

GM PART FILTER

F0H 26H 7BH 2FH 00H **Event** **Part** **Value** F7H

Part = 01H – 10H

All Parts = 7FH

Value: **Off** = 00H **On** = 01H

Event

0	Note	3	After touch	6	Pan	9	Modulation	12	Nrpn
1	Control change	4	Pitch bend	7	Reverb	10	Expression	13	Excl. Message
2	Program change	5	Volume	8	Chorus	11	Rpn		

EXCLUSIVE MESSAGES

MIDI KEYBOARD RX CHANNEL

F0H 26H 7BH 13H 00H **KeyPart Channel** F7H

Channel = 00H – 10H

Off = 00H

KeyPart

0	Preset	4	Bass	8	Groove	12	Program Voice 1	16	Right
1	2 nd Voice	5	Chord 1	9	Drum	13	Program Voice 2	17	Left
2	Lower 1	6	Chord 2	10	Chord 4	14	Program Voice 3	18	Global
3	Lower 2	7	Chord 3	11	Chord 5	15	Program Voice 4	19	Registration

MIDI KEYBOARD TX CHANNEL

F0H 26H 7BH 19H 00H **KeyPart Channel** F7H 00H – 7FH

Channel = 00H – 10H

Off = 00H

0	Preset	4	Bass	8	Groove	12	Program Voice 1	16	Right
1	2 nd Voice	5	Chord 1	9	Drum	13	Program Voice 2	17	Left
2	Lower 1	6	Chord 2	10	Chord 4	14	Program Voice 3	18	Global
3	Lower 2	7	Chord 3	11	Chord 5	15	Program Voice 4	19	Registration

VELOCITY CURVE

F0H 26H 7BH 00H **Curve** F7H

Curve = 00H – 05H

00H	Soft 1
01H	Soft 2
03H	Normal
04H	Hard 1
05H	Hard 2
06H	Fixed

FIXED VELOCITY CURVE VALUE

F0H 26H 7BH 16H 00H **Value** F7H

Value: 01H – 7FH

LEFT LEVEL

F0H 26H 7BH 1CH 00H **Left_level** F7H

Left level: 00H – 7FH

SONG BALANCE

F0H 26H 7BH 1DH 00H **Song_balance** F7H

Song balance

REGISTRATION BANK & NUMBER

F0H 26H 7BH 1EH 00H **Bank_reg Number_reg** F7H

Bank reg: A = 0 B = 1

Number reg: 1 – 99

VELOCITY SLOPE

F0H 26H 7BH 3EH 00H **Part_Value** F7H

Part: 01H – 20H

(01H – 10H Keyboard Part; 11H – 20H GM Part (Song Play))

Value: 00H – 7FH

VELOCITY OFFSET

F0H 26H 7BH 3FH 00H **Part_value** F7H

Part: 01H – 20H

(01H – 10H Keyboard Part; 11H – 20H GM Part (Song Play))

Value: 00H – 7FH

EXCLUSIVE MESSAGES

FILTER VELOCITY SLOPE

F0H 26H 7BH 40H 00H **Part_value** F7H

Part: 01H – 20H

(01H – 10H Keyboard Part; 11H – 20H GM Part (Song Play))

Value: 00H – 7FH

FILTER VELOCITY OFFSET

F0H 26H 7BH 41H 00H **Part_value** F7H

Part: 01H - 20H

(01H – 10H Keyboard Part; 11H – 20H GM Part (Song Play))

Value: 00H – F7H : 00 – 7FH Default: 40H

MODULATION, BEND, AFTERTOUCH, VOICES CONTROLS

F0H 26H 7BH **Control** 00H **Part Value** F7H

Part: 01H – 20H

(01H – 10H Keyboard Part; 11H – 20H GM Part (Song Play))

Value: 00H – 7FH

Control

42H	Mod. Pitch ctrl	4AH	Bend TVF cutoff	5CH	A.touch Lfo pitch
43H	Mod. Pitch cutoff	4BH	Bend amplitude	5DH	A.touch Lfo TVF depth
44H	Mod. Lfo amplitude	4CH	Bend Lfo pitch	5EH	A.touch Lfo TVA depth
45H	Mod. Lfo rate	4DH	Bend Lfo TVF	60H	Voices pitch ctrl
46H	Mod. Lfo pitch depth	4EH	Bend Lfo TVA	61H	Voices TVF cutoff
47H	Mod. Lfo TVF depth	59H	A.touch pitch ctrl	62H	Voices amplitude
48H	Mod. Lfo TVA depth	5AH	A.touch TVF cutoff	63H	Voices Lfo pitch
49H	Bend pitche control	5BH	A.touch amplitude	64H	Voices Lfo TVF depth
				65H	Voices Lfo TVA depth

GENERAL MIDI VOLUME

F0H 26H 7BH 38H 00H **Value** F7H

Value: 00H – 7FH Default: 7FH

GENERAL MIDI PAN

F0H 26H 7BH 39H 00H **Value** F7H

Value

- The numbers followed by letter H are hexadecimal numbers.
- The numbers not followed by letter H are decimal number.

TECHNICAL SPECIFICATIONS

Keyboard	X1: 61 weighted keys. After Touch. 6 Velocity Curves. Split/Bend & Modulation Wheels. X8: Right 52 keys . Left : 120 Bases.
Polyphony	64 notes. 32 Multitimbral.
Sound Source	276 Sounds. 20 Drum Sets. 231 Percussions. Drum Grooves. Pcm, Analog (Saw, Square, Sine), Fm Voicing.
User Voices	128 programmable User Voices. Controls :ADSR,Filter,LFO, Wheels, Aftertouch, Effect.
Sound Card	Flash Card 8Mbyte (optional).
Sound Ram	Simm 16 Mbytes.
Factory Styles	198 Rom Styles (2 Banks x 99). 10 parts: Drums, Bass, Groove, 5 Chords, Lower 1, Lower 2, 4 Arrangers, 3 Intros, 3 Endings, 4 Fill Ins. Jump. Arrange Lock :Drum, Bass, Chords, Bass to Lowest. Bass to Root. Manual Bass. Bass Octave. Bass Sustain. Pedalboard. Swell to Right. Lower octave.Lower Hold. Left Level balance. Key Start. Key Stop. Restart. Count In. Start. Hold. Tempo Slow/Fast (40 - 250). Accelerando/Ritardando.
Custom Styles	198 Custom Styles with programmable Parameter Edit for Factory Styles.
Drum Mixer	10 Drum sections: Kick, Snare, Hi Hat, Cymbal, Tom/Fx, Tambourine, Latin 1, Latin 2, Latin 3, Groove, Drum On/Off switches. Controls: Volume,Reverb, Panpot.
User Drum Set	4 programmable User Drum Sets. Pitch, Key Shift.
Patterns	Up to 99 internal Patterns, Flash RAM 2Mbyte expansion (optional).
Registrations	198 panel Registrations (2 Banks x 99). Up to 999 Single Disk Registrations each Folder.
Programs	128 Programs. 4 Voices. 4 splits. Effects. Duet. Trio. Velocity switch.
Drawbars	8 Digital Drawbars.16 Organ effects. Click, 2nd and 3rd percussion.
One Touch	48 (2 Banks x 24) 1 Touch settings for Right hand.
2nd Voice	2nd Voice programmable on Voices for Bank 1, 2, User and Drawbar.
2nd Voice Edit	Voice change, Volume, Transposer.
Octave	Up/Down +/- 1 octave.
Harmony	Full, Jazz, Double up, Double down, Bluegrass, Trill, Repeat, Repeat Speed.
Portamento	Rate control +/- 64. Mono Legato function.
Transposer	+/- 24 halftones.
Aftertouch	Assignable to Cut Off, Volume, Bend, Slide, LFO. Attack, Threshold and Sensitivity control.
Modulation Wheel	LFO to Pitch, to DCF, to DCA, Wha Wha, Swell, Rate.
Pitch Wheel	Tune +/- 99 cents. Vibrato On/Off. Bend value 0/24. Bend to LFO, DCF, DCA.
Arabic Scale	Tune +/- 99 cents per note. 6 Arabic set up. Footswitch assignable.
Accordion Mode	International, Belgique. Left/Right Velocity control. Bass Octave, Bass Sustain, Bass to Chord recognition, Lower 1/2 Octave. Left Drum to Bass, to Chord.
Effects	2 digital multi-effect DSP's. 60 different Effects. Reverberation, Chorus, Flanger, Feedback, Delay, Wha Wha, Distortion, Overdrive, Rotor Slow/Fast, Equalizer +/-12 db (Low, Middle, High). 16 User Effects.
Sampler	8 Mbyte Sampling 16 Bit - 44.100 KHz. Recording: Time, Trigger, Loop type, Reverse, Delete. Load & Save for. Wave files. Sample Edit: Start, End, Level, Pitch, Zoom, Key, Tune. Up to 8 Multisample with 32 splits each. Multisample (MSP) edit : A,D,S,R, Cut Off, Velocity, Effects, Octave, Level.
Vocalist	(optional). Harmonizer, Vocoder, Melody types, Midi Vocalist track, Left and Right assign, Reverb, Delay, Transpose, Level, Hold. Filter edit: Formant, Frequency, Resonance, Equalizer.
Midi	32 Midi Channels. General Midi standard.
Sequencer	16-tracks. 30.000 Notes. Up to 300.000 notes with 4Mbyte Simm (optional).
Floppy Disk Drive	3.5" 2DD/2HD, SMF Song Playback. Real Time Song Recording. 0/1 Format. Data Save/Load for Custom Styles, Patterns, Programs, Registrations,User Drum Set, User Voice, Sounds. Song Play/Pause. Songs with Lyrics. Karaoke (Reverse, Underlined, Mark). Juke Box ,Lead & Lyric On/Off. Song List. Song Text (Font 1/2).
Video Interface	(optional).
Hard Disk	from 1Gbyte (up to 8 Gbyte max). Type: ATA - IDE 2,5". Up to 99 Folders. 999 Files per Folder. (Optional on Ketron X1 standard).
Computer Interface	PC/Mac interface (Cables & software optional).
Display	240 x 128 pixel backlit graphic TFC.
Out.Assign	GM/Keyboard Out assignment to the 4 audio Outputs.
Amplification	2 x 22 W RMS. 4 Speakers. Speaker On/Off switch. (X1 and X8 only)
Inputs	Stereo Headphone. 2 Line Inputs: Left/Mono, Right. Microphone stereo input. Gain control. Level, Pan/pot, Echo, Reverb, Pitch Shift +/- 12, Dry.
MIDI	Midi In1, In2, Out, Thru.
Outputs	Left/Mono (1), Right (2), 3, 4.Sustain Pedal. Volume Pedal. Footswitch (6 or 13 switches).
Standard accessories	Music stand. Ac cord.
Optional accessories	Hard Disk (only for Ketron X1 standard) Flash Card 8Mbyte Sound Bank 8 or 16 Mbyte. Pattern Flash expansion 2Mbyte. Sequencer Simm expansion 4 Mbyte. Volume Pedal. Footswitch FS 6 - FS 13. Vocalist kit. Sustain Pedal Sustain Pedal Piano type Midi Pedalboard Volume Pedal 4 switches . 9 effect manual switch. Hard Case Video Interface Computer Interface kit for PC (Cable & Software) Computer Interface kit for Mac (Cable & Software)
Dimensions	X 1 /X 8: 17 x 40,5 x 15,5 cm. X 4: 25 x 59 x 12 cm.
Weight	X1/X 8: Kg. 16 X 4: Kg. 7 approx.

Specifications and appearance are subject to change without notice.

ABNORMAL RUNNING CONDITIONS

PROBLEM	POSSIBLE CAUSE / SOLUTION
The keyboard fails to play	The Master volume or Pedal Volume are set at minimum. The Fade Out is enabled The Ear phones are enabled
The Arranger fails to start	Make sure that the Clock Midi is not set in External
Difference in long sound of the keyboard	this is normal. The Multiple-sampling technique involves these sound differences
Some notes are cut	This may occur if the max. polyphony of 64 notes is exceeded, using Programs + Harmony Close + Arranger for example
The effect changes when the Voice is changed	This is normal. Each Voice is called-up with its own effect.
There is an octave difference between the sounds and the Song	This is normal. The octave most suitable for the song has been selected for each sound.
The Disk Save and Load operations with .Wave files are slow	Normal. The time of the Load / Save operations depends on the amount of PCM data of the samples or .Waves considered
The Rotor Effect does not affect all the Organ Voices	Normal: these are some Organ sounds already sampled with their own original modulation effects
The Vibrato is not cut out on some Voices	Normal: these are Voices in which the Vibrato is integral part of the actual sample

For any other problems or abnormal running conditions different to those indicated it is advisable to contact one of our authorized service centres or in any event highly skilled personnel.

ERROR MESSAGES

Here is a list of the most common Error messages together with the indication of the problems to which they refer:

Disk Full	Disk full
Folder Full	The Folder is full.
Pattern Flash Full	The pattern memory is full.
Hd Fatal Error	The Hard Disk is broken or damaged
Folder Error	Generic error encountered in the Folder
Read Error	Reading Error on Disk
Time Error	The Disk fails to respond
Disk Error	Generic Disk Error
Write Error	Writing Error on Disk
Name Error	The name is not acknowledged
Song error	Error during Song copying
Read File Error	Reading Error on Disk
Disk not Ready	The Disk fails to respond to the commands
Diskette absent	The Disk is not inserted in the Floppy Driver
Diskette protected	The Disk is safeguarded
Folder Protected	The Folder is locked.
File Corrupted	The File is damaged
File not Found	No file stored in the directory
Disk not Formatted	Floppy or Hard Disk are not formatted
Pat. Flash Corrupted	The Pattern memory is damaged
Time Sig. not Equal	The Time Signature between 2 Patterns is not compatible
Measures not Equal	The Musical division between 2 Patterns is not compatible.
Pattern Corrupted	The File Pattern is damaged

[illegible]

[illegible]